

Installation Manual

Premier 412/816/832

INS159-13



Texecom

Contents


| | | | |
|--|-----------|--|-----------|
| 1. System Overview..... | 5 | Troubleshooting | 20 |
| System Architecture..... | 5 | Power Faults | 20 |
| Control Panels..... | 5 | Remote Keypads | 20 |
| Remote Keypads | 5 | Remote Expander | 20 |
| Zone Expansion Modules | 6 | Zones | 21 |
| PC-Com Module..... | 6 | Service Faults..... | 21 |
| ComIP Module..... | 6 | Communicator | 21 |
| Speech Module | 6 | Operation | 21 |
| Radio Receiver Module..... | 6 | | |
| 2. Installation..... | 7 | 4. Programming the Control Panel..... | 22 |
| Installation Sequence | 7 | Introduction..... | 22 |
| Control Panel..... | 7 | Viewing Numeric Data (LED Keypads) | 22 |
| Mounting | 7 | Programming Text (LCD Only) | 22 |
| Wiring the Control Panel | 7 | V16 Start up Procedure | 23 |
| Control Panel PCB Layout..... | 8 | Premier RKP8 & 16 LED Keypads..... | 23 |
| Power Supply Ratings..... | 9 | Premier LCD Keypads | 23 |
| All Models (Large & Small Polymer) | 9 | Program Menus | 24 |
| All Models (Metal) | 9 | Programming Zones..... | 25 |
| Connecting AC Mains | 10 | All Zone Options ①①..... | 26 |
| Connecting Devices to the Data Bus | 10 | Zone Type ①①..... | 26 |
| Wiring the Data Bus | 10 | Zone Wiring ①②..... | 27 |
| Cable Type and Distances..... | 10 | Zone Attributes 1 ①③..... | 27 |
| Installing a Power Supply | 10 | Zone Attributes 2 ①④..... | 28 |
| Overcoming Voltage Drop | 11 | Zone Attributes 3 ①⑤..... | 28 |
| Use of pull up resistors | 11 | Zone Attributes 3 (Key Switch) ①⑤..... | 29 |
| Installing Remote Keypads..... | 12 | Zone Partitions & Groups ①⑥..... | 29 |
| Keypad Layouts | 12 | Zone Text (LCD Only) ①⑦..... | 29 |
| Remote Keypad Connections | 12 | Assign Radio Device ①⑧..... | 29 |
| Remote Keypad Address | 12 | Programming Partitions | 30 |
| Keypad Zones | 12 | Partition Exit Delay ②①..... | 31 |
| Keypad Output..... | 12 | Partition Entry Delay 1 ②①..... | 31 |
| Keypad Speaker Output (LCDL/LCDLP FMK/SMK) | 13 | Partition Entry Delay 2 ②②..... | 31 |
| Adjustable Backlighting | 13 | Partition Communication Delay ②③..... | 31 |
| Keypad Lid Tamper..... | 13 | Partition Bell Delay ②④..... | 31 |
| Remote Zone Expander Module..... | 13 | Partition Bell Duration ②⑤..... | 31 |
| Remote Expander Layout | 13 | Partition Options ②⑥..... | 31 |
| Wiring the Zone Expander | 13 | Partition Auto Arm/Disarm Options ②⑦..... | 32 |
| Remote Expander Address..... | 13 | Equipment Areas ②⑧..... | 32 |
| Remote Expander Zones | 13 | Programming Global Options | 33 |
| Zone Expander Outputs..... | 14 | System Timers ③①..... | 35 |
| Zone Expander Speaker Driver | 14 | System Counter/Levels ③①..... | 36 |
| Local Zone Expander Module..... | 14 | System Control Timers ③②..... | 36 |
| Local Expander Layout | 14 | System Options 1 ③③..... | 36 |
| Local Expander Zones | 14 | System Options 2 ③④..... | 37 |
| Installing the Local Zone Expander | 14 | System Options 3 ③⑤..... | 37 |
| Zone Connections | 15 | Hardware Options ③⑥..... | 38 |
| Normally Closed..... | 15 | Auxiliary Input Options ③⑦..... | 38 |
| Normally Open | 15 | Miscellaneous Options 1 ③⑧-①..... | 38 |
| Single EOL - N/C & N/O (Burglary)..... | 16 | Miscellaneous Options 2 ③⑧-②..... | 39 |
| Single EOL - N/O (Fire) | 16 | Miscellaneous Options 3 ③⑧-③..... | 40 |
| Single EOL - N/C..... | 16 | EN50131 Options ③⑨..... | 40 |
| Single EOL - O/C Tamper | 16 | Programming Remote Keypads..... | 41 |
| Single EOL - S/C Tamper | 16 | Keypad Options 1 ④①..... | 42 |
| Double EOL..... | 17 | Keypad Options 2 ④①..... | 42 |
| Zone Doubling | 17 | Keypad Options 3 ④②..... | 42 |
| Triple EOL | 17 | Keypad Options 4 ④③..... | 43 |
| Double Pole..... | 18 | Programming Remote Expanders..... | 44 |
| 2-Wire Smoke Detector | 18 | Expander Partitions ⑤①..... | 44 |
| Speaker/Bell Connections | 18 | Expander Tones ⑤①..... | 44 |
| Speaker Operation..... | 18 | Expander Volume Level ⑤②..... | 44 |
| Siren/Bell Operation..... | 19 | Programming System Outputs..... | 45 |
| Siren/Spk Supervision..... | 19 | Panel Outputs ⑥①..... | 47 |
| Telephone Line Connections..... | 19 | Fast Format/Speech Channels ⑥①..... | 47 |
| Panel Outputs 1 - 8..... | 19 | Expander 1 Outputs ⑥②..... | 47 |
| Output Wiring | 19 | Expander 2 Outputs ⑥③..... | 47 |
| Output Supervision | 19 | Expander 3 Outputs ⑥④..... | 47 |
| | | Keypad Outputs ⑥⑤..... | 47 |
| 3. Commissioning & Troubleshooting..... | 20 | Output Groups and Types..... | 47 |
| Commissioning | 20 | Output Attributes..... | 49 |
| | | Programming the Communicator | 50 |
| | | Communicator Options ⑦①..... | 52 |
| | | ARC 1 Communicator Menu ⑦①..... | 52 |
| | | Telephone Numbers ⑦①-①..... | 52 |

| | | | |
|--|-----------|--|-----------|
| Account Numbers 7-1-1 | 53 | Acknowledging a New Service Fault | 75 |
| Protocol Type 7-1-2 | 53 | View Service Faults | 76 |
| Dial Attempts 7-1-3 | 53 | Anti-code Reset..... | 77 |
| Partition Options 7-1-4 | 53 | Toggle Chime On and Off..... | 77 |
| Reporting Options 7-1-5 | 54 | Change User Code | 77 |
| Pulse Format Options 7-1-6 | 54 | View Log (LCD Only) | 77 |
| Fast Format Reporting Channels 7-1-7 | 54 | Abort Communications..... | 77 |
| Protocol Options 7-1-8 | 55 | 6. Specifications..... | 78 |
| ARC 2 Communicator Options 7-2 | 55 | Control Panel | 78 |
| Fast Format Restore Channels 7-3 | 55 | All Models Large & Small Polymer | 78 |
| Fast Format Open/Close Channels 7-4 | 56 | All Models Metal | 78 |
| Cancel Call Waiting Sequence 7-5 | 56 | Remote Keypads..... | 79 |
| Programming Check List | 57 | Remote Zone Expander..... | 79 |
| Programming Download Options | 58 | Local Zone Expander | 79 |
| Download Menu 7-6 | 60 | Safety Notes..... | 79 |
| Download Options 7-6-0 | 60 | Standards | 79 |
| Call Back Number 7-6-1 | 60 | EN 50131-1/3/6 Compliance | 79 |
| UDL Passcode 7-6-2 | 60 | Warranty | 80 |
| Download Dial Attempts 7-6-3 | 60 | 7. Quick Reference Guide | 81 |
| Ring Count 7-6-4 | 60 | 8. Standard Defaults & Programming | |
| Com1 Device Type 7-6-5 | 60 | Records..... | 86 |
| IP Address & Port 7-6-6 | 61 | Installation Details | 86 |
| ComIP Gateway Address 7-6-7 | 61 | Zone Details..... | 86 |
| ComIP Subnet Mask 7-6-8 | 61 | Programming Worksheets & Defaults | 87 |
| Com2 Device Type 7-6-9 | 61 | Notes | 99 |
| Chiron Iris Data Setup 7-6-10 | 61 | | |
| Programming Reporting Codes..... | 62 | | |
| Zone Alarm/Restore Codes 7-7 | 63 | | |
| Zone Bypass/Unbypass Codes 7-8 | 63 | | |
| Non Zone Alarm/Restore Codes 7-9 | 63 | | |
| Contact ID and SIA Codes | 63 | | |
| Programming Users | 64 | | |
| Program User 8-0 | 66 | | |
| User Options 1 8-1 | 66 | | |
| User Options 2 8-2 | 66 | | |
| User Options 3 8-3 | 67 | | |
| User Text (LCD Only) 8-4 | 67 | | |
| Program Standard Users 8-5 | 67 | | |
| Default ALL Users 8-6 | 67 | | |
| System Tests & Utilities | 68 | | |
| Walk Test 9-0 | 69 | | |
| Test Speakers & Outputs 9-1 | 69 | | |
| Send Test Call 9-2 | 69 | | |
| Enable Remote/Engineer Access 9-3 | 69 | | |
| Start Call Back 9-4 | 69 | | |
| Program Time 9-5 | 69 | | |
| Program Date 9-6 | 69 | | |
| Program Banner Text (LCD only) 9-7 | 69 | | |
| Print 100 Events 9-8 | 69 | | |
| Log Off Engineer 9-9 | 69 | | |
| 5. Operating the Alarm System | 70 | | |
| Introduction | 70 | | |
| Access Codes | 70 | | |
| Arming & Disarming the Alarm System | 70 | | |
| Checking if the System is Ready to Arm | 70 | | |
| Away Arming..... | 70 | | |
| Stay Arming | 70 | | |
| Cancelling the Arming Process | 71 | | |
| Disarming During Entry | 71 | | |
| Disarming when not in Entry | 71 | | |
| Disarming after an Alarm | 71 | | |
| Auto Stay Arming..... | 71 | | |
| Changing between Delayed and Instant Stay..... | 71 | | |
| Arming and Disarming Partitions..... | 72 | | |
| Away Arming Partitions..... | 72 | | |
| Stay Arming Partitions | 72 | | |
| Disarming Partitions | 72 | | |
| Changing to another Partition | 73 | | |
| Bypassing Zones..... | 73 | | |
| Manually Bypassing Zones | 73 | | |
| Unbypassing Zones..... | 73 | | |
| Group Bypass..... | 74 | | |
| Quick Bypass and Arm..... | 74 | | |
| Reset Alarms | 75 | | |
| Last Alarm Log..... | 75 | | |
| Service Faults | 75 | | |

System Overview**Installation****Control Panel PCB Layout****Installing Remote Keypads & Expanders****Zone Connections****Siren/Bell, Telephone and Panel Outputs****Commissioning & Troubleshooting****Programming Menus****Programming Zones****Programming Partitions****Programming Global Options****Programming Remote Keypads****Programming Remote Expanders****Programming System Outputs****Programming the Communicator****Programming Download Options****Programming Reporting Codes****Programming Users****System Tests, Utilities and Using *RadioPlus*****Operating the Alarm System****Specifications****Quick Reference Guide & Defaults**

1. System Overview

System Architecture



Control Panels

The *Premier 412*, *816*, *816 Plus* and *Premier 832* are highly sophisticated security control panels with Integrated Multi-protocol Digital Communicator/Modem. The control panels have the following features:

| Features | 412 | 816 | 816 Plus | 832 |
|----------------------------------|-----|-----|----------|------|
| Zones | 4 | 8 | 8 | 8 |
| Max. Zones when expanded | 12 | 16 | 16 | 32 |
| Partitions | 2 | 4 | 4 | 4 |
| User Codes | 32 | 32 | 32 | 64 |
| Event Log | 750 | 750 | 750 | 1000 |
| Mandatory Log Events (EN50131-3) | 250 | 250 | 250 | 250 |
| Touch Tone Remote Control | x | x | ✓ | ✓✓ |
| Programmable Aux. Input | ✓ | ✓✓ | ✓ | ✓✓ |
| Supervised Siren/Bell Output | ✓ | ✓✓ | ✓ | ✓✓ |
| 2 x 1A Supervised Outputs | ✓ | ✓✓ | ✓ | ✓✓ |
| 6 x 100mA Outputs | ✓ | ✓✓ | ✓ | ✓✓ |
| Printer/UDL Port | ✓ | ✓✓ | ✓ | ✓✓ |
| Integrated Modem/Communicator | ✓ | ✓✓ | ✓ | ✓✓ |

Remote Keypads

The control panels will accept up to a maximum of 6 remote keypads. All remote keypads require a 4-wire connection to the data network and have a built in piezoelectric sounder. The following remote keypad models are available:

Premier RKP4/8/16

A cost effective range of remote keypads with either 4, 8 or 16 zone indicator lights.

- 4-wire connection to data network.
- Built in piezoelectric sounder.
- Dual level back-lighting, normally dim, switching to bright for 8 seconds after any key press
- Dedicated status lights for "Alarm", "Service", "Armed" and "Ready".

Premier RKP8/16 Plus

A professional range of LED remote keypads with either 8 or 16 zone indicator lights.

- 2 programmable EOL zones.
- 4-wire connection to data network.
- Built in piezoelectric sounder.

- Fully adjustable back-lighting, normally bright, dim or off, changing to bright whenever a keypad is used and during the entry mode
- Dedicated status lights for “Alarm”, “Service”, “Armed”, “Ready”, “Fire”, “Bypass”, “Instant” and “Stay”

Premier LCD & LCDL

The *Premier LCD* remote keypad has a standard 32 character back-lit LCD display, whereas the *Premier LCDL* has a large 32 character back-lit LCD display.

- 2 programmable EOL zones
- 1 programmable low current (100mA) output
- 4-wire connection to data network.
- Built in piezoelectric sounder.
- Fully adjustable back-lighting, normally bright, dim or off, changing to bright whenever a keypad is used and during the entry mode
- Dedicated status lights for “Power”, “Armed”, “Ready”, “Service” and “Bypass”
- Speaker driver output (*Premier LCDL* Only).

Premier LCDLP

- *Premier LCDL* keypad with built-in proximity tag reader

Premier LCDP

- *Premier LCD* keypad with built-in proximity tag reader

Premier Elite FMK

- *Flush Mount LCDLP with built in proximity tag reader iconic keys.*
- *Available in various finishes*

Premier Elite SMK

- *Flush Mount LCDLP with built in proximity tag reader iconic keys.*
- *Available in various finishes*

Zone Expansion Modules

Either system can be expanded using one of the following zone expansion modules:

Premier 8X Remote Zone Expander

This module comes supplied in its own enclosure and is connected to the control panel data network to provide remote expansion of the system. This module provides the following additional facilities:

- 8 programmable EOL zones
- 2 programmable low current (100mA) outputs
- Speaker driver output with electronic volume control.

Premier 8XE Local Zone Expander

This module comes supplied as a PCB and simply plugs onto the main control panel circuit board. This module provides 8 programmable EOL zones.

PC-Com Module

This module plugs on to the *Premier 412*, *816* and *Premier 832* control panel to provide an RS232 interface, which can be used for:

- Connection of a serial printer to print the event log
- Upload/download the system programming via *Wintex UDL* software and PC.

ComIP Module

This module plugs on to Com1 or Com2 of the control panel to provide the following:

- Alarm event reporting via TCP/IP (WAN/LAN).
- High speed upload/download of system programming via WAN/LAN using *Wintex UDL* software.

Speech Module

This module plugs on to the control panel to provide the following:

- 4 recordable messages (12 seconds each).
- Each message can be assigned to a specific output function, e.g. Alarm or Fire.

This manual does not cover the full installation of this device; please refer to the instructions supplied with the *Speech Module*.

Radio Receiver Module

The control panel will accept either the Texecom *Ricochet™* Premier Elite 8XP-W or Premier Elite 32XP-W. The receiver module should be wired to the control panel network to provide the following:

- 32 wireless devices, such as PIR, Door Contacts, Shock Sensors, Remote FOBs etc.
- *Ricochet™* Mesh Networking Technology
- RF supervision of each device.
- Battery supervision of each device.

This manual does not cover the full installation of these devices; please refer to the instructions supplied with the radio receiver module.

2. Installation

Installation Sequence

Before attempting to install the alarm system, read this section. Once you have an overall understanding of the installation sequence, carefully work through each step.

1: Design the Layout

Make a rough sketch of the premises to get an idea of where all alarm detection devices, keypads and other modules are to be located.

2: Mounting the Panel

The control panel should be mounted in a dry area close to an unswitched AC power source and the incoming telephone line.



NOTE

You must complete all wiring before connecting the battery, or applying AC to the panel.



NOTE

Some versions of the control panel are not supplied with an integral mains transformer. If this is the case a suitable external mains transformer will be required (see page 78)

3: Install the Keypads

Mount and connect the keypads to the control panel.

4: Zone Wiring

Install detection devices and connect to control panel.

5: Other Wiring

Complete all other wiring including bells or sirens and telephone line connections.

6: Apply Power to the Control Panel

Once steps 1 to 5 are completed, apply power to the control panel. First, connect the red battery lead to the positive terminal and the black lead to negative. Then, connect the AC.

7: Complete the Installation Records & Defaults Worksheets

On page 86 you will find "Installation Records and Defaults" worksheets. These worksheets allow you to record all programming data and also lists all program defaults. It is recommended that the worksheets are filled in before attempting to program the system.

8: Program the System

Using the Programming Worksheets program the control panel in accordance with the procedures in Section 3.

9: Testing the System

Test the system thoroughly to ensure that all features and functions are operating as required.

Control Panel

Mounting

Mount the control panel on a flat, plumb wall using at least three appropriate screws. The rear casing has been designed with a central key-hole slot so that mounting is possible without removing the Printed Circuit Board (PCB).

The angled slot in the lower corner has been provided to allow the panel to be levelled easily. If the PCB has to be removed, carefully pull back the two front PCB securing clips, lift the front of the PCB and slide it downward. To replace the PCB simply reverse the above procedure.



NOTE

It is essential to ensure that none of the fixing slots or cable entries are accessible after fixing.

Mains cabling must be secured (e.g. with a cable tie) to one of the anchor points provided.

Wiring the Control Panel

WARNING: ELECTRICITY CAN KILL

BEFORE connecting the control panel
ALWAYS disconnect the supply at the consumer unit.
If in ANY doubt consult a qualified electrician.



ONLY connect the mains supply to the mains terminal block, NEVER connect the mains supply directly to the PCB.

The system installation MUST be carried out in accordance with the national safety standards, for example EN 60950: 1992.

ALWAYS refer to National Wiring Regulations when conducting installation.


An appropriate and readily accessible disconnection device (e.g. an unswitched fused spur) MUST be provided as part of the installation.

The disconnection device must NOT be fitted in a flexible cord.

Where identification of the neutral in the mains supply is NOT possible, a two-pole disconnection device MUST be used.

Use mains cable of adequate carrying capacity for the rated current (i.e. at least 0.75mm²).

Control Panel PCB Layout



1: Earth Ground Connection

Earth ground. Connect to earth or an earth rod.



Failure to fit an earth cable may prevent proper operation of the system and will invalidate the Texecom warranty and product approvals.

2: AC Input

Connect to a 16.5V transformer.



Do NOT connect the mains supply to the AC input terminals.

3: Battery Connections

A 12V rechargeable battery must be connected to these two terminals in order to provide continuous system operation in the event of mains failure. The battery output is protected by fuse F1 (1.6 Amp).

4: Data Bus Connections

The data bus terminals provide connections to the remote keypads and *Premier 8X Remote Zone Expander*. The + and - terminals provide power whilst the T and R terminals are transmit and receive data.

5: Siren/Spk output

These terminals are used for driving speakers, sirens or bells. The output can be programmed for speaker driver or for Siren/bell driver (see page 36). This output is supervised, if no warning devices are fitted, either fit a 1K Ω resistor between these two terminals or disable the siren supervision, see page 38.

6: Auxiliary 12V Power

These terminals provide auxiliary power for devices that require 12V power. The auxiliary output is protected by fuse F2 (1 Amp).

7: Zone Inputs 1 to 8

These terminals provide the connections to the zone inputs. The *Premier 816* and *Premier 832* have 8 zone inputs, whereas the *Premier 412* has only 4 zone inputs. There are several ways to wire a zone (see page 14). Each zone is fully programmable, see page 25 for information on programming zones.

8: Two-Wire Smoke Detector Enable

Set this link as shown when connecting 2-wire smoke detectors to Panel Output 1.



Output 1 is enabled for 2-wire smoke detectors



Output 1 is normal

9: Aux Input

This is a programmable input, it can be used for monitoring auxiliary tamper devices etc, see page 38 for programming details.

10: Panel Outputs 1 to 8

These are programmable outputs. Panel outputs 1 and 2 are high current (1 Amp) supervised outputs. If panel outputs 1 or 2 are not used, either fit a 1K Ω resistor between the unused output and Auxiliary 12V + or disable the output supervision, see page 38. Panel outputs 3 to 8 are low current (100mA) outputs.

11: Communication Ports 1 and 2

Serial communication ports 1 and 2, these can be used for third party devices or PC for local downloading.

12: Load Defaults

Short between the centre and either of the outer pins during power up to restore the control panel default program parameters. These pins can also be used to reset the Engineer code back to its default value, see page 69.



NOTE Do not leave these pins shorted, otherwise the control panel event log will be erased.

13: Box Tamper Disable

Fit link as shown:



Box Tamper Disabled



Box Tamper Enabled

14: Local Zone Expander

The *Premier 8XE Local Zone Expander* can be plugged on to the main PCB. The local expander provides an additional 8 programmable zones (see page 14).

15: Speech Module

A four channel *Speech Module* can be plugged on to the main PCB (SK1). This connector is only fitted on the *Premier 816Plus* and *Premier 832* control panels.

16: Box Tamper Switch

Box tamper protection for the main control panel.

17: Power Light

On steady when either AC or standby battery is present. Flashes when the on-board communicator is dialling or sending data.

18: Electronic Fuses

The PCB is protected using electronic PTC fuses:

- F1 (2.5 Amp) Battery fuse
- F2 (900mA) Auxiliary 12V power fuse
- F3 (900mA) Siren/Bell output fuse
- F4 (900mA) Network fuse

To reset a fuse, remove all load from the protected circuit, wait 10 seconds, then reconnect.

19: Telephone Line Connections

Telephone line connections (see page 19).

20: RJ11 Telephone Line Connector

An RJ11 connector is provided so that the panel can be connected to the telephone line via a standard RJ11 patch lead.

21: Engineers Keypad Connection

An engineer's keypad (*Premier LCD* keypad and interface lead) can be temporarily plugged onto this connector to allow system programming and testing.

22: Network Data Indicator LEDs

The red transmit (Tx) LED indicates that data is flowing out of the control panel and normally flashes very quickly. The green receive (Rx) LED indicates that data is flowing into the control panel. The green LED flashes faster as more devices are connected to the data network.

23: Electronic Fuse Fault Indicator LEDs

Electronic fuses F2-F4 have red indicator LEDs, which light up when the relevant fuse is open circuit (fault).

24: Battery Kick Start Pins

The control panel has a deep discharge protection circuit that prevents the standby battery from being fully discharged. When powering up the control panel without AC Mains (battery only), the centre and either outer pins must be shorted together in order to bring the battery into circuit.

25: Battery Charge Current Selector

When using a 7Ah standby battery the charge current selector should be set to 300mA. If a 17Ah battery is connected (metal cabinet only) the selector should be set to the 750mA position.

Power Supply Ratings

All Models (Large & Small Polymer)

Current

| | |
|---------------------------|------|
| Current Consumption | 50mA |
| Maximum Current Available | |
| 0.3A charge | 1.1A |

Rated Output

| Battery Arrangement | Battery Charge | Rated Output (Amps) |
|---------------------|----------------|---------------------|
| | | 12h |
| 1 x 7Ah | 0.3A | 0.533A |

Standby and Recharge Times

| EN50131-1 | Grade 1 | Grade 2 |
|------------------------|---------|---------|
| Minimum Standby Period | 12h | 12h |
| Maximum Recharge Time | 72 Hrs | 72 Hrs |

All Models (Metal)

Current

| | |
|---------------------------|------|
| Current Consumption | 50mA |
| Maximum Current Available | |
| 0.3A charge | 1.9A |
| 0.75A charge | 1.0A |

Rated Output

| Battery Arrangement | Battery Charge | Rated Output (Amps) | | | |
|---------------------|----------------|---------------------|--------|--------|--------|
| | | 12h | 24h | 30h | 60h |
| 1 x 7Ah | 0.3A | 0.533A | 0.241A | 0.183A | X |
| 1 x 17Ah | 0.3A | 1.36A | 0.658A | 0.516A | 0.233A |
| | 0.75A | 1.0A | 0.658A | 0.516A | 0.233A |

Standby and Recharge Times

| EN50131-1 | Grade 1 | Grade 2 |
|------------------------|---------|---------|
| Minimum Standby Period | 12h | 12h |
| Maximum Recharge Time | 72 Hrs | 72 Hrs |



NOTE 30h if MAINS FAIL reported to ARC, otherwise 60h

Jumper Settings

| Battery Arrangement | Recharge Time | Battery Charge Selector |
|---------------------|---------------|-------------------------|
| 1 x 7Ah | < 24Hrs | 0.3 A |
| 1 x 17Ah | < 24Hrs | 0.75 A |
| | < 72Hrs | 0.3 A |


Connecting AC Mains

The AC Mains supply is connected to a 3 way 'Euro Type' fused terminal block, which is fitted with a 3.15A medium/slow blow fuse.



NOTE All other wiring **MUST** be carried out before AC mains is connected to the control panel.

After connecting the AC Mains, fit the mains cover, this can be found in the spares bag.




Connecting Batteries

Up to one 12V 7Ah battery can be fitted inside the control panel to provide continued operation in the event of an AC mains failure.




NOTE All other wiring **MUST** be carried out before the battery is connected to the control panel.

Connect the red battery lead to the positive terminal of the battery and connect the black battery lead to the negative terminal of the battery.




EN50131 Battery Installation

Step 1: Screw 2 x battery clamps into holes provided in the rear of the panel.



Step 2: Fit battery into place, position the clamps against the top face of the battery and tighten screws.



Connecting Devices to the Data Bus

Before connecting remote keypads and zone expanders, isolate ALL power from the control panel (AC Mains & Battery). Do not continue if there is still power present on the control panel.



NOTE Connecting devices with power still present on the control panel may damage the device or control panel and invalidate any warranty.

Remote keypads and zone expanders are all connected to the same data terminals located at the bottom left hand corner of the control panel and may be connected serially (daisy chain), in parallel (star) or any combination of the two.

Wiring the Data Bus

The data bus is made up of four terminals incorporating power and data. To ensure correct operation, all four terminals on the device must be connected to the corresponding terminals on the control panel, or previous device (see page 10 for wiring details). The table below shows each terminal and its description:

| Terminal | Description |
|----------|---------------|
| + | +12V Supply |
| - | 0V Supply |
| T | Transmit Data |
| R | Receive Data |

Cable Type and Distances

For improved immunity to electrical noise Texecom recommend the use of screened 4 core cable. The screen should be twisted together and wired into the (-) terminal at the control panel only.

The maximum recommended distance for devices when using standard 7/0.2 alarm cable is:

- 250m for each branch when using the star (parallel) configuration
- When using a daisy chain (series) configuration the maximum distance will depend on the number of devices connected on the chain. The more devices that are connected, the shorter the distance to the last device (this is due to voltage drop in the cable)



Whichever method of wiring configuration is used, ensure that the voltage between the '+' and '-' terminals at each device is no lower than 10.0V when the system is running on the standby battery.

Installing a Power Supply

When a power supply is installed, the 0V connections on the power supply must be connected through to 0V on the control panel and the +12V connection between the control panel and the device must be disconnected (see figure below).

The table below shows maximum cable runs when one keypad or expander is installed using standard 7/0.2 alarm cable with various loads:

| Configuration | Max. Cable Run |
|-----------------------------|----------------|
| 1. Keypad + 2 PIR's @15mA | 250m |
| 2. Expander + 2 PIR's @15mA | 250m |
| 3. Expander + 8 PIR's @15mA | 100m |
| 4. As No. 3 + 16Ω Speaker | 30m |



Overcoming Voltage Drop

There are several ways to overcome voltage drop:


- Use thicker lower resistance cable. Standard 7/0.2 alarm cable has a resistance of 8Ω per 100m

- Double up on the power connections – this will require using a 6 or 8-core cable rather than a 4-core cable
- Install a power supply to power the device locally, remember to common the two negative connections

Use of pull up resistors


Devices lost from the network, or high levels of network errors can sometimes be cured using pull-up resistors.

Poor quality cable and/or installation practices are the most common cause of continued faults with network devices. The diagram details the type and placement of the resistors.




Installing Remote Keypads


Keypad Layouts



RKP4/8/16 Layout



RKP8/16 Plus Layout



LCD/LCDL/LCDP/LCDLP
SMK & FMK Layout

- ① Address DIL Switch
- ② Tamper Switch
- ③ Piezo Sounder
- ④ Data Bus Connections
- ⑤ Programmable Zones 1 and 2
- ⑥ Speaker Output (*Premier LCDL/LCDLP Only*)
- ⑦ Programmable Output

Remote Keypad Connections

The remote keypad is connected to the data bus terminals located at the bottom left hand side of the PCB. (See pages 8 to 10).

Remote Keypad Address

Each remote keypad must be assigned a different address using the Address DIL switch (①). The table below shows how to set the address:

| Address | DIL 1 | DIL 2 | DIL 3 | DIL 4 | |
|---------|--------|-------|-------|-------|--|
| 1 | On/Off | Off | Off | Off | |
| 2 | Off | On | Off | Off | |
| 3 | Off | Off | On | Off | |
| 4 | Off | Off | Off | On | |
| 5 | On | Off | Off | On | |
| 6 | Off | On | Off | On | |

Keypad Zones

The *Premier RKP8/16 Plus* and all LCD remote keypads have two programmable zone inputs (see page 15 for wiring details). Each zone is also fully programmable (see page 25 for programming details). The table below shows the zone allocation when using the *Premier RKP8/16 Plus* or *Premier LCD* remote keypads:

| Address | Premier 412 | | Premier 816/832 | |
|---------|-------------|---------|-----------------|---------|
| | Zone 1 | Zone 2 | Zone 1 | Zone 2 |
| 1 | Zone 05 | Zone 06 | Zone 09 | Zone 10 |
| 2 | Zone 07 | Zone 08 | Zone 11 | Zone 12 |
| 3 | Zone 09 | Zone 10 | Zone 13 | Zone 14 |
| 4 | Zone 11 | Zone 12 | Zone 15 | Zone 16 |
| 5 | N/A | N/A | N/A | N/A |
| 6 | N/A | N/A | N/A | N/A |

NOTE The onboard remote keypad zones are not seen by the system until they have been enabled. To enable the onboard keypad zones (see page 43 for details).

Keypad Output


All *Premier LCD* remote keypads have one programmable output, which can be used to drive auxiliary devices such as LED's, sounders or relays etc. Wire as per Panel Outputs shown on page 19 (see page 47 for programming details).

Keypad Speaker Output (LCDL/LCDLP FMK/SMK)

The Premier LCDL and LCDLP keypads has an output that can be used for driving up to one 8Ω or two 16Ω loudspeakers (see page 18 for wiring details).

NOTE The speaker volume is also fully adjustable (see page 36 for details).

Adjustable Backlighting

To adjust the keypad backlighting press the **YES** key, then with the **YES** key still pressed use  to increase or decrease the backlighting until the required brightness is achieved, then release both keys.

NOTE The backlight can only be adjusted when the keypad is not in a menu.


Keypad Lid Tamper

The lid tamper of each keypad can be disabled if required using the relevant keypad option in the Keypad Options 4 menu (see page 43 for details).

Remote Zone Expander Module

The Premier 8X Remote Zone Expander provides 8 additional detection zones, two programmable outputs and a speaker driver output.

Remote Expander Layout






- ① Data Bus Connections
- ② Programmable Zone Inputs
- ③ Auxiliary 12V
- ④ Programmable Outputs 1 and 2
- ⑤ Speaker Driver Output
- ⑥ Power LED
- ⑦ Disable Tamper Jumper
- ⑧ Tamper Switch
- ⑨ Address DIL Switch

Wiring the Zone Expander

The Remote Zone Expansion Module is connected to the data bus terminals located at the bottom left hand side of the PCB. (See pages 8 to 10).

Remote Expander Address

Each remote expander must be assigned a different address using the Address DIL switch (⑨). The table below shows how to set the address:

| Address | DIL 1 | DIL 2 | DIL 3 | DIL 4 | |
|---------|--------|-------|-------|-------|---|
| 1 | On/Off | Off | Off | Off |  |
| 2 | Off | On | Off | Off |  |
| 3 | Off | Off | On | Off |  |

NOTE Only one remote expander can be connected to the Premier 412 & 816 control panels (Address = 1).

Remote Expander Zones

The Premier 8X Remote Expander has eight programmable zone inputs (see page 15 for wiring details). Each zone is also fully programmable (see page 25 for programming details).

The table below shows the system zone allocation when one or more modules are installed:

| Address | Remote Expander Zone Inputs | | | | | | | |
|---------|-----------------------------|----|----|----|----|----|----|----|
| | Z1 | Z2 | Z3 | Z4 | Z5 | Z6 | Z7 | Z8 |
| 1 | 09 | 10 | 11 | 12 | 13 | 14 | 15 | 16 |
| 2 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 |
| 3 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 |

NOTE When the system is expanded above 8 zones, it MUST be fitted with a suitable remote keypad. For systems up to 16 zones a Premier RKP16 or Premier RKP16 Plus should be installed. For systems above 16 zones a LCD remote keypad should be installed.

The system will only support one type of expansion device for zones 09 - 16, i.e., you can fit either a Premier 8X Remote Expander (Address = 1) or a Premier 8XE Local Expander, you cannot fit both.

Zone Expander Outputs

The Zone Expander module has two programmable outputs, which can be used to drive auxiliary devices such as relays, LED's, smoke detectors etc. The table below shows the electrical characteristics for each output:

| No | Supervised | Max Current | Type |
|----|------------|-------------|--------------|
| 1 | No | 100mA | Switched -ve |
| 2 | No | 100mA | Switched -ve |

Wire as per Panel Outputs shown on page 19.


Zone Expander Speaker Driver

The Zone Expander has a Speaker driver output and can be used for driving 8 or 16 Ohm loud speakers as shown on page 18.

Local Zone Expander Module

The *Premier 8XE Local Zone Expander* plugs onto the control panel to provide 8 additional programmable detection zones.

Local Expander Layout



① Zone Inputs 9 to 16

These terminals provide the connections to the zone inputs.

② Auxiliary 12V Power

These terminals provide auxiliary power for devices that require 12V power. The auxiliary output is protected by fuse F2 (1 Amp) on the control panel.

③ Plug-On Connector

The *Premier 8XE Local Zone Expander* plugs onto the control panel via this connector and is held in place by four plastic pillars located in each corner.

Local Expander Zones

The *Premier 8XE Local Zone Expander* has eight programmable zone inputs (see page 15 for wiring details). Each zone is also fully programmable (see page 25 for programming details).

The table below shows the zone allocation when the module is installed:

| Panel | Panel Zones | Expander Zones |
|--------------------|-------------|----------------|
| <i>Premier 412</i> | 1 to 4 | 9 to 16 |
| <i>Premier 816</i> | 1 to 8 | 9 to 16 |
| <i>Premier 832</i> | 1 to 8 | 9 to 16 |



When the system is expanded above 8 zones, it MUST be fitted with a suitable remote keypad. For systems up to 16 zones a *Premier RKP16* or *Premier RKP16 Plus* should be installed. For systems above 16 zones a *Premier LCD/LCDL* should be installed.

The system will only support one type of expansion device for zones 09 - 16, i.e., you can fit either a *Premier 8X Remote Expander* (Address = 1) or a *Premier 8XE Local Expander*, you cannot fit both.


Installing the Local Zone Expander

► To install the Local Zone Expander proceed as follows:

Ensure that all power is removed from the control panel (mains and battery) before attempting to fit the expander.

Push the four support pillars (supplied) into the four locating holes on the control panel PCB.

Align the Local Expander Connector with the 8 way plug (JP2) on the control panel. Push expander into place, ensuring that all four pillars clip into the four locating holes on the local expander.



Zone Connections


Each zone on the system is fully programmable to allow for maximum flexibility (see page 25 for Zone Programming details). The program options for a zone will also determine how the zone may be wired. The following wiring options are available:

| Type | Zone Status | Response |
|-------------------------------------|-------------|----------------------|
| ⑩ Normally Closed | < 10K | Secure |
| | > 10K | Active |
| ① Normally Open | < 10K | Active |
| | > 10K | Secure |
| ② Single EOL - N/C & N/O (Burglary) | < 1K | Active |
| | 1K - 4.7K | Secure |
| | > 4.7K | Active |
| ③ Single EOL - N/O (Fire) | < 1K | Active |
| | 1K - 4.7K | Secure |
| | > 4.7K | Trouble |
| ④ Single EOL - N/C | < 2K | Trouble |
| | 1K - 4.7K | Secure |
| | > 4.7K | Active |
| ⑤ Single EOL - O/C Tamper | < 1K | Secure |
| | 1K - 4.7K | Active |
| | > 4.7K | Tamper |
| ⑥ Single EOL - S/C Tamper | < 1K | Tamper |
| | 1K - 4.7K | Secure |
| | > 4.7K | Active |
| ⑦ Double EOL | < 1K* | Tamper |
| | 1K - 4K* | Secure |
| | 4K - 20K | Active |
| | > 20K | Tamper |
| ⑧ Zone Doubled | < 1K | Zones A & B Trouble |
| | 1K - 2K | Zones A & B Secure |
| | 2K - 4K | Zone A Violated |
| | 4K - 6K | Zone B Violated |
| | > 6K | Zones A & B Violated |
| ⑨ Triple EOL | < 1K* | Tamper |
| | 1K - 4K* | Secure |
| | 4K - 6K | Trouble (Fault) |
| | 6K - 8K | Active |
| | 8K - 20K | Trouble (Masked) |
| | > 20K | Tamper |

* This value may vary depending on the country code variant.


Normally Closed

Use this wiring configuration when connecting normally closed detection devices to the zone. Ensure that the zone is programmed for Normally Closed operation (see page 27). The zone must be wired as follows:




Normally Open

Use this wiring configuration when connecting normally open detection devices to the zone. Ensure that the zone is programmed for Normally Open operation (see page 27). The zone must be wired as follows:




Single EOL - N/C & N/O (Burglary)

Use this wiring configuration when connecting a mixture of normally closed and normally open detection devices to the zone. Ensure that the zone is programmed for Single EOL - N/C & N/O operation (see page 27). The zone must be wired as follows:




Single EOL - N/O (Fire)

Use this wiring configuration when connecting a 4-wire smoke detector to the zone. Ensure that the zone is programmed for Single EOL - N/O (Fire) operation (see page 27). The zone must be wired as follows:




Single EOL - N/C

Use this wiring configuration when connecting just normally closed detection devices to the zone. Ensure that the zone is programmed for Single EOL - N/C operation (see page 27). The zone must be wired as follows:



Single EOL - O/C Tamper

Use this wiring configuration when connecting just normally closed detection devices to a zone and when a tamper response is required in the event of an open circuit. Ensure that the zone is programmed for Single EOL - O/C Tamper operation (see page 27). The zone must be wired as follows:




Single EOL - S/C Tamper

Use this wiring configuration when connecting just normally closed detection devices to the zone and when a tamper response is required in the event of a short circuit. Ensure that the zone is programmed for Single EOL - S/C Tamper operation (see page 27). Wire Single EOL - S/C Tamper zones as shown for Single EOL - N/C.

Double EOL

Use this wiring configuration when connecting detection devices to a zone that requires alarm/tamper monitoring. Ensure that the zone is programmed for Double EOL operation (see page 27). The zone must be wired as follows:




Zone Doubling

This wiring option allows you to wire two detection devices into one set of zone connections. However, the system will treat each device, as if it were connected to a separate zone, i.e., each device is fully programmable.

NOTE When using this configuration, the system must be fitted with the appropriate keypad, *Premier RKP16* on the *Premier 816* and the *Premier RKP8* on the *Premier 412*.

When a zone is configured for “Zone Doubled” it must be wired as follows:



The following table shows how each physical zone is mapped when using the “Zone Doubled” configuration:


| Premier 412 | | |
|-----------------|--------|--------|
| Panel Zone | Zone A | Zone B |
| 1 | 1 | 5 |
| 2 | 2 | 6 |
| 3 | 3 | 7 |
| 4 | 4 | 8 |
| Premier 816/832 | | |
| Panel Zone | Zone A | Zone B |
| 1 | 1 | 9 |
| 2 | 2 | 10 |
| 3 | 3 | 11 |
| 4 | 4 | 12 |
| 5 | 5 | 13 |
| 6 | 6 | 14 |
| 7 | 7 | 15 |
| 8 | 8 | 16 |


NOTE Zones above 9 on either the *Premier 8X/8XE Expander* MUST not be configured for “Zone Doubled”.

The *Premier 8X/8XE Expander* cannot be used on the *Premier 816/832* control panels if any of zones 1 - 8 are configured as “Zone Doubled”.

Triple EOL

This wiring option is designed to be used with Texecom detectors that support Triple EOL (T-EOL) wiring. Ensure that the zone is programmed for Triple EOL operation (see page 27). The zone must be wired as follows:






NOTE Triple EOL wiring can only be used on remote keypads and remote expanders that are fitted with V7.1 software or above..


Double Pole

This wiring configuration can only be used on the *Premier LCD/LCDL* remote keypads. It provides monitoring for alarm and tamper using normally closed detection devices. Ensure that the zone is programmed for Double EOL operation (see page 27). The zone must be wired as follows:



2-Wire Smoke Detector

Compatible 2-wire smoke detectors such as the ESL429AT or System Sensor 2100TS can be connected as shown:



NOTE Panel Output 1 must be enabled for 2-wire smoke detection (see page 36 for details).

The jumper link fitted across JP1 (Enabled 2-Wire Smoke Det.) MUST be removed.


The maximum number of detectors is 20.

Speaker/Bell Connections

The Siren/Spk output terminals on the main PCB can be configured for Speaker or Siren/Bell operation.

Speaker Operation

When configured as speaker operation the output can be used for driving 8 or 16 Ohm loud speakers as shown:




NOTE The Siren/Spk output must be enabled for speaker driver (see page 36 for details).

Siren/Bell Operation

When configured as bell operation the output terminals provide up to **750mA** of power for driving bells as shown:

NOTE For EN50131 & INCERT Installations the bell Aux/Tamper must be wired to a zone.



NOTE The Siren/Spk output must be enabled for bell driver (see page 37 for details).


Siren/Spk Supervision

The Siren/Spk output is supervised, if no warning devices are fitted, either disable Siren Supervision (see page 38 for details) or connect a 1K Ω resistor between the Siren terminals as shown:



Telephone Line Connections

The control panel has a built in digital communicator and modem, which is used for communicating with an alarm receiving centre and for downloading. If either of these features are used, a telephone line must be connected to the control panel as shown:



Failure to fit an earth cable may prevent proper operation of the system and will invalidate the Texecom warranty and product approvals.




Panel Outputs 1 - 8

The control panel has eight programmable outputs, which can be used to drive auxiliary devices such as relays, LED's, smoke detectors etc. The table shows the electrical characteristics for each output:

| Panel Outputs | | | |
|---------------|------------|-------------|--------------|
| No | Supervised | Max Current | Type |
| 1 | Yes | 1 Amp | Switched -ve |
| 2 | Yes | 1 Amp | Switched -ve |
| 3 | No | 100mA | Switched -ve |
| 4 | No | 100mA | Switched -ve |
| 5 | No | 100mA | Switched -ve |
| 6 | No | 100mA | Switched -ve |
| 7 | No | 100mA | Switched -ve |
| 8 | No | 100mA | Switched -ve |


Output Wiring

The figure below shows some typical wiring examples:



Output Supervision

Panel outputs 1 and 2 are supervised, if either output is unused, either disable the relevant output supervision (see page 38 for details) or connect a 1K Ω resistor between the relevant output terminal and Auxiliary 12V+ as shown:





3. Commissioning & Troubleshooting

Commissioning

Once ALL connections have been made to the control panel and power is ready to be applied, you should read this section before continuing.

The control panel leaves the factory with default settings. For a complete list of factory default settings, please refer to the programming worksheets from page 86.

- Connect the black battery lead to the negative (–) terminal of the standby battery and the red battery lead to the positive (+) terminal of the standby battery. The green power light on the main PCB will flash whilst the default values are being loaded.
- If the system has gone into an alarm condition, enter the default Master User code **5 6 7 8**. The alarm tone will then stop.
- To access the Engineer Programming Menu, **enter the default Engineer code 1 2 3 4 and press**  **followed by 9**. All the zone lights will illuminate.
- Panels with V16 or later firmware installed will use the start-up procedure found on page 23
- Confirm Devices see page 22
- Program the system date and time, see page 69.
- Select the Language, see page 36.
- Select the Country Code, see page 36.
- Program the system as described in the next section (Programming the Control Panel).
- Perform a walk test as described on page 69. Remember that some powered detectors (e.g. PIRs and combined technology detectors) take several minutes to warm up and become operational.
- Test the internal sounder, external sounder and strobe as described on page 69.
- Replace the lid and secure with the two lid screws supplied - **do not over-tighten**.
- Replace the screw covers.
- **Press**  **to leave the programming menus. All the zone lights will turn off.**
- The **Service** light will be flashing to indicate that action is required. Switch on the mains supply to the control panel. The **Service** light will stop flashing and stay on continuously.

Installation is now complete and the system is ready for use.

Troubleshooting

Power Faults

No Power to Unit (mains only)

- Check the mains block fuse and replace if blown.
- Check for any loose wires at the mains block, the transformer and the AC terminals on the PCB.

- Check the mains block is connected correctly; live to live (brown), neutral to neutral (blue).

No Power to Unit (battery only)



- Make sure the “Kick Start” pins have been shorted together.
- Check for any loose wires at the BATT terminals on the PCB.
- Check that the battery wires are connected correctly; red from BATT+ to the battery positive [+], black from BATT- to the battery negative [–].

Remote Keypads

Keypad Does Not Operate at All

- Check that the remote keypad is wired correctly from the control panel.
- Check that the network fault indicator is off. If the indicator is on, the electronic fuse has activated indicating a short circuit across the [+] and [–] of the network terminals.

Keypad Does Not Accept Access Codes

- If the system has more than one remote keypad check that each keypad is addressed differently, see page 12 for details. The address of a keypad can be checked by pressing the  and  keys together, the address is displayed by the relevant zone light.
- Check that the remote keypad is wired correctly.
- If the remote keypad is on a cable run that is longer than 100m, check the voltage between the [+] and [–] terminals at the remote and ensure that it measures no less than 10.0V.
- Check that you are using the correct Access code. The default Engineer code is **1 2 3 4** and the default Master User code is **5 6 7 8**.
- Check that the User code you are using is not “Time Locked”, if the User code is time locked then the Access code will only be accepted when Control Timer 1 is off, see page 66 for further details.

Keypad Does Not Generate Alarm Tones etc.

- Each keypad can be configured so that the alarm, entry, exit, chime tones etc. can be enabled or disabled. Check that the keypad has been programmed correctly, see page 42 for details.

Keypad Emergency Keys Do Not Operate

- Each keypad can be configured so that the emergency keys **FIRE**, **POLICE** and **MEDICAL** can be enabled or disabled. Check that the keypad has been programmed correctly, see page 42 for details.

Remote Expander

Expander Does Not Operate at All

- Check that the expander is wired correctly from the control panel.
- Check that the network fault indicator is off. If the indicator is on, the electronic fuse has activated indicating a short circuit across the [+] and [–] of the network terminals.

System Does Not Recognise Zones 9 to 16

- If the expander is on a cable run that is longer than 100m, check the voltage between the [+] and [–] terminals at the remote and ensure that it measures no less than 10.0V.

The Speaker Output Does Not Work

- The expander can be configured so that the alarm, entry, exit, chime tones etc. can be enabled or disabled. Check that the expander has been programmed correctly, see page 44 for details.
- The speaker volume on the expander is electronically adjustable. Check the volume is set to the desired level, see page 44 for details.

Zones**One or More Zones Show an Alarm**

- Each zone on the system can be configured for different wiring options. Check that the zones are programmed for the correct wiring configuration, see page 27 for further details.
- Check that the zone is wired correctly, see page 15 for further details.

Service Faults

If the Service light is on or flashing then the system has detected one or more fault conditions, for details on how to view and acknowledge Service Faults see page 75.

On Power-Up the Service Light is On

- When the system is powered-up the system date and time are incorrect. This will cause a Date/Time Loss fault, to clear this fault, program the system date and time, see page 69.
- If the battery presence check is enabled the system will check the battery every 30 seconds. If the system does not have a battery connected then a battery fault will be generated. To clear this fault either connect a battery or disable the battery presence check, see page 36.
- Panel outputs 1 and 2 are supervised outputs, if you have not connected a device to either of these outputs the system will generate an output fault. To clear this fault either fit 1K load resistors between the outputs and +12V, see page 19 or disable the monitoring of outputs 1 and 2, see page 38.
- The Siren output is a supervised output, if you have not connected a device to this output the system will generate a siren fault. To clear this fault either fit 1K load resistors between the siren terminals, see page 19 or disable the monitoring of the siren output, see page 38.

Communicator**The Communicator Will Not Dial**

- By default the communicator is disabled, check that the communicator is enabled, see page 52.
- Check that the telephone line has been correctly wired to the control panel.

- Check that the primary telephone number is programmed correctly, see page 52.
- Check that the primary account number is programmed correctly, see page 53.
- Check that the primary protocol is programmed correctly, see page 53.
- Check that the primary dial attempts is not programmed as zero, see page 53.
- Check that the primary reporting partitions have been programmed correctly, see page 53.
- Check that the primary reporting options have been programmed correctly, see page 54.

Communicator Dials But Does Not Communicate

- Check that the primary telephone number is programmed correctly, see page 52.
- Check that the primary account number is programmed correctly, see page 53.
- Check that the primary protocol is programmed correctly, see page 53.
- If you are using either Pulse or Express formats check that the protocol is configured correctly, see page 54.

Operation**The System Will Not Allow Arming**

- Check that there are no outstanding Service Faults, see page 75.
- Check that there are no outstanding alarms that require resetting, see page 75.
- Check that the User code has been programmed to allow arming, see page 66.
- Check that the User code has been assigned to the correct partition(s), see page 66.
- If the User code is programmed for "Local Partition Access Only" (see page 67) then ensure that the keypad that is being used is assigned to the correct partition, see page 42.


The System Will Not Allow Disarming


- Check that the User code has been programmed to allow disarming, see page 66.
- Check that the User code has been assigned to the correct partition(s), see page 66.
- If the User code is programmed for "Local Partition Access Only" (see page 67) then ensure that the keypad that is being used is assigned to the correct partition, see page 42.

4. Programming the Control Panel


Introduction


All engineers should read this section carefully so as to familiarise themselves with the programming of the control panel.


The programming menus can only be accessed when the control panel is fully disarmed. **Enter the default Engineer code 1 2 3 4 and press  followed by 9** to access the program menus:



A programming menu is selected by entering a two-digit menu code. On completion of each menu option, the system reverts to the main programming menu, allowing other programming menu options to be accessed.


To exit the programming menu **enter 9 9 or press the ** key, the system will revert to normal operation:



 **NOTE** If the “EN 50131-1 Requirements” option is programmed as enabled (see page 37) the Engineer code will only be accepted after a user has authorised Engineer access. For


information on complying with EN 50131-1 please refer to page 79.

Viewing Numeric Data (LED Keypads)

When programming numeric data, the value of the data may be viewed by pressing the  key. The keypad will flash the value in sequence using the following lights:

| | |
|------------|------------|
| Alarm = 0 | Zone 5 = 5 |
| Zone 1 = 1 | Zone 6 = 6 |
| Zone 2 = 2 | Zone 7 = 7 |
| Zone 3 = 3 | Zone 8 = 8 |
| Zone 4 = 4 | Armed = 9 |

Programming Text (LCD Only)

Text is programmed in a similar way to mobile phones. Characters are selected by pressing the corresponding key the appropriate number of times (to select a character on the same key, press  to move the cursor along).

The table below shows the keys to use and the characters that are assigned to them:


| Key | Characters | | | | | | | | | |
|-----|----------------------------|---|---|---|---|-------------------|---|---|---|--|
| ① | . | , | ? | ! | 1 | @ | " | - | & | |
| ② | a | b | c | 2 | A | B | C | | | |
| ③ | d | e | f | 3 | D | E | F | | | |
| ④ | g | h | i | 4 | G | H | I | | | |
| ⑤ | j | k | l | 5 | J | K | L | | | |
| ⑥ | m | n | o | 6 | M | N | O | | | |
| ⑦ | p | q | r | s | 7 | P | Q | R | S | |
| ⑧ | t | u | v | 8 | T | U | V | | | |
| ⑨ | w | x | y | z | 9 | W | X | Y | Z | |
| ⑩ | _ | 0 | , | # | * | Custom characters | | | | |
| ↔ | Move cursor left and right | | | | | | | | | |
| ⌫ | Backspace (delete) | | | | | | | | | |
| ✓ | Accept text | | | | | | | | | |

V16 Start up Procedure

V16 sees a new start-up procedure allowing selection of the control panel language, loading specific country defaults and confirming devices connected to the panel network at start-up.

Premier RKP8 & 16 LED Keypads

For LED keypads there is no change to the current operation. Bypassing the requirement to set the language and country code at initial power up is as follows.




































- Power up the panel
- Enter the default engineers code ①②③④
- Press  then 9

You are now in the programming menu and can continue as you did with previous versions of the panel.

Premier LCD Keypads

As with LED keypad operation, the requirement to set the language and country code can be bypassed. The procedure is identical to that shown for LED keypads.

On powering up the panel the following sequence will be presented. You can exit this procedure at anytime by using the keys detailed in the Options column.

| Action | Display | Options |
|--|-------------------------------------|---|
| Enter the default engineers code ①②③④ | Set Language? YES to Select | Press  takes you to the Arming Menu Press  takes you to the Confirm Devices Menu Press  takes you to the Confirm Devices Menu |
| Press  and use the  key to select the desired language | Language English | Press  takes you to the Confirm Devices Menu Press  takes you to the Confirm Devices Menu Press  takes you to the Confirm Devices Menu |
| Press  to confirm Language | Set Country? YES to Select | Press  takes you to the Arming Menu Press  takes you to the Confirm Devices Menu Press  takes you to the Confirm Devices Menu |
| Press  and use the numeric keys to enter the desired country code. | Country Code Enter Value: 027 | Press  takes you to the Confirm Devices Menu Press  takes you to the Confirm Devices Menu |
| The panel will now load the defaults for the country code selected. | Confirm Devices YES to Select | Press  takes you to the Arming Menu Press  takes you to the Programming Menu Press  takes you to the Programming Menu |
| Press  and check that all devices installed are shown. | Net RKP>1..... Net Exp>... | Press  takes you to day mode. You will be prompted to confirm devices when you log in again. |
| Press  . | Confirm Devices YES to Confirm | Press  takes you to day mode. You will be prompted to confirm devices when you log in again. |
| Press  . | Program Time YES to Select | Press  takes you to the Arming Menu Press  takes you to the Arming Menu |
| Press  and use the numeric keys to enter the correct time. | Program Time > 00:17 | Press  takes you to the Programming Menu Press  takes you to the Programming Menu |
| You will be prompted to programme the correct date | Program Date YES to Select | Press  takes you to the Arming Menu Press  takes you to the Arming Menu |
| Press  and use the numeric keys to enter the correct date. | Program Date > 18/05/15 | Press  takes you to the Programming Menu Press  takes you to the Programming Menu |
| You are now at the Programming Menu | Programmin9 Menu Enter Code > ?? | Press  takes you to day mode Press  takes you to day mode |




NOTE If confirm devices is not carried out you will be prompted every time you login as an engineer to carry out this function. If the date & time are not set then the engineer or user will be prompted when they login, and each time until the date and time are set.


Program Menus

| Menu | Function | Page |
|-------------------------------------|------------------------------|------|
| Programming Zones | | |
| ① ① ① | All Zone Options | 26 |
| ① ① ① | Zone Type | 26 |
| ① ① ② | Zone Wiring | 27 |
| ① ① ③ | Zone Attributes 1 | 27 |
| ① ① ④ | Zone Attributes 2 | 28 |
| ① ① ⑤ | Zone Attributes 3 | 28 |
| ① ① ⑥ | Zone Partitions & Groups | 29 |
| ① ① ⑦ | Zone Text | 29 |
| ① ① ⑧ | Assign Radio Device | 29 |
| Programming Partitions | | |
| ② ② ① | Partition Exit Time | 31 |
| ② ② ① | Partition Entry Delay 1 Time | 31 |
| ② ② ② | Partition Entry Delay 2 Time | 31 |
| ② ② ③ | Partition Communicator Delay | 31 |
| ② ② ④ | Partition Bell Delay | 31 |
| ② ② ⑤ | Part Bell Duration | 31 |
| ② ② ⑥ | Partition Options | 31 |
| ② ② ⑦ | Partition Auto Arm/Disarm | 32 |
| ② ② ⑧ | Equipment Areas | 32 |
| Programming Global Options | | |
| ③ ③ ① | System Timers | 35 |
| ③ ③ ① | System Counters/Levels | 36 |
| ③ ③ ② | System Control Timers | 36 |
| ③ ③ ③ | System Options 1 | 36 |
| ③ ③ ④ | System Options 2 | 37 |
| ③ ③ ⑤ | System Options 3 | 37 |
| ③ ③ ⑥ | Hardware Options | 38 |
| ③ ③ ⑦ | Auxiliary Input Options | 38 |
| ③ ③ ⑧-① | Miscellaneous Options 1 | 38 |
| ③ ③ ⑧-② | Miscellaneous Options 2 | 38 |
| ③ ③ ⑧-③ | Miscellaneous Options 3 | 38 |
| ③ ③ ⑨ | EN50131 Options | 39 |
| Programming Remote Keypads | | |
| ④ ④ ① | Keypad Options 1 | 42 |
| ④ ④ ① | Keypad Options 2 | 42 |
| ④ ④ ② | Keypad Options 3 | 42 |
| ④ ④ ③ | Keypad Options 4 | 43 |
| Programming Remote Expanders | | |
| ⑤ ⑤ ① | Expander Partitions | 44 |
| ⑤ ⑤ ① | Expander Tones | 44 |
| ⑤ ⑤ ② | Expander Volume Level | 44 |

| Menu | Function | Page |
|-------------------------------------|---------------------------------|------|
| Programming System Outputs | | |
| ⑥ ⑥ ① | Panel Outputs | 47 |
| ⑥ ⑥ ① | Fast Format Channels | 47 |
| ⑥ ⑥ ② | Expander 1 Outputs | 47 |
| ⑥ ⑥ ③ | Expander 2 Outputs | 47 |
| ⑥ ⑥ ④ | Expander 3 Outputs | 47 |
| ⑥ ⑥ ⑤ | Keypad Outputs | 47 |
| Programming The Communicator | | |
| ⑦ ⑦ ① | Communicator Options | 52 |
| ⑦ ⑦ ① | ARC 1 Communicator Options | 52 |
| ⑦ ⑦ ② | ARC 2 Communicator Options | 55 |
| ⑦ ⑦ ③ | Fast Format Restore Channels | 55 |
| ⑦ ⑦ ④ | Fast Format Open/Close Channels | 56 |
| ⑦ ⑦ ⑤ | Cancel Call Waiting | 56 |
| Programming Download Option | | |
| ⑦ ⑦ ⑥ | Download Menu | 60 |
| Programming Reporting Codes | | |
| ⑦ ⑦ ⑦ | Zone Alarm/Restore Codes | 63 |
| ⑦ ⑦ ⑧ | Zone Bypass/Unbypass Codes | 63 |
| ⑦ ⑦ ⑨ | Non Zone Alarm/Restore Codes | 63 |
| Programming Users | | |
| ⑧ ⑧ ① | Program User | 66 |
| ⑧ ⑧ ① | User Options 1 | 66 |
| ⑧ ⑧ ② | User Options 2 | 66 |
| ⑧ ⑧ ③ | User Options 3 | 67 |
| ⑧ ⑧ ④ | User Text | 67 |
| ⑧ ⑧ ⑤ | Program Standard Users | 67 |
| ⑧ ⑧ ⑥ | Default All Users | 67 |
| System Tests and Utilities | | |
| ⑨ ⑨ ① | Walk Test | 69 |
| ⑨ ⑨ ① | Test Speakers and Outputs | 69 |
| ⑨ ⑨ ② | Send Test Call | 69 |
| ⑨ ⑨ ③ | Enable Download Access | 69 |
| ⑨ ⑨ ④ | Start Call Back | 69 |
| ⑨ ⑨ ⑤ | Program Time | 69 |
| ⑨ ⑨ ⑥ | Program Date | 69 |
| ⑨ ⑨ ⑦ | Program Banner Text | 69 |
| ⑨ ⑨ ⑧ | Print 100 Events | 69 |
| ⑨ ⑨ ⑨ | Log Off Engineer | 69 |

Programming Zones





All Zone Options

This menu option allows you to program the Zone Type, Zone Wiring, Zone Attributes 1, Zone Attributes 2, Zone Attributes 3 and Partitions & Bypass Groups all in one sequence.

Zone Type

How the alarm system responds, when a zone is violated depends on the zone type. The following zone types are available:

① ① Null

A zone that is not monitored by the system, unused zones should be programmed as Null zones.

① ② Delay 1

This zone type is normally used for entry/exit detection. The zone can be violated during the exit delay without causing an alarm. Once the system/partition is armed, activation of the zone will start the Entry Delay 1 timer for the selected partition. The user must disarm the system before the entry timer elapses or the system will generate an alarm.

① ③ Delay 2

Operates as Delay 1, but uses Entry Delay 2 timer for the selected partition.

① ④ Interior Follower

This zone type is normally used for interior detection devices, such as passive infrared sensors. The zone will not cause an alarm if violated during the entry delay. However, if the zone is violated before the entry delay has started, it will generate an instant alarm.

① ⑤ Interior Instant

This zone type is normally used for interior detection where an instant response is required. The zone will cause an instant alarm if it is violated when the system/partition is armed.

① ⑥ Perimeter Instant

This zone type is normally used for perimeter protection, windows, patio doors etc. The zone will cause an instant alarm if it is violated when the system/partition is armed.

① ⑦ Fire

This zone type is normally used for monitoring smoke detectors. The zone will cause a unique alarm with distinctive 'fire' tone if it is

violated when the system/partition is armed or disarmed. In addition, the bell output will be pulsed rather than sounding continuously as with a normal alarm.

If the "Double Knock" attribute is enabled on a Fire zone, the zone will behave as a verified fire zone. On the first activation the panel will start the "Double Knock" timer then remove power to the smoke detector (Sensor Reset on Reset) for a short period, then reapply the power (to reset the detector). If the detector activates again before the timer expires the panel will generate a verified fire alarm condition.

0 7 PA Silent

This zone type is normally used for monitoring Panic or hold-up alarms. The zone will cause a silent alarm if it is violated when the system/partition is armed or disarmed.

0 8 PA Audible

This zone type is normally used for monitoring Panic or hold-up alarms. The zone will cause an instant audible alarm if it is violated when the system/partition is armed or disarmed.

0 9 Medical

This zone type is normally used for monitoring medical alarms. The zone will cause a silent alarm if it is violated when the system/partition is armed or disarmed.

1 0 24-Hour Tamper

This zone type will cause an instant audible alarm if it is violated when the system/partition is armed or disarmed.

1 1 Trouble

This zone type will cause an internal alarm (keypads and speaker) if it is violated when the system/partition is armed or disarmed.

1 2 24-Hour - Gas

This zone type will cause a silent alarm if it is violated when the system/partition is armed or disarmed. The panel will report a 24-Hour Gas alarm to the monitoring station if communication is enabled.

1 3 24-Hour - Water

This zone type will cause a silent alarm if it is violated when the system/partition is armed or disarmed. The panel will report a 24-Hour Water alarm to the monitoring station if communication is enabled.

1 4 24-Hour - High Temperature

This zone type will cause a silent alarm if it is violated when the system/partition is armed or disarmed. The panel will report a 24-Hour High Temperature alarm to the monitoring station if communication is enabled.

1 5 24-Hour - Low Temperature

This zone type will cause a silent alarm if it is violated when the system/partition is armed or disarmed. The panel will report a 24-Hour Low Temperature alarm to the monitoring station if communication is enabled.

1 6 Momentary Key Switch

This zone type can be used to arm/disarm and reset one or more partitions. When the zone is violated and then secured the system will arm the partition(s) assigned to the zone. When the zone is subsequently violated and then secured, the system will disarm the partition(s) assigned to the zone. Operating this zone following an

alarm condition resets the assigned partition(s). The operation of this zone type can be further changed, see "Zone Attributes 3" on page 29.

1 7 Maintained Key Switch

This zone type can be used to arm/disarm and reset one or more partitions. When the zone is violated the system will arm the partition(s) assigned to the zone. When the zone is subsequently secured, the system will disarm the partition(s) assigned to the zone. Operating this zone following an alarm condition resets the assigned partition(s). The operation of this zone type can be further changed, see "Zone Attributes 3" on page 29.

1 8 Push to Set

This zone type is used to arm the system/partition. When the system is armed, the panel will provide an infinite exit delay. When a user violates and restores the Push to Set zone, the panel will wait 5 seconds, then arm the system/partition.



To enable the Push to Set feature, the exit delay timer for the selected partition MUST be programmed to 255 seconds.

Zone Wiring

The zone wiring option determines how the detection device may be electrically wired to the zone input. It also determines what status conditions can be monitored. See page 15 for details on wiring zones.

The following wiring types are available:

0 Normally Closed

1 Normally Open

2 Single EOL - N/C & N/O (Burglary)

3 Single EOL - N/O (Fire)

4 Single EOL - N/C

5 Single EOL - O/C Tamper

6 Single EOL - S/C Tamper

7 Double EOL

8 Zone Doubled

9 Triple EOL

Zone Attributes 1

Zone Attributes 1 can be assigned to a zone to alter its default operation. The function of each attribute is described as follows:

1 Enable Instant Internal Alarm Tones

On: The keypad sounder and speaker driver will sound immediately the zone causes an alarm.

Off: The keypad sounder and speaker driver will sound after the bell delay timer. (Zone must also be programmed for Delayed Bell).

2 Enable Bell

On: The bell output will trigger when the zone causes an alarm.

Off: The bell output will not trigger.

3 Delayed Bell

On: The bell output is delayed when the zone causes an alarm.

Off: The bell output is instant.

4 Pulsed Bell

On: The bell output is pulsed on and off when the zone causes an alarm (Fire).

Off: The bell output is constant.

⑤ Enable Instant Strobe

On: The strobe output will trigger immediately the zone causes an alarm.

Off: The strobe output will trigger after the bell delay timer. (Zone must also be programmed for Delayed Bell).

⑥ Enable User Chime

On: The keypad sounder and speaker driver will generate a chime tone when zone is violated in the disarmed state.

Off: The zone will respond as normal.

⑦ Enable Transmission Delay

On: The on-board communicator will delay the alarm transmission to the monitoring station when the zone causes an alarm.

Off: The transmission is instant.

⑧ Enable Transmission

On: The on-board communicator will report the alarm status to the monitoring station when the zone causes an alarm.

Off: The alarm status is not reported.

Zone Attributes 2**① ④**

Zone Attributes 2 can be assigned to a zone to alter its default operation. The function of each attribute is described as follows:

① Enable Manual Bypass

On: The user can bypass the zone.

Off: The user cannot bypass the zone.

② Enable Stay Bypass

On: The zone is automatically bypassed when the system is stay armed.

Off: The zone is not bypassed when stay armed.

③ Enable Force Arming

On: The user can arm the system/partition with the zone violated.

Off: The zone must be secure before the system/partition can be armed.

④ Quick Response Time

On: The zone response time is governed by the Zone Loop Response Timer (see page 35).

Off: The zone response time is fixed at 250ms.

⑤ Enable Cross Zoning

On: When two or more zones are programmed with this attribute, the system will start the Cross Zone Delay timer after the first zone is violated. If another Cross Zone is violated before the timer expires the system will report a Verified Cross Zone alarm.

Off: The zones report as normal.

⑥ Enable Soak Test

On: The zone is selected for soak test. During the soak test period the zone will not cause an alarm if violated, but the system will record the event in the log and indicate a Service Required Fault. This fault condition can only be cleared, by performing a "Reset" with the Engineer's code.

Off: The zone responds as normal.

⑦ Enable Swinger Shutdown

On: The zone will only rearm at the end of the bell duration providing the Swing Shutdown limit has not been reached.

Off: The zone always rearms at the end of the bell duration and subsequent violations of the zone will cause the system to reactivate the bell and report the alarm to the monitoring station.

⑧ Enable Double Knock

On: When a zone is enabled for Double Knock it will only cause an alarm when:

a) The zone remains violated for the duration of the "Cross Zone Time Window".

b) The zone is violated twice within the "Cross Zone Time Window".

c) If any two zones within the same partition with the "Double Knock" attribute are violated during the "Cross Zone Time Window".

Off: The zone responds as normal.

Zone Attributes 3**① ⑤**

Zone Attributes 3 can be assigned to a zone to alter its default operation. The function of each attribute is described as follows:

① Change to Delay 1 on Stay Arm

On: The zone will change to a Delay 1 zone type when the system is Stay armed.

Off: The zone type will not change.

② Change to Follower on Stay Arm

On: The zone will change to a Follower zone type when the system is Stay armed.

Off: The zone type will not change.

③ Zone Warning

On: The panel will generate an internal alarm when the zone remains active for 2 minutes during the disarmed state.

Off: The panel will respond as normal.

④ Auto Reinstate if Force Armed

On: When a zone is force armed (bypassed), it will automatically be reinstated when the zone is secured.

Off: Force armed zones remain bypassed until the partition is disarmed.

⑤ Disable Keyswitch when Away Armed

On: The keyswitch zone is disabled once the system is Away armed, i.e., it cannot be used to disarm the selected partitions.

Off: The keyswitch zone can be used to arm and disarm the selected partitions.

⑥ Disable Exit Faults

On: The zone will not cause the panel to generate a fault tone or extinguish the "Ready" light, if violated during the exit mode.

Off: The zone behaves as normal.

⑦ Truncate Exit Delay

On: When the zone is activated during exit, the panel will truncate any remaining exit time to zero. This attribute would normally be used with Delay 1/Delay 2 zone types.

Off: The zone behaves as normal.

⑧ Forced Walk Test

On: When arming the system the zone will be indicated as active, if the zone has not been activated during the "Activity Time Window", see page 36. This will force the user to check that the zone is secure, on activating the zone the system will clear the indication from the remote keypad and the user may continue to arm the system. This feature can be used on detectors that are at risk of being masked or obscured in some way.

Off: The zone behaves as normal.

Zone Attributes 3 (Key Switch) ① ⑤

When a zone is programmed as a Key Switch type Zone Attributes 3 options 3, 4 and 6 are used to change the operation of the Key Switch zone. The function of each attribute is described as follows:

③ Key Switch is Instant Arming

On: The key switch zone will arm the selected partitions immediately (no exit delay).

Off: The key switch zone will start exit timer for the selected partitions.

④ Key Switch will Stay Arm/Disarm

On: The key switch zone will Stay arm/disarm the selected partitions.

Off: The key switch zone will Away arm/disarm the selected partitions.

⑥ Disable Auto Arm

On: When a key switch zone with this attribute is active, it will disable the auto-arm feature for the partitions assigned to the zone. When the zone returns to the secure state the auto-arm feature is re-enabled.

Off: Keyswitch zones behave as normal.

⑦ Monitor Only

On: Any Activation/deactivation from this zone will be logged and reported to an ARC as a Keytube. There will be no notification on any keypads or alarm.

Off: Keyswitch zones behave as normal.

Zone Partitions & Groups ① ⑥

Partitions allow the system to be divided into areas of protection so that different partitions can be armed and disarmed independently from each other. By default all zones are assigned to Partition 1, but if required a zone can be assigned to Partitions 1 - 4. If a zone is assigned to more than one partition it will only be armed when all partitions they are assigned to are armed.

The system has four Bypass Groups, these can be configured so that the user can select a predefined group of zones for bypassing.

The function of each attribute is described as follows:

① Partition 1

On: The zone is assigned to Partition 1.

Off: The zone is not assigned to Partition 1.

② Partition 2

On: The zone is assigned to Partition 2.

Off: The zone is not assigned to Partition 2.

③ Partition 3 (Premier 816/832 Only)

On: The zone is assigned to Partition 3.

Off: The zone is not assigned to Partition 3.

④ Partition 4 (Premier 816/832 Only)

On: The zone is assigned to Partition 4.

Off: The zone is not assigned to Partition 4.

⑤ Group 1 Bypass

On: The zone is assigned to Group 1 Bypass.

Off: The zone is not assigned to Group 1 Bypass.

⑥ Group 2 Bypass

On: The zone is assigned to Group 2 Bypass.

Off: The zone is not assigned to Group 2 Bypass.

⑦ Group 3 Bypass

On: The zone is assigned to Group 3 Bypass.

Off: The zone is not assigned to Group 3 Bypass.

⑧ Group 4 Bypass


On: The zone is assigned to Group 4 Bypass.

Off: The zone is not assigned to Group 4 Bypass.



NOTE Zones must be assigned to at least one partition, if a zone is not assigned to a partition it will not respond to any alarm activation.


Zone Text (LCD Only) ① ⑦

If the system is fitted with LCD remote keypad you can assign up to 16 characters of text to each zone. Text is programmed in a similar way to mobile phones. Characters are selected by pressing the corresponding key the appropriate number of times (to select a character on the same key, press  to move the cursor along). For details on entering text, see page 22.

Assign Radio Device ① ⑧

If the system is fitted with a **Radioplus™** or **Ricochet™** radio module this menu option is enabled. This menu is used to assign radio devices such as PIRs and Door Contacts to a zone on the system. Radio devices can be assigned to any of the available zones on the system.

Programming Partitions




Led Key

- Off
- On
- ✱ Slow Flash
- ✱ Fast Flash

Note

If the system only has 1 partition, the option to enter the Partition No will NOT be displayed.



Partition Exit Delay (2) (0)

This timer controls the delay between the user initiating the exit procedure for the selected partition and the partition actually arming. If a 'Push to Set' zone is used for arming the partition, this timer must be set to 255 seconds.

Partition Entry Delay 1 (2) (1)

If the user enters the premises via a 'Delay 1' zone, the system uses this timer to allow the user time to access the keypad and disarm the selected partition.



NOTE The Entry Delay Timer must be set at 30 seconds or greater to comply with the requirements of EN50131.

Partition Entry Delay 2 (2) (2)

If the user enters the premises via a 'Delay 2' zone, the system uses this timer to allow the user time to access the keypad and disarm the selected partition.



NOTE The Entry Delay Timer must be set at 30 seconds or greater to comply with the requirements of EN50131.

Partition Communication Delay (2) (3)

This timer controls the delay between an alarm occurring in the selected partition and the panel reporting the alarm event to the alarm receiving centre.

Partition Bell Delay (2) (4)

This timer controls the delay between an alarm occurring in the selected partition and the bell output activating.

Partition Bell Duration (2) (5)

This timer controls the duration of the bell output after an alarm has occurred in the selected partition.

Partition Options (2) (6)

The function of the partition options is described as follows:

() Enable Auto Bypass Mode

On: The system will automatically Stay arm the selected partition if the user arms the system using the ARM button, but does not violate the entry/exit zone.

Off: The system will away arm the selected partition even if the entry/exit zone is not violated.

() Stay Armed Exit is Silent

On: The selected partition will not generate an exit tone when being Stay armed.

Off: The selected partition will generate exit tone.

() Enable Remote Arming

On: The selected partition can be armed remotely via download software.

Off: The selected partition cannot be armed remotely.

④ Enable Remote Disarming

On: The selected partition can be disarmed remotely via the downloading computer.

Off: The selected partition cannot be disarmed remotely.

⑤ Enable Local Exit Tones

On: When arming the selected partition only the keypad that is being used will generate an exit tone.

Off: When arming the selected partition all keypads will generate an exit tone.

⑥ Stay Armed Entry is Instant

On: When the selected partition is Stay armed the entry/exit zone changes to instant.

Off: When the selected partition is stay armed the entry/exit zone is delayed.

⑦ Stay Armed Exit is Delayed

On: The selected partition will provide an exit delay when being Stay armed.

Off: The selected partition will arm instantly when being Stay armed.

⑧ Only Start Exit when Partition is Ready

On: When a user attempts to arm their partition, the system will only allow the exit mode to start if the partition is Ready (all zones secure).

Off: The system will allow the exit mode to start even if one or more zones are violated. If one or more zones are violated, the keypad will indicate the active zone(s) and generate a fault tone. The active zones must be secured before the exit time expires or the partition will not arm.

Partition Auto Arm/Disarm Options ②⑦

The system has four independent Control Timers that may be configured to switch on and off at different points of the day and days of the week (see page 36). One or more of these Control Timers can be used to automatically Arm or Disarm a selected partition:

① Auto Arm Partition with Control Timer 1

On: The selected partition is armed automatically when Control Timer 1 is switched ON.

Off: The selected partition is not armed automatically.

② Auto Arm Partition with Control Timer 2

On: The selected partition is armed automatically when Control Timer 2 is switched ON.

Off: The selected partition is not armed automatically.

③ Auto Arm Partition with Control Timer 3

On: The selected partition is armed automatically when Control Timer 3 is switched ON.

Off: The selected partition is not armed automatically.

④ Auto Arm Partition with Control Timer 4

On: The selected partition is armed automatically when Control Timer 4 is switched ON.

Off: The selected partition is not armed automatically.



NOTE

When the control timer switches on, the panel will start a 2 minute exit timer. During the first 90 seconds of the exit timer the panel will generate a warning tone every 10 seconds. After which the panel will revert to a standard exit tone for the remaining 30 seconds.

⑤ Auto Disarm Partition with Control Timer 1

On: The selected partition is disarmed automatically when Control Timer 1 is switched OFF.

Off: The selected partition is not disarmed automatically.

⑥ Auto Disarm Partition with Control Timer 2

On: The selected partition is disarmed automatically when Control Timer 2 is switched OFF.

Off: The selected partition is not disarmed automatically.

⑦ Auto Disarm Partition with Control Timer 3

On: The selected partition is disarmed automatically when Control Timer 3 is switched OFF.

Off: The selected partition is not disarmed automatically.

⑧ Auto Disarm Partition with Control Timer 4

On: The selected partition is disarmed automatically when Control Timer 4 is switched OFF.

Off: The selected partition is not disarmed automatically.

Equipment Areas**②⑧**

This option allows you to assign the following to partitions:

① Auxiliary Input Areas

This option allows the Auxiliary input to be assigned to one or more partitions. This will affect how the Auxiliary input now functions, e.g. if the Auxiliary input is programmed as a "Latched Keyswitch" (see page 38) and is assigned to partition 3 and 4, the system will arm partitions 3 and 4 when the Auxiliary input is activated etc.

① Panel Bell Areas

This option allows the panel Bell output to be assigned to one or more partitions. This will affect how the Bell output operates, e.g. if the Bell output is assigned to partition 1 and 2, the panel Bell will only activate when an alarm occurs in either partition 1 or 2.

② Bell Squawk Areas

This option allows the Bell Squawk feature to be assigned to one or more partitions. This will effect how the Bell Squawk feature operates, e.g. if the Bell Squawk feature is assigned to partition 1 and 2, the panel Bell output and any outputs programmed as Bell will squawk when either partition 1 or 2 is armed/disarmed.




NOTE


The Bell Squawk feature must also be enabled, see page 38.

③ Masked when Armed

When a partition is assigned to this option, the system will generate a full alarm if an Anti-Masking detector in the selected partition reports a "Masking" condition whilst the selected partition is armed. If the partition is unassigned, the system will only generate a "Zone Trouble alarm". The detector must be wired to the system using Triple EOL wiring configuration, as shown on page 17.

Programming Global Options





System Options 1

- ① System Clock = Crystal
- ② Battery Connection Supervision
- ③ Battery Dynamically Load Tested
- ④ Panel NVM is Locked
- ⑤ Power Savings During AC Mains Failure
- ⑥ Line Fault Overrides Bell Delay
- ⑦ Two-Wire Smoke Detection on O/P 1
- ⑧ Convert Siren Output from Voltage to Speaker

System Options 2

- ① Tamper Alarms Cause a Trouble While Disarmed
- ② Tamper Alarms Cause a Trouble While Stay Armed
- ③ Defer Reporting of Non-Zone Restorals
- ④ Use Delay Timer to Defer Non-Zone Restorals
- ⑤ Inhibit Keyswitch Operation Upon EOL Tamper
- ⑥ Away Arm Overrides Alarm Transmission Delay
- ⑦ Defer Reporting of Zone Restorals
- ⑧ Use Delay Timer to Defer Zone Restorals

System Options 3


- ① Away Arm Exit Error Doesn't Sound Bell
- ② Zone Test - Silence on No Violation
- ③ Alarm Status Light Indicates Fire
- ④ Enable Entry/Exit Tones for Panel Speaker
- ⑤ Enable Cross Partitioning
- ⑥ Enable EN 50131-1 Requirements
- ⑦ Reinstall Bypassed Zones on Disarm
- ⑧ Invert Panel Siren Output

Hardware Options

- ① Panel Output 1 Supervised for Faults
- ② Panel Output 2 Supervised for Faults
- ③ Siren/Bell Output Supervised for Faults
- ④ Panel Box Tamper Switch Monitored
- ⑤ Auxiliary Fuse Supervised for Faults
- ⑥ Battery Supervised for Faults
- ⑦ AC Mains Supply is Monitored
- ⑧ Telephone Line is Monitored

Auxiliary Input Types

- ① Not Used
- ② Auxiliary Tamper
- ③ Remote Reset
- ④ Telephone Line Monitor
- ⑤ Panic Alarm
- ⑥ Silent PA
- ⑦ Latched Keyswitch
- ⑧ Momentary Keyswitch



System Timers

These timers control the system timing and delay functions. The function of each timer is described as follows:

①① AC Fail Delay

This timer delays the audible indication following a mains (AC) failure.

①① Telephone Line Fault Delay

This timer delays the audible indication following a telephone line fault.

①② Cross Zone Time Window

If one or more zones have been programmed with 'Enabled Cross Zoning', the system will only generate a verified cross zone alarm if the zones are violated within this time window.

①③ Zone Soak Test Time

This timer controls the number of days a zone is put on soak test. If a zone is violated during the soak test period it will not cause an alarm, however, the event will be logged and the zone that failed test will be indicated when the user disarms the system. The Zone Soak Test is started when one or more zones are programmed with 'Enable Soak Test' attribute, see page 28. All zones that are on test are removed from test at the end of the soak test period, providing no failures have occurred.

①④ Restore Reporting Delay

This timer controls the delay between a system event restoring and the system reporting the restore condition to the Alarm Receiving Centre.

①⑤ Output Short Pulse Time

If output is programmed with the 'Use Short Pulse Time' attribute the output will activate for the duration of this timer, 001 to 255 x 100mS.

①⑥ Zone Loop Response Time

If a zone is programmed with the 'Quick Response Time' attribute the zone loop response will be controlled by the duration of this timer, 001 to 255 x 8mS.

①⑦ Transmission Abort Delay

This timer controls the duration in which an alarm transmission may be aborted following alarm activation. When an alarm occurs, the 'Alarm Cancel' condition is only reported if the system is disarmed within this period. If the system is disarmed after this period the 'Alarm Cancel' is NOT reported.

①⑧ Test Transmission Interval

This timer controls the interval of test transmissions to the alarm receiving centre. 000 = Control Timer 3; 024 = daily; 168 = weekly etc. Enable Auto Test Transmission on page 52 must be ON,

①⑨ Courtesy Delay

This timer controls the duration of courtesy output. The courtesy output is activated whenever a keypad is used and when the system is in entry mode.

①⑩ Service Timer

This timer controls the period in which a Service Required fault condition will occur. If the timer is set to 000 this feature is disabled.

①① Verified 2-Wire Smoke Delay

When the timer is set to zero 2-wire smoke detectors are unverified, i.e., as soon as a detector activates, the panel will go into a fire alarm condition. When the timer is set above zero, 2-wire smoke detectors are verified as follows: On the first activation the panel will start this timer then remove power to the 2-wire smoke detector for a short period, then reapply the power (to reset the detector). If the detector activates again before this timer expires, the panel will generate a verified fire alarm condition.

①② Alarm Confirmation Delay

When an Intruder alarm occurs, this timer starts. If a second (different) zone is activated within this time window, the "Confirmed Alarm" output will activate. If a second (different) zone is activated after this time window, the "Confirmed Alarm" output will not activate.

①③ Activity Time Window

If a zone has the "Forced Walk Test" attribute and it is not activated during this time window, it will be indicated as an active zone when they try to arm the system. Once the timer expires it is restarted and all "Forced Walk Test" zones are displayed as active on the keypad.

①④ Poll IP Every

This timer controls how often the *ComIP* module (if fitted) polls the ARC software with a "Polling" message.

System Counter/Levels

③①

The function of each Counter/Level is described as follows:

① Swinger Shutdown Count

This counter controls the number of times a zone can re-arm following an alarm activation. Once a zone has reached this limit it will not cause any further alarms. In order to use the Swinger Shutdown Counter the zone must be programmed with the 'Enable Swinger Shutdown' attribute, see page 28. The Swinger Count is also applied to alarms caused by the Auxiliary input.

① Panel Speaker Volume

This counter/level controls the advisory tones (entry/exit, fault etc.) volume level of the speakers connected to the siren output. 0 = minimum volume; 7 = maximum volume.

② Chime Volume

This counter/level controls the chime volume level of the speakers connected to the siren output. 0 = disabled; 1 = minimum volume; 7 = maximum volume.

③ Clock Adjustment

This counter can be used to automatically adjust the real time clock either forward or backwards up to 49 seconds per day. When this counter is set to 50 (default value) no clock adjustment will be made. If the counter is set to value less than 50 the clock will be slowed down, e.g., a value of 48 will slow the clock down by 2 seconds per day. If the counter is set to value greater than 50 the

clock will be speeded up, e.g., a value of 52 will speed the clock up by 2 seconds per day.

④ Language Selection

This option selects the operating language of the system. Use the scroll keys to display the available languages, then press Yes to select. After a short delay the keypad display will switch to the selected language.

⑤ Country Operation Code

The country operation code determines the way that the panel works so as to satisfy country specific alarm and telecoms standards. Enter the code as a 3 digit number by reference to the table below. The panel will re-load the default configuration for the selected country, thereby overwriting all programming already carried out. This command will take around 10 seconds to complete. If a country is not listed then enter the code 000 to load the standard configuration.

| Country | Code | Country | Code |
|--------------|------|-----------|------|
| Standard | 000 | UK | 044 |
| South Africa | 027 | Norway | 047 |
| New Zealand | 064 | Russia | 007 |
| Sweden | 046 | Hungary | 036 |
| Denmark | 045 | Belgium | 032 |
| Holland | 031 | Belgium 2 | 131 |
| Holland 2 | 131 | Portugal | 351 |
| Australia | 061 | Poland | 048 |
| Australia 2 | 161 | Bulgaria | 059 |
| Australia 3 | 162 | | |
| Spain | 034 | | |

System Control Timers

③②

The system has 4 independent Control Timers that may be configured to switch on and off at different points of the day and days of the week. Once configured these timers can be used to automatically arm/disarm partitions or lock-out users from operating the system. Control Timer 3 can be used to send an automatic test call to the alarm receiving centre, see "Test Transmission Interval" on page 35. Control Timer 4 can be used to perform a dynamic battery test, see "Control Timers 4 Performs Battery Test" on page 39.

System Options 1

③③

The function of each option is described as follows:

① Clock = Crystal

On: The system clock is calculated using the onboard crystal.

Off: The system clock is calculated by using the incoming mains supply at a frequency of 50Hz.

② Battery Connection Supervision

On: The system will check that the stand-by battery is connected (every 30 seconds).

Off: The system will not check the standby battery.

③ Battery Dynamically Load Tested

On: The standby battery is tested when any partition is disarmed or every 12 hours from the last battery test.

Off: The system will not perform the dynamic battery test.

④ Panel NVM is Locked

- On: The NVM is locked and the "Load Defaults" jumper pins on the main PCB are disabled, thus preventing the factory defaults from being loaded.
- Off: The "Load Defaults" jumper pins on the main PCB are enabled, thus allowing the panel to be defaulted.

⑤ Power Savings during AC Mains Failure

- On: The back-lighting for all remote keypads is switched off during a mains failure.
- Off: The back-lighting is enabled during a mains failure.

⑥ Line Fault Overrides Bell Delay

- On: The system will override the bell delay in the event of a telephone line fault.
- Off: The system will enforce the bell delay.

⑦ Two-Wire Smoke Detection on O/P 1

- On: Panel Output 1 is enabled for 2-wire smoke detectors (JP1 on the main PCB must also be removed, see page 8).
- Off: Panel Output is a normal programmable output.

⑧ Convert Siren O/P from Voltage to Speaker Driver

- On: The Siren output terminals on the main PCB are configured for a speaker driver.
- Off: The Siren output terminals on the main PCB are configured for Voltage output to power a bell or siren.

System Options 2**③ ④**

The function of each option is described as follows:

① Tamper Alarms Cause a Trouble While Disarmed

- On: Tamper alarms cause a trouble condition while the system is disarmed.
- Off: Tamper alarms cause an alarm while the system is disarmed.

② Tamper Alarms Cause a Trouble While Stay Armed

- On: Tamper alarms cause a trouble condition while the system is Stay armed.
- Off: Tamper alarms cause an alarm while the system is Stay armed.

③ Defer Reporting of Non-Zone Restorals

- On: The communicator reporting of non-zone restorals will be deferred until the Restore Reporting Delay timer expires or until the system is disarmed (see 4 below).
- Off: Non-zone restorals will report immediately as they occur.

④ Use Delay Timer to Defer Non-Zone Restorals

- On: If System Option 2.3 (see above) is enabled, then enabling this option will defer the non-zone restoral reporting until the Restore Reporting Delay Timer has elapsed.
- Off: Non-zone restorals are deferred until the system is disarmed.

⑤ Inhibit Keyswitch Operation upon EOL Tamper

- On: Tampering of a keyswitch zone will inhibit the keyswitch operation.
- Off: Tampering will not inhibit the keyswitch operation.

⑥ Away Arm Overrides Alarm Transmission Delay

- On: The 'Alarm Transmission Delay' timer is overridden when the system/partition is away armed.
- Off: The 'Alarm Transmission Delay' timer is not overridden.

⑦ Defer Reporting of Zone Restorals

- On: The communicator reporting of zone restorals will be deferred until the Restore Reporting Delay Timer expires or until the system is disarmed (see 8 below).
- Off: Zone restorals will report immediately as they occur.

⑧ Use Delay Timer to Defer Zone Restorals

- On: If System Option 2.7 (see above) is enabled, then enabling this option will defer the zone restoral reporting until the Restore Reporting Delay Timer has elapsed.
- Off: Zone restorals are deferred until the system is disarmed.

System Options 3**③ ⑤**

The function of each option is described as follows:

① Away Arm Exit Error Doesn't Sound Bell

- On: The bells will not sound if an exit error occurs when the system is away armed.
- Off: The system will sound the bell if an exit error occurs when the system is away armed.

② Zone Test - Silence on No Violation

- On: The Zone Test sounder is silent when all zones are secure and will pulse sound when one or more zones are violated.
- Off: The Zone Test sounder is on continuously when all zones are secure and will pulse sound when one or more zones are violated.


③ Alarm Status Light Indicates Fire

- On: The alarm status light will only indicate Fire alarms. Fire alarms activated from zones will illuminate the relevant zone light and the alarm light. Fire alarms activated from a 2-wire smoke detector will only illuminate the alarm light. All other zone alarms will illuminate the relevant zone light only.
- Off: The alarm status light indicates both alarms and fire alarms.

④ Enable Entry/Exit Tones for Panel Speaker

- On: The panel speaker will produce entry/exit tones.
- Off: The panel speaker only produces alarm and trouble tones.

⑤ Enable Cross Partitioning

- On: The user may temporarily switch to another partition by pressing the  key, and the relevant partition number. Once the remote keypad has been selected for another partition, the indicator lights will only display information relevant for the selected partition. The remote keypad will revert back to its normal partition 15 seconds after the last key press or 1 minute after the last entry of a User code.
- Off: All remote keypads are locked to their programmed partition number and the user cannot switch to another partition.

⑥ Enable EN 50131-1 Requirements

- On: The Engineer code will only be accepted if the user has authorised Remote/Engineer Access (see page 69). If an alarm occurs during entry (timed-out entry alarm) the system will generate an internal alarm for 30 seconds before activating the bell and communicator. Wireless detectors must have polled in within 20 minutes when attempting to arm the system. Mag 2 input on the *RadioPlus* magnetic contact is a tamper input.
- Off: The Engineer code is accepted at all times and the timed-out entry alarms respond as normal. Wireless detectors do not need to poll in within 20 minutes when attempting to arm the system. Mag 2 input on the *RadioPlus* magnetic contact is an alarm input.

⑦ Reinstate Bypassed Zones on Disarm

- On: Any zones that have been manually bypassed are automatically reinstated when the partition is disarmed.
- Off: Any zones that have been manually bypassed will remain bypassed when the partition is disarmed.

⑧ Invert Panel Siren Output

- On: When the panel siren output is configured for voltage drive (see System Options 1.8 on page 37) the output is inverted, i.e. Bells off = voltage applied, Bells on = voltage removed.

Off: The siren output is normal.

Hardware Options ③ ⑥

The hardware options allow you to control which hardware monitoring features are enabled or disabled. The function of each option is described as follows:

① Panel Output 1 Supervised for Faults

On: Panel Output 1 is supervised and if the device or wiring is disconnected, the system will generate an "Output 1 Fault" alarm.

Off: Panel Output 1 is not supervised.

② Panel Output 2 Supervised for Faults

On: Panel Output 2 is supervised and if the device or wiring is disconnected, the system will generate an "Output 2 Fault" alarm.

Off: Panel Output 2 is not supervised.

③ Siren/Bell Output Supervised for Faults

On: The Siren/Bell Output is supervised and if the device or wiring is disconnected, the system will generate a "Siren/bell Fault" alarm.

Off: The Siren/Bell Output is not supervised.

④ Panel Box Tamper Switch Monitored

On: The system will monitor the main panel box tamper switch.

Off: The main panel box tamper switch is not monitored.

⑤ Auxiliary Fuse Supervised for Faults

On: The Auxiliary 12V Power fuse is supervised, and if the fuse is blown, the system will generate an "Aux Fuse Fault" alarm.

Off: The Auxiliary 12V Power fuse is not supervised.

⑥ Battery Supervised for Faults

On: The Battery is supervised, and if the battery is disconnected or faulted, the system will generate a "Battery Fault" alarm.

Off: The Battery is not supervised.

⑦ AC Mains Supply is Monitored

On: The AC mains supply voltage is monitored, and if the supply is removed, the system will generate a "AC Fail" alarm.

Off: The AC mains supply voltage is not monitored.

⑧ Alarm Call Path Monitored

The alarm call path monitoring depends on the chosen method of alarm call delivery.

If alarm calls are to be transmitted over the internet ("Connect Via IP" ARC Protocol Option 8 see page 53)

On: The IP connection is monitored and if the connection is lost a "Line Fault" will be generated.

Off: The IP connection is not monitored.

If alarms are to be transmitted over the telephone line

On: The telephone line to the control panel is monitored, and if the telephone line is disconnected, the system will generate a "Line Fault" alarm.

Off: The telephone line is not monitored.

Auxiliary Input Options ③ ⑦

The Auxiliary Input on the main panel PCB can be used for a wide range of functions, the operation of the input can also be inverted to allow various wiring options (see page 39). The following Auxiliary Input functions are available:

① Not Used

The Auxiliary Input is not monitored.

① Auxiliary Tamper

When activated the panel will generate a tamper alarm for the assigned partitions (see page 32).

② Remote Reset

When activated the system will reset any alarms/faults for the assigned partitions (see page 32).

③ Telephone Line Monitor

When activated the system will generate a Telephone Line fault for all partitions.

④ Panic Alarm Input

When activated the system will generate an Audible Panic alarm for the assigned partitions (see page 32).

⑤ PA Silent Input

When activated the system will generate a Silent Panic alarm for the assigned partitions (see page 32).

⑥ Latched Keyswitch Input

When the input is active the system will arm the assigned partitions (see page 32). When the input is inactive the system will disarm the assigned partitions.

⑦ Momentary Keyswitch Input

When the input is activated the system will arm the assigned partitions (see page 32). When the input is activated again the system will disarm the assigned partitions.



NOTE

Both the "Latched" and "Momentary" Keyswitch input types are ideally suited for use with remote RF fobs as they have a special auto re-arm feature. When either input type is used to disarm one or more partitions, the control panel will monitor all zones activity for 2 minutes. If after two minutes no zones were activated within the partition that was disarmed, the panel automatically re-arms the partition. This means even if the user activates the fob unintentionally and disarms the system without realising it; the panel will automatically arm its self after 2 minutes.

Miscellaneous Options 1 ③ ⑧ - ①

The function of each option is described as follows:

① Enable Bell Squawk on AWAY Arm/Disarm

On: When the system is Away armed, the panel bell/siren output is pulsed once. On disarming the output is pulsed twice. The panel bell/siren output must be configured for voltage drive (see System Options 1.8 on page 37).

Off: The panel bell/siren output behaves normally on Away arm.

② Enable Bell Squawk on STAY Arm/Disarm

On: When the system is Stay armed, the panel bell/siren output is pulsed once. On disarming the output is pulsed twice. The panel bell/siren output must be configured for voltage drive (see System Options 1.8 on page 37).

Off: The panel bell/siren output behaves normally on Stay arm.

③ Disable AC Fail Acknowledgement

On: When the mains supply power fails the Service light will flash rapidly indicating an AC failure. The system can now be armed without the need for acknowledging the "AC Fail" fault.

Off: When the mains supply power fails the Service light will flash normally indicating the "AC Fail" Fault. The fault must be acknowledged before the system can be armed.

④ Disable Open/Close Reporting on STAY Arm

On: Open and Close events are not reported to the Alarm Receiving Centre when Stay arming the system/partition.

Off: Open and Close events are reported when Stay arming the system/partition.

⑤ Cross/Double Knock Timer is in Minutes

On: System timer 02 "Cross Zone Time Window" is counted in minutes.

Off: System timer 02 "Cross Zone Time Window" is counted in seconds.

⑥ Disable Zone Bypass when Armed

On: The user cannot bypass zones in an armed partition. Only zones that are unarmed can be selected for bypass.

Off: The user can bypass zones in an armed partition.

⑦ Activated Zones Cause Alarm during Exit

On: If a non "delay" or "follower" zone is activated during exit mode the panel will generate a full alarm condition.

Off: If a non "delay" or "follower" zone is activated during exit mode the panel will generate a fault condition.

⑧ Control Timer 4 Performs Battery Test

On: Control Timer 4 is used to perform the dynamic battery test, i.e. when the timer switches on the panel will allow the stand-by battery to power the system for 1 minute.

Off: Control Timer 4 behaves as normal.

Miscellaneous Options 2**③ ⑧ - ②**

The function of each option is described as follows:

① Disable Service Fault Acknowledgement

On: When a Service Fault occurs the system can be armed without the need to acknowledge the fault condition.

Off: All Service Faults require acknowledgment before the system can be armed.

② Enable User Reset for Alarms

On: Any user can reset alarms and troubles.

Off: Alarms and troubles can only be reset by users with the "Allow Alarm/Fault Acknowledgement" attribute (see User Options 3 on page 67).

③ Disable Online Printing

On: The online printer port (Com1) will not send real time event data.

Off: The online printer port (Com1) will send real time event data.

④ Enable Bell Module and UK Options

On: When the system is fitted with a *Premier Bell Module* this option must be enabled (this module is only used in the UK). Also the following UK options are enabled:

- All alarm zones and tampers are disabled whilst in engineers programming mode
- After entering the engineers passcode, the Strobe output on the *Premier Bell Module* pulses 3 times, this invokes the Engineer Hold Off mode if a *Texecom Odyssey* bell box is connected

Off: The *Premier Bell Module* and UK options are disabled.

⑤ Enable DD 243:2002 Options

On: The Confirmation output is disabled once the Entry Timer is started, i.e. during the Entry Time, activation of a second (different) zone will NOT activate the Confirmation output.

Off: The Confirmation output operates as normal.



To comply with DD 243:2002 this option must be enabled if access to the protected premises initiates the entry timer.

Owing to the ability to disable ALL of the confirmation facilities, the customer should be advised in writing by the alarm company that ALL means of alarm confirmation are disabled when the initial entry door is opened. The alarm company should then obtain written acceptance from the customer of the disabling of the means of alarm confirmation.

⑥ Enable Confirmation After Entry Time-Out

On: If option 5 (above) is enabled the Confirmation output is ONLY disabled for the duration of the Entry Time and re-enabled once the Entry Timer has expired, i.e. after the Entry Timer has expired, further activation of two different zones WILL activate the Confirmation output.

Off: If option 5 (above) is enabled the Confirmation output remains disabled once the Entry Timer is started.



To comply with DD 243:2004 this option can only be enabled if the system is unset by a single action device such as a Swipe Card, Radio FOB, Infra-Red FOB, Proximity Card etc.

⑦ Invert Auxiliary Input Operation

On: The operation of the auxiliary input is inverted and operates as shown in the table below:

| Inverted | |
|---------------------|--------------------------|
| Function | Operation |
| Aux Tamper | Normally Open |
| Remote Reset | Remove 0V to reset |
| Phone Line Monitor | Remove 0V for Line Fault |
| Audible PA | Normally Open |
| Silent PA | Normally Open |
| Latched Keyswitch | Apply 0V to Arm |
| Momentary Keyswitch | 0V to Removed to change |

Off: The operation of the auxiliary input is inverted and operates as shown in the table below:

| Normal | |
|---------------------|-------------------------|
| Function | Operation |
| Aux Tamper | Normally Closed |
| Remote Reset | Apply 0V to reset |
| Phone Line Monitor | Apply 0V for Line Fault |
| Audible PA | Normally Closed |
| Silent PA | Normally Closed |
| Latched Keyswitch | Apply 0V to Disarm |
| Momentary Keyswitch | Removed to 0V to change |

⑧ Auto BST/GMT Time Change

On: The clock is automatically put forward by one hour on the last Sunday in March at 2.00AM and put back by one hour on last Sunday in October at 2:00AM.

Off: The clock is not adjusted automatically.

Miscellaneous Options 3

(3) (8) - (3)

① Allow User Tamper Reset

On: A User can reset Tamper Alarms.

Off: A User cannot reset Tamper Alarms.

② Allow Engineer Access when Armed

On: An Engineer can access the system when armed.

Off: An Engineer cannot access the system when armed.

EN50131 Options

(3) (9)

The function of each option is described as follows:



NOTE

ALL options listed below, together with Option 6 of menu 35 must be enabled if the system is to comply with EN50131.

① Low Battery FOB Arming

On: An arming fob with a low battery causes a warning to be indicated. The user must be acknowledged the warning before arming can continue.

Off: An arming fob with a low battery arms the system.

② Indicate zone Soak Test active enabled

On: A zone or zones on Soak Test being armed will cause the "Soak Test Warning" to be displayed. The user can then continue to arm the system or return to Day Mode.

Off: The "Soak Test Warning" message is not displayed.

③ Soak Test Acknowledgement enabled

On: Soak Test warnings must be acknowledged by the user.

Off: Soak Test warnings are displayed for 2 seconds before arming continues.

④ Entry Stray Notification Delay

On: Entry stray notification is delayed after the alarm.

Off: Entry stray notification occurs at the time of the alarm.

⑤ Entry Timeout notifies immediately

On: Entry timeout notification is delayed after the alarm.

Off: Entry timeout notification occurs at the time of the alarm.

⑥ Expander Lost

On: A cable cut short circuit on an expander generates a Tamper Alarm.

Off: A cable cut or short circuit on an expander generates a fault condition.



NOTE

When this option is switched on any circuits connected to the expander will go active.

⑦ User Code Entry

NOTE

A user code must be entered in 60 seconds, after every 10 invalid code entry attempts all keypads on the system are locked out for 90 seconds. After 21 invalid code attempts a keypad tamper event will be notified.

On: A user's code must be entered in 60 seconds.


Off: User code validity is by number of characters entered..

⑧ Mains and Battery Failures Latched

On: Mains and Battery Failures are latched and notified and must be acknowledged before the system can be set.

Off: Mains and Battery Failures are only shown when present.

Programming Remote Keypads



Keypad Options 1 ④ ①

The operation of Keypad Options 1 is described as follows:

① Partition 1 Operation

On: The selected keypad is assigned to Partition 1.

Off: The selected keypad is not assigned to Partition 1.

② Partition 2 Operation

On: The selected keypad is assigned to Partition 2.

Off: The selected keypad is not assigned to Partition 2.

③ Partition 3 Operation (Premier 816/832 Only)

On: The selected keypad is assigned to Partition 3.

Off: The selected keypad is not assigned to Partition 3.

④ Partition 4 Operation (Premier 816/832 Only)

On: The selected keypad is assigned to Partition 4.

Off: The selected keypad is not assigned to Partition 4.

⑤ Permanent Keypad Status Display

On: The keypad status will be displayed permanently.

Off: Keypad status (not just zone status) will blank after the courtesy timer has expired.

⑥ Press Any Key for Display

On: If Keypad Option 1.5 (above) is selected as disabled, the selected keypad will re-enable the display after any key press.

Off: The selected keypad display will only re-enable after a valid Access code has been entered.

⑦ Display Zones vs. Partitions

On: The selected keypad will use its zone lights to indicate zone status details.

Off: The selected keypad will use its zone lights to indicate armed status of partitions.

⑧ Wrong Code Attempts Cause Code Tamper

On: The selected keypad will lockout key presses for 5 minutes and will generate a code tamper alarm after 3 incorrect code attempts (12 key presses).

Off: The keypad will accept any amount of incorrect code attempt entries.

Keypad Options 2 ④ ①

The operation of Keypad Options 2 is described as follows:

① Code Tamper Causes a Tamper Alarm

On: If a code tamper is generated by the selected keypad, the system will give a tamper alarm response.

Off: If a code tamper is generated by the selected keypad, the system will lock out the keypad for 5 minutes.



NOTE

Keypad Options 1.8 must also be enabled.

② Keypad Activation of Fire Alarm

On: The selected keypad will generate an emergency Fire alarm if keys ① and ③ are pressed at the same time.

Off: The selected keypad will not generate an emergency Fire alarm.

③ Keypad Activation of Medical Alarm

On: The selected keypad will generate an emergency Medical alarm if keys ⑦ and ⑨ are pressed at the same time.

Off: The selected keypad will not generate an emergency Medical alarm.

④ Keypad Activation of PA Alarm

On: The selected keypad will generate a Panic Alarm (Police) if keys ④ and ⑥ are pressed at the same time.

Off: The selected keypad will not generate an emergency Panic Alarm.

⑤ Keypad PA Alarm is Silent

On: The selected keypad will generate a silent Panic Alarm (Police) if keys ④ and ⑥ are pressed at the same time.

Off: The selected keypad will generate an audible Panic Alarm (Police) if keys ④ and ⑥ are pressed at the same time.



NOTE

Keypad Options 2.4 must also be enabled.

⑥ Quick Arm with Keypad ARM Key

On: The selected keypad can be used to quick arm the system (Access code not required).

Off: An Access code must be entered before the selected keypad can be used to arm the system.

⑦ Quick Disarm with Keypad DISARM Key

On: The selected keypad can be used to quick disarm the system (Access code not required).

Off: An Access code must be entered before the selected keypad can be used to disarm the system.

⑧ Quick Bypass with Keypad BYPASS Key

On: The selected keypad can be used to quick bypass zones (Access code not required).

Off: An Access code must be entered before the selected keypad can be used to bypass zones.

Keypad Options 3 ④ ②

The operation of Keypad Options 3 is described as follows:

① Fire Alarm Tones from Keypad

On: The internal sounder for the selected keypad will produce Fire Alarm tones.

Off: Fire Alarm tones will not be produced.

② Burglary Alarm Tones from Keypad

On: The internal sounder for the selected keypad will produce Burglary Alarm tones.

Off: Burglary Alarm tones will not be produced.

③ Service Tones from Keypad

On: The internal sounder for the selected keypad will produce Service tones.

Off: Service tones will not be produced.

④ Acceptance Tones from Keypad

On: The internal sounder for the selected keypad will produce Acceptance tones.

Off: Acceptance tones will not be produced.

⑤ Error Tones from Keypad

On: The internal sounder for the selected keypad will produce Error tones.

Off: Error tones will not be produced.

⑥ Chime Tones from Keypad

On: The internal sounder for the selected keypad will produce Chime tones.

Off: Chime tones will not be produced.

⑦ Exit Tones from Keypad

On: The internal sounder for the selected keypad will produce Exit tones.

Off: Exit tones will not be produced.

⑧ Entry Tones from Keypad

On: The internal sounder for the selected keypad will produce Entry tones.

Off: Entry tones will not be produced.

Keypad Options 4**④ ③**

The operation of Keypad Options 4 is described as follows:

① Enable Keypad Zones

On: The zones onboard the selected remote keypad are enabled and allocated as follows:

| Keypad | Premier 412 | Premier 816/832 |
|--------|---------------|-----------------|
| 1 | Zones 05 & 06 | Zones 09 & 10 |
| 2 | Zones 07 & 08 | Zones 11 & 12 |
| 3 | Zones 09 & 10 | Zones 13 & 14 |
| 4 | Zones 11 & 12 | Zones 15 & 16 |
| 5 | N/A | N/A |
| 6 | N/A | N/A |

Off: The zones onboard the selected remote keypad are disabled:



This option is only relevant if the keypad type is a *Premier RKP8/16 Plus* or *Premier LCD*.

If the system is fitted with either a local or remote expander, the relevant zones on the expander will be disabled if the zones on the remote keypad are enabled.

② Disable Keypad Lid Tamper

On: The remote keypad lid tamper is not monitored.

Off: The remote keypad lid tamper is monitored.

③ Zone Shift by 4

On: The remote keypad zone status lights indicate from Zone 5 onwards i.e., Zone 1 on the remote keypad follows the status of Zone 5 and Zone 2 on the remote keypad follows the status of Zone 6 etc.

Off: The remote keypad zone status lights indicate as normal.

④ Zone Shift by 8

On: The remote keypad zone status lights indicate from Zone 9 onwards i.e., Zone 1 on the remote keypad follows the status of Zone 9 and Zone 2 on the remote keypad follows the status of Zone 10 etc.

Off: The remote keypad zone status lights indicate as normal.


⑤ Zone Shift by 16

On: The remote keypad zone status lights indicate from Zone 17 onwards i.e., Zone 1 on the remote keypad follows the status of Zone 17 and Zone 2 on the remote keypad follows the status of Zone 18 etc.

Off: The remote keypad zone status lights indicate as normal.




Options 3, 4 and 5 allow the *Premier RKP4* remote keypad to be used on a multi-partition system with more than 4 zones and the *Premier RKP8* remote keypad to be used on a multi-partition system with more than 8 zones. The example below shows how a 16 zone system split into 2 partitions could use two *Premier RKP 8* remote keypads:



Remote Keypad 1 (Partition 1)

Keypad Options 4:

- ③ Zone Shift by 4 (Disabled)
- ④ Zone Shift by 8 (Disabled)
- ⑤ Zone Shift by 16 (Disabled)




Remote Keypad 2 (Partition 2)

Keypad Options 4:

- ③ Zone Shift by 4 (Disabled)
- ④ Zone Shift by 8 (Enabled)
- ⑤ Zone Shift by 16 (Enabled)

Programming Remote Expanders



Expander Partitions (5)(0)

When the expander is assigned to one or more partitions the speaker output on the expander will generate tones only for the partition(s) it's assigned to. E.g. if the expander is assigned to partition 3, the speaker will only be enabled when partition 3 is in alarm, entry, exit etc.

Expander Tones (5)(1)

The Expander Tones are described as follows:

(1) Fire Alarm Tones from Expander

On: The siren output on the Expander will produce Fire Alarm tones.

Off: Fire Alarm tones will not be produced.

(2) Burglary Alarm Tones from Expander

On: The siren output on the Expander will produce Burglary Alarm tones.

Off: Burglary Alarm tones will not be produced.

(3) Service Tones from Expander

On: The siren output on the Expander will produce Service tones.

Off: Service tones will not be produced.

(4) Acceptance Tones from Expander

On: The siren output on the Expander will produce Acceptance tones.

Off: Acceptance tones will not be produced.

(5) Error Tones from Expander

On: The siren output on the Expander will produce Error tones.

Off: Error tones will not be produced.

(6) Chime Tones from Expander

On: The siren output on the Expander will produce Chime tones.

Off: Chime tones will not be produced.

(7) Exit Tones from Expander

On: The siren output on the Expander will produce Exit tones.

Off: Exit tones will not be produced.

(8) Entry Tones from Expander


On: The siren output on the Expander will produce Entry tones.


Off: Entry tones will not be produced.

Expander Volume Level (5)(2)

This option controls the advisory tones (entry/exit, fault etc.) volume level of the speakers connected to the remote expander speaker output. 0 = minimum volume; 7 = maximum volume.

Programming System Outputs





① System Output Types

- 00 Courtesy
- 01 Successful Transmission
- 02 Log 80% Full
- 03 Program Mode Selected
- 04 Download In Progress
- 05 Timed Arming Countdown
- 06 Zone Soak Test Active
- 07 Zone Soak Test Failed
- 08 Latched AC Fail
- 09 Telephone Line Fault
- 10 Smoke Alarm
- 11 Box/Auxiliary Tamper
- 12 Date Time Loss
- 13 Zone Service/Tamper
- 14 Keypad Tamper/Removed
- 15 System Service
- 16 Output 1 Fault
- 17 Output 2 Fault
- 18 Speaker Fault
- 19 Smoke Sensor Fault
- 20 Auxiliary Fuse Fault
- 21 Latched Battery Fault
- 22 Service Required/Test Fail
- 23 Fail To Communicate
- 24 Control Timer 1 Active
- 25 Control Timer 2 Active
- 26 Control Timer 3 Active
- 27 Control Timer 4 Active
- 28 PC Output 1
- 29 PC Output 2
- 30 Walk Test
- 31 Confirmed Alarm
- 32 ARC2 Active
- 33 Zones Locked-Out
- 34 AC Fail
- 35 Battery Fail
- 36 Poll Timer

② Partition Output Types

- 00 PA Alarm
- 01 Duress Alarm
- 02 Burglar Alarm
- 03 Medical Alarm
- 04 24Hr - Water Alarm
- 05 24Hr - Gas Alarm
- 06 24Hr - Low Temp Alarm
- 07 24Hr - High Temp Alarm
- 08 Tamper
- 09 Service
- 10 Fire
- 11 Trouble/Tamper
- 12 Bell
- 13 Strobe
- 14 Entry
- 15 Exit
- 16 Armed
- 17 Stay Armed
- 18 Ready
- 19 Bypass
- 20 Sensor Reset on Exit
- 21 Sensor Reset on Reset
- 22 Single Pulse on Arming
- 23 Double Pulse on Arming
- 24 Chime
- 25 Door Strike
- 26 Cross Zone Time Active
- 27 Single Pulse on Disarming
- 28 Reset Required
- 29 Acknowledgement Required
- 30 Confirmed Alarm
- 31 Alarm Abort
- 32 Away Armed
- 33 Away Armed/Exit
- 34 Detector Latch
- 35 Armed/Alarm
- 36 Arm Failed
- 37 All Armed

③ Zone Output Types

- 01 Zone 01 Mimic
- 02 Zone 02 Mimic
- 03 Zone 03 Mimic
- 04 Zone 04 Mimic
- 05 Zone 05 Mimic
- 06 Zone 06 Mimic
- 07 Zone 07 Mimic
- 08 Zone 08 Mimic
- 09 Zone 09 Mimic
- 10 Zone 10 Mimic
- 11 Zone 11 Mimic
- 12 Zone 12 Mimic
- 13 Zone 13 Mimic
- 14 Zone 14 Mimic
- 15 Zone 15 Mimic
- 16 Zone 16 Mimic
- 17 Zone 17 Mimic
- 18 Zone 18 Mimic
- 19 Zone 19 Mimic
- 20 Zone 20 Mimic
- 21 Zone 21 Mimic
- 22 Zone 22 Mimic
- 23 Zone 23 Mimic
- 24 Zone 24 Mimic
- 25 Zone 25 Mimic
- 26 Zone 26 Mimic
- 27 Zone 27 Mimic
- 28 Zone 28 Mimic
- 29 Zone 29 Mimic
- 30 Zone 30 Mimic
- 31 Zone 31 Mimic
- 32 Zone 32 Mimic
- 33 Zone 01 Alarm
- 34 Zone 02 Alarm
- 35 Zone 03 Alarm
- 36 Zone 04 Alarm
- 37 Zone 05 Alarm
- 38 Zone 06 Alarm
- 39 Zone 07 Alarm
- 40 Zone 08 Alarm
- 41 Zone 09 Alarm
- 42 Zone 10 Alarm
- 43 Zone 11 Alarm
- 44 Zone 12 Alarm
- 45 Zone 13 Alarm
- 46 Zone 14 Alarm
- 47 Zone 15 Alarm
- 48 Zone 16 Alarm
- 49 Zone 17 Alarm
- 50 Zone 18 Alarm
- 51 Zone 19 Alarm
- 52 Zone 20 Alarm
- 53 Zone 21 Alarm
- 54 Zone 22 Alarm
- 55 Zone 23 Alarm
- 56 Zone 24 Alarm
- 57 Zone 25 Alarm
- 58 Zone 26 Alarm
- 59 Zone 27 Alarm
- 60 Zone 28 Alarm
- 61 Zone 29 Alarm
- 62 Zone 30 Alarm
- 63 Zone 31 Alarm
- 64 Zone 32 Alarm

Panel Outputs (6)(0)

This menu option allows you to program the eight control panel outputs.

Fast Format/Speech Channels (6)(1)

When using the Fast Format communication protocol (see page 53) the channels that are reported to the Alarm Receiving Centre must be programmed for the relevant conditions. This menu option allows you to program the eight channels that are used by the Fast Format protocol.

Expander 1 Outputs (6)(2)

The *Premier 8X* remote expander has two programmable outputs. This menu option allows you to program the outputs of expander 1.

Expander 2 Outputs (6)(3)

The *Premier 8X* remote expander has two programmable outputs. This menu option allows you to program the outputs of expander 2 (*Premier 832 Only*).

Expander 3 Outputs (6)(4)

The *Premier 8X* remote expander has two programmable outputs. This menu option allows you to program the outputs of expander 3 (*Premier 832 Only*).

Keypad Outputs (6)(5)

Both the *Premier LCD* and *LCDL* remote keypads have a programmable output. This menu option allows you to program the keypad outputs.

Output Groups and Types

Group (0) - Not Used

This group contains no output types, by assigning an output to this group the output will never activate.

Group (1) - System Output Types

This group contains the system output types as listed below:

(0)(0) Courtesy

This output type activates after any keypad has been used and during entry delay. The output will remain active for the duration of the Courtesy timer (see page 36).

(0)(1) Successful Transmission

This output type activates after the communicator has successfully reported to the alarm receiving centre.

(0)(2) Log 80% Full

This output type activates when the Event Log is 80% full. The output is cleared when the event log is uploaded by the remote downloading computer.

(0)(3) Program Mode Selected

This output type activates when the program mode is selected.

(0)(4) Download in Progress

This output type activates when a Download is in progress.

(0)(5) Timed Arming Countdown

This output type activates when the system initiates a timed arm.

(0)(6) Zone Soak Test Active

This output type activates when any zone is enabled for soak test.

(0)(7) Zone Soak Test Failed

This output type activates if any zone fails during a zone soak test.

(0)(8) Latched AC Fail

This output type activates when the mains supply is disconnected.

(0)(9) Telephone Line Fault

This output type activates when the communicator detects a telephone line fault.

(1)(0) Smoke Alarm

This output type activates when a 2-wire smoke detector connected to Panel Output 1 causes an alarm.

(1)(1) Box/Auxiliary Tamper Alarm

This output type activates when the box tamper or the Auxiliary Input (Tamper) on the main panel causes an alarm.

(1)(2) Date/Time Loss

This output type activates when the control panel real time clock is reset (power up). The output clears when the clock is set.

(1)(3) Zone Trouble/Tamper

This output type activates when any zone is in trouble or tamper.

(1)(4) Keypad Tamper/Removed

This output type activates when a keypad is either disconnected or its box tamper causes an alarm.

(1)(5) Service Fault

This output type activates when there are any Service Faults on the system (mimics the Service light on the remote keypad).

(1)(6) Output 1 Fault

This output type activates when Panel Output 1 detects a fault.

(1)(7) Output 2 Fault

This output type activates when Panel Output 2 detects a fault.

(1)(8) Siren/Bell Fault

This output type activates when Siren Output detects a fault.

(1)(9) Smoke Sensor Fault

This output type activates when a 2-wire smoke detector connected to Panel Output 1 causes a fault.

(2)(0) Auxiliary Fuse Fault

This output type activates when the Auxiliary fuse is ruptured.

(2)(1) Latched Battery Fault

This output type activates when the system detects a fault from the stand-by battery.

(2)(2) Service Required/Test Fail

This output type activates when a Service Required fault exists or the system has failed zone soak test.

(2)(3) Fail to Communicate

This output type activates after the communicator has failed to report to the alarm receiving centre.

(2)(4) Control Timer 1 Active

This output type activates when Control Timer 1 is active.

(2)(5) Control Timer 2 Active

This output type activates when Control Timer 2 is active.

(2)(6) Control Timer 3 Active

This output type activates when Control Timer 3 is active.

(2)(7) Control Timer 4 Active

This output type activates when Control Timer 4 is active.

(2)(8) PC Output 1

The remote Downloading computer controls this output type.

(2)(9) PC Output 2

The remote Downloading computer controls this output type.

③① Walk Test

This output type activates when the user selects the Zone Test option (menu 90).

③① Confirmed Alarm

This output type activates when two different zones are violated from any armed partition.

③② ARC 2 Active

This output type activates when the panel is communicating to ARC2.

③③ Zone Locked-Out

This output type activates when the one or more zones are locked out after the confirmation timer has expired.

③④ AC Fail

This output type activates when the mains supply is disconnected.

③⑤ Battery Fault

This output type activates when the system detects a fault from the stand-by battery.

③⑥ Poll Timer

This output is linked to the Global System Timer 14 "Poll IP Every" in minutes. Thus if this timer is programmed with a non-zero value, when the timer times out, this new output "Poll Timer" will activate for 10 seconds and then reset. This cycle will repeat every time the "Poll IP Every" timer expires.

Group ② - Partition Output Types

This group contains the partition output types as listed below:

①① PA Alarm

This output type activates when a PA alarm is generated in the selected Partition. If another PA alarm is generated the output will reset for 3 seconds then reactivate.

①① Duress Alarm

This output type activates when a Duress alarm is generated in the selected Partition. If another Duress alarm is generated the output will reset for 3 seconds then reactivate.

①② Burglar Alarm

This output type activates when a Burglar alarm is generated in the selected Partition. If another Burglar alarm is generated the output will reset for 3 seconds then reactivate.

①③ Medical Alarm

This output type activates when a Medical alarm is generated in the selected Partition. If another Medical alarm is generated the output will reset for 3 seconds then reactivate.

①④ 24Hr - Water Alarm

This output type activates when a 24hr Water alarm is generated in the selected Partition. If another 24hr Water alarm is generated the output will reset for 3 seconds then reactivate.

①⑤ 24Hr - Gas Alarm

This output type activates when a 24hr Gas alarm is generated in the selected Partition. If another 24hr Gas alarm is generated the output will reset for 3 seconds then reactivate.

①⑥ 24Hr - Low Temp Alarm

This output type activates when a 24hr Low Temperature alarm is generated in the selected Partition. If another 24hr Low Temperature alarm is generated the output will reset for 3 seconds then reactivate.

①⑦ 24Hr - High Temp Alarm

This output type activates when a 24hr High Temperature alarm is generated in the selected Partition. If another 24hr High Temperature alarm is generated the output will reset for 3 seconds then reactivate.

①⑧ Tamper

This output type activates when a Tamper alarm is generated in the selected Partition. If another Tamper alarm is generated the output will reset for 3 seconds then reactivate.

①⑨ Trouble

This output type activates when a Trouble alarm is generated in the selected Partition. If another Trouble alarm is generated the output will reset for 3 seconds then reactivate.

①① Fire

This output type activates when a Fire alarm is generated in the selected Partition. If another Fire alarm is generated the output will reset for 3 seconds then reactivate.

①① Trouble/Tamper

This output type activates when a Trouble or Tamper alarm is generated in the selected Partition.

①② Bell

This output type activates when an alarm is generated in the selected Partition.

①③ Strobe

This output type activates when an alarm is generated in the selected Partition.

①④ Entry

This output type activates when the selected Partition is in entry mode.

①⑤ Exit

This output type activates when the selected Partition is in exit mode.

①⑥ Armed

This output type activates when the selected Partition is stay or away armed.

①⑦ Stay Armed

This output type activates when the selected Partition is stay armed.

①⑧ Ready

This output type activates when the selected Partition is ready for arming.

①⑨ Bypass

This output type activates when the selected Partition has one or more zones bypassed.

②① Sensor Reset on Exit

This output type is normally active and deactivates for 2 seconds when the selected Partition is in exit mode.

②① Sensor Reset on Reset

This output type is normally active and deactivates for 2 seconds when the user resets the selected Partition.

②② Single Pulse on Arming

This output type activates for 2 seconds when the selected Partition is armed.

②③ Double Pulse on Arming

This output type activates twice (2 seconds on) when the selected Partition is armed.

②④ Chime

This output type activates for 2 seconds when a zone programmed as Chime is violated in the selected Partition.

②⑤ Door Strike

This output type activates for 2 seconds when an Access code with the "Activate Door Strike Output" attribute is entered.

②⑥ Cross Zone Time Active

This output type activates when a Cross Zone is violated and remains active for the duration of the Cross Zone Time Window.

②⑦ Single Pulse on Disarming

This output type activates for 2 seconds when the selected Partition is disarmed.

②⑧ Reset Required

This output type activates when an alarm condition requires resetting in the selected Partition.

②⑨ Acknowledgement Required

This output type activates when a Service Fault requires acknowledgement.

③① Confirmed Alarm

This output type activates when two different zones are violated during an armed period.

③① Alarm Abort

This output type activates when the system is disarmed after an alarm condition (providing the system is disarmed before the "Alarm Transmission Abort" delay has expired, see page 35).

③② Away Armed

This output type activates when the partition is "Away Armed".

③③ Away Armed/Exit

This output type activates when the partition is in exit mode (Away arming) and when the partition is "Away Armed".

③④ Detector Latch

This output type is used to latch an alarm condition on detectors that have a latch input.

③⑤ Armed/Alarm

This output type is used to indicate both the armed and alarm status of a partition, it operates as follows: on = armed; off = disarmed; pulsing = alarm.

③⑥ Arm Failed

This output type activates when the selected partition fails to arm.

③⑦ All Armed

This output activates when all selected partitions are armed. It resets when any of the selected partitions is disarmed.

Group ③ Zone Output Types

This group contains the zone output types as listed below:

③① - ③② Zone 01 - 32 Mimic

This output type activates when Zone XX is violated and deactivates when the zone is secure.

③③ - ③④ Zone 01 - 32 Alarm

This output type activates when Zone XX causes an alarm and deactivates when the alarm is reset.

Output Attributes

Each output can have the following attributes assigned to alter the function of the selected output:

① Enable for Partition 1

On: The selected output is assigned to Partition 1.

Off: The selected output is not assigned to Partition 1.

② Enable for Partition 2

On: The selected output is assigned to Partition 2.

Off: The selected output is not assigned to Partition 2.

③ Enable for Partition 3 (Premier 816/832 Only)

On: The selected output is assigned to Partition 3.

Off: The selected output is not assigned to Partition 3.

④ Enable for Partition 4 (Premier 816/832 Only)

On: The selected output is assigned to Partition 4.

Off: The selected output is not assigned to Partition 4.

⑤ Enable for User Test

On: The selected output is activated during a user test.

Off: The selected output is not activated during a user test.

⑥ Inverted

On: The selected output is inverted.

Off: The selected output is normal.

⑦ Latching

On: The selected output will latch on until the system is reset.


Off: The selected output will not latch.

⑧ Pulsed


On: The selected output will pulse for the duration of the Output Short Pulse Timer (see page 35).

Off: The selected output will be normal.

Programming the Communicator



From
Previous Page

**Protocol Types**

- (0) Disabled
- (1) Pulse Format
- (2) Express Format
- (3) Fast Format/Speech Module
- (4) Contact ID
- (5) SIA Level 2/3
- (6) Pager Format
- (7) Mobile Phone

Note

Reporting Partitions are only used by the following protocol types:
Pulse Format
Express Format
Contact ID
SIA Level 2/3
Pager Format

Reporting Events

- (1) Report Priority Alarm and Cancel Events
- (2) Report Alarm and Cancel Events
- (3) Report Open and Close Events
- (4) Report Bypass and Unbypass Events
- (5) Report Maintenance Alarm Events
- (6) Report Tamper Alarm Events
- (7) Report Test Transmission Events
- (8) Report Restore Events

Pulse Format Options


- (1) Use 1900Hz Carrier
- (2) Use 40 PPS Baud Rate
- (3) Enable Parity
- (4) Use 2 Digit Events
- (5) Use 2300Hz Handshake
- (6) Use 2300Hz Kiss-Off
- (7) Use Fast/Slow Format

Fast Format Reporting

- (1) Report Channel 1
- (2) Report Channel 2
- (3) Report Channel 3
- (4) Report Channel 4
- (5) Report Channel 5
- (6) Report Channel 6
- (7) Report Channel 7
- (8) Report Channel 8

Protocol Options

- (1) Disable SIA Modifier/Enable Speech Module
- (2) Disable Separate Events for Each Partition
- (3) Pager Terminator = * (Star)
- (4) Send Pager Terminator Twice/SIA Text
- (5) Pager DTMF Tones = 500mS
- (6) Disable Zone Restorals
- (7) Coms. Acknowledgement Tone
- (8) Connect via IP



Communicator Options ⑦ ①

The on-board digital communicator/modem has the following options:

① Enable On-Board Communicator

On: The on-board digital communicator will report system events to the Alarm Receiving Centre.

Off: The communicator will not report system events.

② Enable DTMF Dialling

On: The on-board digital communicator will dial using DTMF (Dual Tone Multiple Frequency) format.

Off: The communicator will dial using the older pulse format.

③ Switch to Pulse Dialling After 3rd Attempt

On: The communicator will switch to the pulse dialling format after failed 3rd attempt.

Off: The communicator will always dial using DTMF format.



NOTE Only applicable if Communicator Option 2 is enabled.

④ Enable European Pulse Dialling

On: The communicator will dial using the European pulse dialling timing ratios.

Off: The communicator will dial using US pulse dialling ratios.



NOTE Only applicable if Communicator Option 2 is disabled.

⑤ Enable Auto Test Transmission

On: The communicator will send a periodic test transmission to the Alarm Receiving Centre. See page 35 to alter the Test Transmission Interval

Off: The communicator will not send test transmissions.

⑥ Enable Cancel Call Waiting

On: The communicator will dial the Cancel Call Waiting sequence before dialling the monitoring station.

Off: The communicator will not dial the Cancel Call Waiting sequence.

⑦ Enable Backup to Alarm Receiving Centre

On: The communicator will always report to Alarm Receiving Centre 1, then make a backup report to Alarm Receiving Centre 2.

Off: The communicator will initially attempt to report to Alarm Receiving Centre 1. If for any reason the communicator fails after using all its attempts, the communicator will attempt to report to Alarm Receiving Centre 2.

⑧ Enable Blind Dialling

On: The communicator will NOT look for a dial tone before dialling the telephone number.

Off: The communicator will wait for the dial tone before attempting to dial out.

ARC 1 Communicator Menu ⑦ ①

The ARC 1 Communicator Menu has the following options:

① Primary and Secondary Telephone Numbers

② Account Numbers

③ Protocol Type

④ Dial Attempts

⑤ Partition Options

⑥ Reporting Options

⑦ Pulse Format Options

⑧ Fast Format Reporting Channels

⑨ Protocol Options

Telephone Numbers ⑦ ① - ①

Alarm Receiving Centre 1 has a primary and secondary telephone number. The primary number is the number that is dialled first and if programmed the secondary telephone number is a backup number for the primary number. If both numbers are programmed the panel will alternate between them when dialling the alarm receiving centre.

Each telephone number can be up to 24 digits. When entering the telephone number the following keys can be used:

- Press** **1** to insert a “*”.
- Press** **2** to insert a “#”.
- Press** **3** to insert a “,” (3 second pause).
- Press** **4** to insert a “W” (10 second pause).
- Press** **5** to insert a “D” (Wait for dial tone).
- Press** **6** to insert a “+” (Force dials next number).

Account Numbers

7 1 - 1

Alarm Receiving Centre 1 has four account numbers. Account No 1 is for partition 1 and is also the global account number. Account numbers 2 - 4 are for partitions 2 - 4. To send events on separate account numbers, you must ensure the “Disable Separate Events for Each Partition” is turned off (see Protocol Options on page 55). The account number can be up to 6 digits. Separate partition account numbers can be selected by pressing the key. When entering the account number the following keys can be used to insert hexadecimal characters:

- Press** **1** to insert a “B”.
- Press** **2** to insert a “C”.
- Press** **3** to insert a “D”.
- Press** **4** to insert a “E”.
- Press** **5** to insert a “F”.
- Press** **6** to insert a “A”.

Protocol Type

7 1 - 2

This is the reporting protocol that is used to communicate with Alarm Receiving Centre 1. The following protocols are supported:

- 0 Disabled**
Communication disabled.

- 1 Pulse Format**
The panel will communicate with Alarm Receiving Centre 1 using Pulse Format. See page 62 for details on configuring reporting codes.

- 2 Express Format**
The panel will communicate with Alarm Receiving Centre 1 using Express Format. See page 62 for details on configuring reporting codes.

- 3 Fast Format/Speech Module**
The panel will communicate with Alarm Receiving Centre 1 using Fast Format protocol. If the “Enable Speech Module” option is enabled in the Protocol Options (see page 55) the panel will use the plug-on *Speech Module* to communicate the alarm information. The Fast Format/Speech channels must be programmed to the required to type, see Program Outputs on page 47.

- 4 Contact ID**
The panel will communicate with Alarm Receiving Centre 1 using Contact ID. The defaults Contact ID codes are shown in the standard defaults worksheets from page 86.

- 5 SIA Level 2/3**
The panel will communicate with Alarm Receiving Centre 1 using SIA Level 2. If the “Send SIA Text” option is enabled, the panel will communicate using SIA level 3. The defaults SIA codes are shown in defaults worksheets from page 86.

6 Pager

The panel will communicate to a pager. When using the pager option the panel transmits the data to the pager using the following format:

Pager Format = AAAAAA EE

| | |
|---------------|---|
| AAAAAA | 4 - 6 digit account number |
| EE | Event Code |
| | This code is the same code used for Pulse formats (see page 62) |

If for example the account number for the site was programmed as 1234 and zone 8 was violated and caused a burglar alarm, the pager would display 1234 38.



When using the pager option the telephone number will require a pause after it to make it work properly, see Telephone Numbers above.

When using the pager option the pager is normally terminated using either a * or #. This is programmable see Protocol Options on page 55.

The dial attempts when using the pager option should be programmed to 1, see Dial Attempts on page 53.

The panel has no way of confirming if the pager was called successfully which means a “Communication Failure” fault will never be generated.

The panel will only report the event groups that are selected in the Reporting Options, see page 54.

7 Mobile Phone

This protocol can be used to communicate with standard or mobile phones. When an alarm is activated the panel will dial the programmed telephone number and play a number of “bleeps”, which is repeated 10 times, after which the panel will hang-up.

The number of bleeps corresponds to the pulse format code for the selected event, e.g., if the pulse code for zone 4 alarm is programmed as “4” the panel will play 4 “bleeps”. See page 62 for details on configuring reporting codes.

Dial Attempts

7 1 - 3

This is the number of times the panel will attempt to communicate with Alarm Receiving Centre 1.



The maximum number of repeat dialling attempts is limited to 9. The system will only allow you to enter values between 0 and 9. Setting the value to 0 will disable the communicator for ARC 1.

Partition Options

7 1 - 4

The Partition Options are described as follows:

- 1 Report for Partition 1**
On: The system will report events for Partition 1 to Alarm Receiving Centre 1.
Off: The system will not report events for Partition 1.
- 2 Report for Partition 2**
On: The system will report events for Partition 2 to Alarm Receiving Centre 1.
Off: The system will not report events for Partition 2.

③ Report for Partition 3 (Premier 816/832 Only)

On: The system will report events for Partition 3 to Alarm Receiving Centre 1.

Off: The system will not report events for Partition 3.

④ Report for Partition 4 (Premier 816/832 Only)

On: The system will report events for Partition 4 to Alarm Receiving Centre 1.

Off: The system will not report events for Partition 4.

Reporting Options**⑦ ① - ⑤**

The Reporting Options are described as follows:

① Report Priority Alarm and Cancel Events

On: Priority alarm and cancel events are reported to ARC1.

Off: Priority alarms and cancel events are not reported.

② Report Alarm and Cancel Events

On: Alarm and cancel events are reported to ARC1.

Off: Alarm and cancel events are not reported.

③ Report Open and Close Events

On: Open and close events are reported to ARC1.

Off: Open and close events are not reported.

④ Report Bypass and Unbypass Events

On: Bypass and unbypass events are reported to ARC1.

Off: Bypass and unbypass events are not reported.

⑤ Report Maintenance Alarm Events

On: Maintenance alarm events are reported to ARC1.

Off: Maintenance alarm events are not reported.

⑥ Report Tamper Alarm Events

On: Tamper alarm events are reported to ARC1.

Off: Tamper alarm events are not reported.

⑦ Report Test Transmission Events

On: Test transmission events are reported to ARC1.

Off: Test transmission events are not reported.

⑧ Report Restore Events

On: Restore events are reported to ARC1.

Off: Restore events are not reported.

Pulse Format Options**⑦ ① - ⑥**

If ARC 1 protocol is programmed for "Pulse Format", the pulse format protocol can be changed using this menu option. The following options are available:

① Use 1900Hz Carrier

On: Pulse Format carrier frequency is set to 1900Hz.

Off: Pulse Format carrier frequency is set to 1800Hz.

② Use 40 PPS Baud Rate

On: Pulse Format baud rate is set to 40 pulses per second.

Off: Pulse Format baud rate is set to 20 pulses per second.

③ Enable Parity

On: Pulse Format uses parity.

Off: Pulse Format doesn't use parity.

④ Use 2 Digit Events

On: Pulse/Express Format uses 2 digits (3 + 2 or 4 + 2).

Off: Pulse/Express Format uses 1 digit (3 + 1 or 4 + 1).

⑤ Use 2300Hz Handshake

On: Pulse Format uses 2300Hz handshake.

Off: Pulse Format uses 1400Hz handshake.

⑥ Use 2300Hz Kiss-Off Frequency

On: Pulse Format uses 2300Hz kiss-off.

Off: Pulse Format uses 1400Hz kiss-off.

⑦ Use Fast/Slow Format

On: Pulse Format uses 10 PPS.

Off: Pulse Format uses either 20 or 40 PPS as defined by option 2 (Use 40 PPS Baud Rate).

The table below shows how to configure some of the common protocols:

| Protocol | Zone Lights | | | | | | |
|----------------------------|-------------|---|---|---|---|---|---|
| | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
| Ademco Slow 3x1/4x1 | - | - | - | - | - | - | ✓ |
| Ademco Slow 3x2/4x2 | - | - | - | ✓ | - | - | ✓ |
| Ademco Fast 3x1/4x1 | - | - | - | - | - | - | - |
| Ademco Fast 3x2/4x2 | - | - | - | ✓ | - | - | - |
| Silent Knight Fast 3x1/4x1 | ✓ | - | - | - | - | - | - |
| Silent Knight Fast 3x2/4x2 | ✓ | - | - | ✓ | - | - | - |
| FBI (No Parity) 3x1/4x1 | ✓ | - | - | - | - | - | - |
| FBI (Parity) 3x1/4x1 | ✓ | - | ✓ | - | - | - | - |
| Franklin 3x1/4x1 | - | - | - | - | ✓ | ✓ | - |
| Franklin 3x2/4x2 | - | - | - | ✓ | ✓ | ✓ | - |
| Radionics 3x1/4x1 | - | ✓ | - | - | ✓ | ✓ | - |
| Radionics (Parity) 3x1/4x1 | - | ✓ | ✓ | - | ✓ | ✓ | - |
| Radionics 3x2/4x2 | - | ✓ | - | ✓ | ✓ | ✓ | - |
| Radionics (Parity) 3x2/4x2 | - | ✓ | ✓ | ✓ | ✓ | ✓ | - |
| Sescoa | ✓ | - | - | - | - | - | - |
| Sescoa Super Fast | - | - | ✓ | - | - | - | - |

✓ ✓ = Zone Light On

Fast Format/Speech Reporting Channels**⑦ ① - ⑦**

This option defines which channels are reported to Alarm Receiving Centre 1 when using the Fast Format communication protocol (see page 53).

① Report Fast Format/Speech Channel 1

On: Channel 1 is reported.

Off: Channel 1 is not reported.

② Report Fast Format/Speech Channel 2

On: Channel 2 is reported.

Off: Channel 2 is not reported.

③ Report Fast Format/Speech Channel 3

On: Channel 3 is reported.

Off: Channel 3 is not reported.

④ Report Fast Format/Speech Channel 4

On: Channel 4 is reported.

Off: Channel 4 is not reported.

⑤ Report Fast Format Channel 5

On: Channel 5 is reported.

Off: Channel 5 is not reported.

⑥ Report Fast Format Channel 6

On: Channel 6 is reported.

Off: Channel 6 is not reported.

⑦ Report Fast Format Channel 7

On: Channel 7 is reported.

Off: Channel 7 is not reported.

⑧ Report Fast Format Channel 8

On: Channel 8 is reported.

Off: Channel 8 is not reported.



The channel must also be programmed to report an event, see "Program Outputs" on page 45.

Protocol Options**⑦ ① ⑧**

This menu option allows you to alter the operation of certain protocol types. The Protocol Options are described as follows:

① Disable SIA Modifier Block/Enable Speech Module

On: When using SIA protocol, the area/partition modifier data block (ri) is not transmitted. When using Fast Format protocol the *Speech Module* is enabled.

Off: When using SIA protocol, the area/partition modifier data block (ri) is transmitted. When using Fast Format protocol the *Speech Module* is disabled.

② Disable Separate Events for Each Partition

On: The panel will communicate as follows:

- If the event occurs in single partition, the panel will report the event using the appropriate account number for the partition.
- If the event occurs in multiple partitions, the panel will report the event using the appropriate account number for the lowest partition, e.g., if the event occurs in partitions 2, 3 and 4, the panel will report the event for partition 2.
- If the account number is not programmed for partitions 2, 3 and 4, the global (partition 1) account number is used.

Off: The panel will communicate as follows:

- If the event occurs in single partition, the panel will report the event using the appropriate account number for the partition.
- If the event occurs in multiple partitions, the panel will report a separate event for each partition using the appropriate account numbers. E.g., if the event occurs in

partitions 1 and 3, the panel will report the event for partition 1 using the account number for partition 1, then it will report the event for partition 2 using the account number for partition 2.

- If the account number is not programmed for partitions 2, 3 and 4, the global (partition 1) account number is used.

③ Pager Terminator = * (Star)

On: When using the pager format, the panel transmits a * (star) to terminate the pager call.

Off: When using the pager format, the panel transmits a # (hash) to terminate the pager call.

④ Send Pager Terminator Twice/SIA Text

On: When using the pager format, the panel transmits the pager terminator (* or #) twice to terminate the pager call. If SIA protocol is enabled, the panel will send zone/user text for relevant events (SIA level 3).

Off: When using the pager format, the panel transmits the pager terminator (* or #) once to terminate the pager call. If SIA protocol is enabled, the panel does not send zone/user text for relevant events (SIA level 2).

⑤ Pager DTMF Tones = 500ms

On: When using the pager format, the panel transmits the pager DTMF tones with an on time of 500ms.

Off: When using the pager format, the panel transmits the pager DTMF tones with an on time of 80ms.

⑥ Disable Zone Restorals

On: Zone restore events are not sent to the Alarm Receiving Centre (even if Report Restore Events are enabled, see page 54).

Off: Zone restore events are sent to the Alarm Receiving Centre 1 (providing Report Restore Events are enabled, see page 54).

⑦ Communication Acknowledgment Tone

On: After a successful communication with the alarm receiving centre the keypads and panel speaker will generate an acknowledgment tone.

Off: After a successful communication the system will remain silent.

⑧ Send via IP

On: Alarm events are sent to the ARC via the *ComIP* module (TCP/IP). Only Fast Format, Contact ID and SIA protocols are supported with this option.

Off: Alarm events are not sent via the *ComIP* module.

ARC 2 Communicator Options**⑦ ②**

This option allows the on-board communicator to be configured for Alarm Receiving Centre 2. The same options are available as for the ARC 1 communicator options (see above).

Fast Format/Speech Restore Channels**⑦ ③**

If either ARC 1 or ARC 2 protocols are programmed as "Fast Format (UK)", the channels that report a restore event to the Alarm Receiving Centre may be selected.

① Report Restore on Channel 1

On: Restore reported on channel 1.

Off: Restore not reported on channel 1.

② Report Restore on Channel 2

On: Restore reported on channel 2.

Off: Restore not reported on channel 2.

③ Report Restore on Channel 3

On: Restore reported on channel 3.

Off: Restore not reported on channel 3.

④ Report Restore on Channel 4

On: Restore reported on channel 4.

Off: Restore not reported on channel 4.

⑤ Report Restore on Channel 5

On: Restore reported on channel 5.

Off: Restore not reported on channel 5.

⑥ Report Restore on Channel 6

On: Restore reported on channel 6.

Off: Restore not reported on channel 6.

⑦ Report Restore on Channel 7

On: Restore reported on channel 7.

Off: Restore not reported on channel 7.

⑧ Report Restore on Channel 8

On: Restore reported on channel 8.

Off: Restore not reported on channel 8.



NOTE The channel must also be programmed to report an event, see "Program Outputs" on page 45.

The channel must also be programmed to report to the ARC, see "Fast Format Reporting Channels" on page 54.



NOTE The channel must also be programmed to report an event, see Program Outputs on page 45.



The channel must also be programmed to report to the ARC, see "Fast Format Reporting Channels" on page 54.

Cancel Call Waiting Sequence**⑦ ⑤**

This is the number that the panel dials to disable Call Waiting. The number can be up to 24 digits. The Cancel Call Waiting option must also be enabled, see Communicator Options on page 52.

Fast Format Open/Close Channels **⑦ ④**

If either ARC 1 or ARC 2 protocols are programmed as "Fast Format (UK)", the channels that report an Open/Close event to the Alarm Receiving Centre may be selected.

① Report Open/Close on Channel 1

On: Open/Close reported on channel 1.

Off: Open/Close not reported on channel 1.

② Report Open/Close on Channel 2

On: Open/Close reported on channel 2.

Off: Open/Close not reported on channel 2.

③ Report Open/Close on Channel 3

On: Open/Close reported on channel 3.

Off: Open/Close not reported on channel 3.

④ Report Open/Close on Channel 4

On: Open/Close reported on channel 4.

Off: Open/Close not reported on channel 4.

⑤ Report Open/Close on Channel 5

On: Open/Close reported on channel 5.

Off: Open/Close not reported on channel 5.

⑥ Report Open/Close on Channel 6

On: Open/Close reported on channel 6.

Off: Open/Close not reported on channel 6.

⑦ Report Open/Close on Channel 7

On: Open/Close reported on channel 7.

Off: Open/Close not reported on channel 7.

⑧ Report Open/Close on Channel 8

On: Open/Close reported on channel 8.

Off: Open/Close not reported on channel 8.

Programming Check List

The table below provides a checklist of what options require programming for each of the protocols supported:

| Protocol | 0 - Telephone No | 1 - Account No | 2 - Protocol Type | 3 - Dial Attempts | 4 - Partition Options | 5 - Reporting Options | 6 - Pulse Format Options | 7 - Fast Format Channels | 8 - Protocol Options | 73 - Fast Format Restore Channels | 74 - Fast Format Open/Close Channels | Notes |
|----------------|------------------|----------------|-------------------|-------------------|-----------------------|-----------------------|--------------------------|--------------------------|----------------------|-----------------------------------|--------------------------------------|--|
| Pulse Format | ✓✓ | ✓✓ | ✓✓ 1 | ✓✓ | ✓✓ | ✓✓ | ✓ 2 | | ✓ 3 | | | 1. Program to type 1. 2. Use table on page 54. 3. Set option 6 as required. |
| Express Format | ✓✓ | ✓✓ | ✓✓ 1 | ✓✓ | ✓✓ | ✓✓ | ✓ 2 | | ✓ 3 | | | 1. Program to type 2. 2. Enable option 4 if 2 digit format is required. 3. Set option 6 as required. |
| Fast Format | ✓✓ | ✓✓ | ✓✓ 1 | ✓✓ | | | | ✓✓ 2 | | ✓✓ 3 | ✓✓ 4 | 1. Program to type 3. 2. Select channels that are required to report. Also program the channels for the relevant type, see page 47. 3. Select channels that require a restore to be reported. 4. Select channels that require to report Open/Close. |
| Speech Module | ✓✓ | | ✓✓ 1 | ✓✓ | | | | ✓✓ 2 | ✓✓ 3 | | | 1. Program to type 3. 2. Select channels 1 and/or 2,3 & 4. Also program the channels for the relevant type, see page 47. 3. Enable option 1. |
| Contact ID | ✓✓ | ✓ | ✓✓ 1 | ✓✓ | ✓✓ | ✓✓ | | | ✓✓ 2 | | | 1. Program to type 4. 2. Set options 2 and 6 as required. |
| SIA Level 2 | ✓✓ | ✓ | ✓✓ 1 | ✓✓ | ✓✓ | ✓✓ | | | ✓✓ 2 | | | 1. Program to type 5. 2. Set options 1, 2 and 6 as required. |
| SIA Level 3 | ✓✓ | ✓ | ✓✓ 1 | ✓✓ | ✓✓ | ✓✓ | | | ✓✓ 2 | | | 1. Program to type 5. 2. Set options 1, 2 and 6 as required. Enable option 4. |
| Pager | ✓✓ | ✓ | ✓✓ 1 | ✓✓ | ✓✓ | ✓✓ | | | ✓✓ 2 | | | 1. Program to type 6. 2. Set options 3, 4, 5 and 6 as required. |
| Mobile Phone | ✓✓ | ✓ | ✓✓ 1 | ✓✓ | ✓✓ | ✓✓ | | | ✓✓ 2 | | | 1. Program to type 7. 2. Set option 6 as required. |

Programming Download Options


Enter Engineers code
 (?) (?) (?) (?)
 Then press then (9)

Programming Menu
 Enter Code > ??

Note

Only Engineer codes that have the "Allow NVM Locking/Communicator Programming" option are allowed to access menus 70 - 79.

Led Key
 Off
 On
 Slow Flash
 Fast Flash




Download Options

- (1) Enable Attended Download
- (2) Enable Unattended Call Back
- (3) Enable 2-Call Answer Phone Defeat
- (4) Restrict Download when Armed
- (5) Download when Part Armed
- (6) Disconnect Telephone Line

Continues on
 Next Page

From
Previous Page

**Device Types**

- (0) PC-Com/USB-Corr
- (1) RadioPlus
- (2) Inovonics Radio
- (3) ComIP Module
- (4) WebWay One/Emizon Module
- (5) Chiron Module

Note

The ComIP address and port number MUST be entered as a 17 digit sequence, e.g. If the IP address is 192.168.0.10 and the port number 980, then it should be entered as:
192 168 000 010 00980

Note

The ComIP Gateway address MUST be entered as a 12 digit sequence, e.g. If the Gateway address is 192.168.0.1, then it should be entered as:
192 168 000 001

Device Types

- (0) PC-Com/USB-Corr
- (1) RadioPlus
- (2) Inovonics Radio
- (3) ComIP Module
- (4) WebWay One/Emizon Module
- (5) Chiron Module

Chiron Data

- (0) Access PT Name
- (1) User Name
- (2) Password

Download Menu

⑦ ⑥

The Download Menu has the following options:

- ① Download Options
- ① Download Telephone Number
- ② UDL Passcode
- ③ Call Back Attempts
- ④ Ring Count
- ⑤ Com1 Device Type
- ⑥ ComIP Address & Port
- ⑦ ComIP Gateway address
- ⑧ ComIP Subnet Mask
- ⑨ Com 2 Device Type
- 🏠 Chiron Data Setup

Download Options

⑦ ⑥ - ①

The system has the following Download options:

① Enable Attended Download

On: The system will only allow download access if a user has authorised downloading.

Off: The system will allow unattended download access.

② Enable Unattended Call Back

On: The system will call back the remote computer before the system can be downloaded.

Off: Call back is not required.

③ Enable 2-Call Answer Phone Defeat

On: The panel will answer incoming calls as follows:

- In order to “prime” the panel one or more rings must be detected, but the panel must not detect more than the ring count. If the panel detects more than the ring count the panel will not “prime” itself.
- The panel will remain in primed state for 60 seconds.
- When the panel is primed the next incoming call is answered immediately.

Off: The panel will answer incoming calls after the specified “Download Ring Count”, see below.

④ Restrict Download when Armed

On: Download access is restricted when the system is armed (see option 5 below).

Off: The panel can be downloaded at any time.

⑤ Download when Part Armed

If option 4 above is enabled, then downloading is restricted as follows:

On: The panel will allow download access if system is part armed (one or more partitions disarmed).

Off: The panel will only allow download access when all partitions are disarmed.

⑥ Disconnect Telephone Line

If this option is enabled, the standard T and R connections cannot be used instead the telephone line must be connected to terminals T1 and R1. This configuration provides additional lightning protection as the telephone line is isolated most of the time and is

only switched in when the panel is required to transmit an alarm or to test the status of the telephone line. If this option is used then it is NOT possible to use the upload/download feature unless the user enables “Remote Access” see page 69. The operation is as follows:

On: The telephone line is disconnected from panel during normal operation and is only switched in when the panel is required to send an alarm event or test the line (tested every hour).

Off: The telephone line is continuously connected and operates as normal.

① & ⬇️ (down) or ⑨ & ⬆️ (up) Polling IP Address & Port Number

This is the polling IP Address and Port number of the alarm Receiving Centre. The IP address and port number MUST be entered as a 17 digit sequence, e.g. if the IP address is 192.168.0.10 and the port number 980, then it should be entered as: 19216800001000980. Values entered here are not used to set up the Chiron IRIS Module, (The Chiron IRIS module's Polling IP Address is taken from the first 12 digits of the Primary Telephone Number and its Account Number is that of Partition 1).

Call Back Number

⑦ ⑥ - ①

This is the telephone number that is used to dial the remote downloading computer when the system has been configured to use Unattended Call Back, see Download Options.

UDL Passcode

⑦ ⑥ - ②

When the remote downloading computer dials into the system, the control panel compares the Security code sent by the computer with Security code stored in the control panel. If the Security codes match, access to the control panel is granted, otherwise access is denied.

The security programmed in this option MUST also be programmed in the customer account on the remote downloading computer. The Security code can be up to 8 characters.

Download Dial Attempts

⑦ ⑥ - ③

If the “Enable Unattended Call Back” feature is enabled, (see Download Options), this option controls the number of times the panel will attempt to call back the remote downloading computer.



The maximum number of repeat dialling attempts is limited to 9. The system will only allow you to enter values between 0 and 9. Setting the value to 0 will disable the modem from dialling out.

Ring Count

⑦ ⑥ - ④

This counter controls the number of rings required in order for the on-board modem to answer the incoming call. If the “Ring Count” is set to 0 the panel will not answer any incoming calls.

Com1 Device Type

⑦ ⑥ - ⑤

This option allows you to specify which module is connected to communication port Com1. The control panel will accept the following modules:

- ① PC-Com
- ① RadioPlus
- ② Inovonics Radio
- ③ ComIP
- ④ WebWayOne/Emizon Module
- ⑤ Chiron Module

IP Address & Port

7 6 - 6

This option allows you to assign a local IP address and port number to a module connected to a Com Port (e.g. ComIP or Chiron IRIS). The IP address and port number **MUST** be entered as a 17 digit sequence, e.g. If the IP address is 192.168.0.10 and the port number 980, then it should be entered as: 19216800001000980. If an IP module (WebWayOne, Chiron IRIS, etc) is fitted its IP address and port must also enter via the Polling IP address and port number.



NOTE Note for the Chiron IRIS module entry of only the 12 digit IP Address results in the port number being set to its default, 10001.

ComIP Gateway Address

7 6 - 7

This option allows you to assign a Gateway IP address to the *ComIP* module (if fitted). The Gateway IP address **MUST** be entered as a 12 digit sequence, e.g. If the Gateway IP address is 192.168.0.1, then it should be entered as: 192168000001.

ComIP Subnet Mask

7 6 - 8

This option allows you to assign a Subnet Mask to the *ComIP* module (if fitted). The Subnet Mask is entered as a decimal value of 001 through to 024. Each decimal value generates the following Subnet Masks used by the *ComIP* module:

| Value | Subnet Mask | Value | Subnet Mask |
|-------|-----------------|-------|---------------|
| 001 | 255.255.255.254 | 013 | 255.255.224.0 |
| 002 | 255.255.255.252 | 014 | 255.255.192.0 |
| 003 | 255.255.255.248 | 015 | 255.255.128.0 |
| 004 | 255.255.255.240 | 016 | 255.255.0.0 |
| 005 | 255.255.255.224 | 017 | 255.254.0.0 |
| 006 | 255.255.255.192 | 018 | 255.252.0.0 |
| 007 | 255.255.255.128 | 019 | 255.248.0.0 |
| 008 | 255.255.255.0 | 020 | 255.240.0.0 |
| 009 | 255.255.254.0 | 021 | 255.224.0.0 |
| 010 | 255.255.252.0 | 022 | 255.192.0.0 |
| 011 | 255.255.248.0 | 023 | 255.128.0.0 |
| 012 | 255.255.240.0 | 024 | 255.0.0.0 |

Com2 Device Type

7 6 - 9

This option allows you to specify which module is connected to communication port Com2. See Com1 Device Type above for a list of supported devices.

Chiron Iris Data Setup

7 6 - 1

This menu option has three submenus to allow programming of the Chiron Iris module data. The value of each parameter can be viewed by pressing the key or its value can be edited by pressing the key. A maximum of 30 characters for the Access Point Name and 32 Characters for User Name and Password can be entered. Text is programmed in a similar way to mobile phones. Characters are selected by pressing the corresponding key the appropriate number of times (to select a character on the same key, press the key to move the cursor along). For details on entering text, see page 22.

7 6 - 1

Access Point Name

This is the GPRS Access Point Name. It's value can be viewed by pressing the key or its value can be edited by pressing the key. A maximum of 30 characters can be entered. Text is programmed in a similar way to mobile phones. Characters are selected by pressing the corresponding key the appropriate number of times (to select a character on the same key, press the key to move the cursor along). For details on entering text, see page 22.

7 6 - 2

User Name


This is the GPRS Access Point Name. It's value can be viewed by pressing the key or its value can be edited by pressing the key. A maximum of 32 characters can be entered. Text is programmed in a similar way to mobile phones. Characters are selected by pressing the corresponding key the appropriate number of times (to select a character on the same key, press the key to move the cursor along). For details on entering text, see page 22.

7 6 - 3

Password

This is the GPRS Access Point Name. It's value can be viewed by pressing the key or its value can be edited by pressing the key. A maximum of 32 characters can be entered. Text is programmed in a similar way to mobile phones. Characters are selected by pressing the corresponding key the appropriate number of times (to select a character on the same key, press the key to move the cursor along). For details on entering text, see page 22.

Programming Reporting Codes



Zone Alarm/Restore Event Numbers

| No | Event Type | No | Event Type |
|----|-----------------|----|-----------------|
| 00 | Zone 01 Alarm | 16 | Zone 09 Alarm |
| 01 | Zone 01 Restore | 17 | Zone 09 Restore |
| 02 | Zone 02 Alarm | 18 | Zone 10 Alarm |
| 03 | Zone 02 Restore | 19 | Zone 10 Restore |
| 04 | Zone 03 Alarm | 20 | Zone 11 Alarm |
| 05 | Zone 03 Restore | 21 | Zone 11 Restore |
| 06 | Zone 04 Alarm | 22 | Zone 12 Alarm |
| 07 | Zone 04 Restore | 23 | Zone 12 Restore |
| 08 | Zone 05 Alarm | 24 | Zone 13 Alarm |
| 09 | Zone 05 Restore | 25 | Zone 13 Restore |
| 10 | Zone 06 Alarm | 26 | Zone 14 Alarm |
| 11 | Zone 06 Restore | 27 | Zone 14 Restore |
| 12 | Zone 07 Alarm | 28 | Zone 15 Alarm |
| 13 | Zone 07 Restore | 29 | Zone 15 Restore |
| 14 | Zone 08 Alarm | 30 | Zone 16 Alarm |
| 15 | Zone 08 Restore | 31 | Zone 16 Restore |

Zone Bypass/Unbypass Event Numbers

| No | Event Type | No | Event Type |
|----|------------------|----|------------------|
| 00 | Zone 01 Bypass | 16 | Zone 09 Bypass |
| 01 | Zone 01 Unbypass | 17 | Zone 09 Unbypass |
| 02 | Zone 02 Bypass | 18 | Zone 10 Bypass |
| 03 | Zone 02 Unbypass | 19 | Zone 10 Unbypass |
| 04 | Zone 03 Bypass | 20 | Zone 11 Bypass |
| 05 | Zone 03 Unbypass | 21 | Zone 11 Unbypass |
| 06 | Zone 04 Bypass | 22 | Zone 12 Bypass |
| 07 | Zone 04 Unbypass | 23 | Zone 12 Unbypass |
| 08 | Zone 05 Bypass | 24 | Zone 13 Bypass |
| 09 | Zone 05 Unbypass | 25 | Zone 13 Unbypass |
| 10 | Zone 06 Bypass | 26 | Zone 14 Bypass |
| 11 | Zone 06 Unbypass | 27 | Zone 14 Unbypass |
| 12 | Zone 07 Bypass | 28 | Zone 15 Bypass |
| 13 | Zone 07 Unbypass | 29 | Zone 15 Unbypass |
| 14 | Zone 08 Bypass | 30 | Zone 16 Bypass |
| 15 | Zone 08 Unbypass | 31 | Zone 16 Unbypass |

Zone Alarm/Restore Codes (7) (7)

This menu option allows you to change the alarm/restore reporting event codes for each zone. These codes are used with Pulse Format, Express Format, Pager and Mobile Phone communication protocols. The default reporting codes are listed in the programming worksheets from page 86.



NOTE To disable the zone from reporting an event, program the first and second digit as 00.

Zone Bypass/Unbypass Codes (7) (8)

This menu option allows you to change the bypass/unbypass reporting event codes for each zone. These codes are used with Pulse Format, Express Format, Pager and Mobile Phone communication protocols. The default reporting codes are listed in the programming worksheets from page 86.



NOTE To disable the zone from reporting an event, program the first and second digit as 00.

Non Zone Alarm/Restore Codes (7) (9)

This menu option allows you to change the reporting event codes for non zone events. These codes are used with Pulse Format, Express Format, Pager and Mobile Phone communication protocols. The default reporting codes are listed in the programming worksheets from page 86.



NOTE To disable the event from reporting, program the first and second digit as 00.

The table below shows the event numbers for both alarm and restore for each event type:


| Event Type | Alarm Event No | Restore Event No |
|---------------------------|----------------|------------------|
| AC Fail | 00 | 01 |
| Low Battery | 02 | 03 |
| Telephone Line Fault | 04 | 05 |
| Fail to Communicate | 06 | 07 |
| Open/Close | 08 | 09 |
| Recent Closing | 10 | 11 |
| Auto Open/Close | 12 | 13 |
| Auto Arm Deferred | 14 | 15 |
| Remote Open/Close | 16 | 17 |
| Quick Arm | 18 | 19 |
| Open After Alarm (Cancel) | 20 | 21 |
| Download Start | 22 | 23 |
| Download End | 24 | 25 |
| Group Bypass/Unbypass | 26 | 27 |
| Log Capacity Alert (80%) | 28 | 29 |
| Keypad Lockout | 30 | 31 |
| Code Tamper Alarm | 32 | 33 |

| Event Type | Alarm Event No | Restore Event No |
|--------------------------------|----------------|------------------|
| Manual Test Transmission | 34 | 35 |
| Automatic Test Transmission | 36 | 37 |
| User Zone Test Start/End | 38 | 39 |
| Auxiliary Power Fail/Restore | 40 | 41 |
| Bell Output Fault/Restore | 42 | 43 |
| Installer Programming Start | 44 | 45 |
| Installer Programming End | 46 | 47 |
| Exit Error | 48 | 49 |
| Verified Cross Zone Alarm | 50 | 51 |
| Soak Test | 52 | 53 |
| Fire Zone Trouble | 54 | 55 |
| System Power Up | 56 | 57 |
| Swinger Shutdown | 58 | 59 |
| User Code | 60 | 61 |
| Exit Started | 62 | 63 |
| Entry Started | 64 | 65 |
| Bell Active | 66 | 67 |
| Alarm Active | 68 | 69 |
| Keypad Tamper | 70 | 71 |
| Keypad Medical | 72 | 73 |
| Keypad Fire/2-Wire Smoke | 74 | 75 |
| Duress Code Alarm | 76 | 77 |
| Keypad Silent PA | 78 | 79 |
| Keypad Audible PA/Auxiliary PA | 80 | 81 |
| Box Tamper | 82 | 83 |
| Zone Tamper | 84 | 85 |
| Zone Trouble | 86 | 87 |
| Expander/Remote Trouble | 88 | 89 |
| Auxiliary Tamper Input | 90 | 91 |
| Date Changed | 92 | 93 |
| Time Changed | 94 | 95 |
| System Reset | 96 | 97 |
| Remote Control | 98 | 99 |

Contact ID and SIA Codes


The reporting codes for Contact ID and SIA are fully configurable, however these codes can only be changed using *Wintex* downloading software.

Programming Users



From
Previous Page


User Text




Text Editing Keys

- ① ., ? ! 1 @ " - &
- ② a b c 2 A B C
- ③ d e f 3 D E F
- ④ g h i 4 G H I
- ⑤ j k l 5 J K L
- ⑥ m n o 7 M N O
- ⑦ p q r s 7 P Q R S
- ⑧ t u v 8 T U V
- ⑨ w x y z 9 W X Y Z
- ⑩ Space 0 , # *
- Move Left/Right
- Backspace (delete)


Program Standard Users




Default ALL Users



Delete User



Assign Radio Fob



Program User (8) (0)

The Program User option allows the engineer to assign new users for the alarm system. The number of users (including the engineer) that are available is as follows:

- Premier 412 - 32 Users
- Premier 816 - 32 Users
- Premier 832 - 64 Users

User 00 is the Engineer and can only be accessed by the engineer code. User 01 is the Master User which has a default code of 5678. Neither of these two users can be deleted from the system.

Each user is assigned the following attributes:

- **Access Code**
This is a unique 4, 5 or 6 digit code that is assigned to the user. The system will allow a mixture of different length Access codes. The Access code must be entered at a keypad before the user can operate the alarm system.
- **User Options 1**
See User Options 1 on page 66 for details.
- **User Options 2**
See User Options 2 on page 66 for details.
- **User Options 3**
See User Options 3 on page 67 for details.
- **User Text (LCD Only)**
See User Text on page 67 for details.

When using an LED keypad it is possible to view the next available user by pressing the Area key before entering the two digit user number. This will cause the next available user to be indicated using the top row of status lights.

User Options 1 (8) (1)

User Options 1 can be enabled or disabled for a selected user so that the level of access to the system may be altered. The following options are available:

- (1) Enable for Partition 1**
On: The user can access Partition 1.
Off: The user cannot access Partition 1.
- (2) Enable for Partition 2**
On: The user can access Partition 2.
Off: The user cannot access Partition 2.
- (3) Enable for Partition 3 (Premier 816/832 Only)**
On: The user can access Partition 3.
Off: The user cannot access Partition 3.
- (4) Enable for Partition 4 (Premier 816/832 Only)**
On: The user can access Partition 4.
Off: The user cannot access Partition 4.
- (5) Allow Arming**
On: The user can arm the partitions they have been given access to.
Off: The user cannot arm any partitions.
- (6) Allow Bypassing**
On: The user can bypass zones in partitions they have been given access to.
Off: The user cannot bypass zones.

- (7) Allow Disarming**
On: The user can disarm the partitions they have been given access to.
Off: The user cannot disarm any partitions.



NOTE The Engineer code (User 0) can only disarm the system, if the system was armed with the Engineer code.

- (8) Allow User Functions**
On: The user can access the following user functions:
 - Reset
 - View Alarm Log
 - View Service Faults
 - Enable Chime
 - Change Own Code
 Off: The user cannot access the above user functions.

User Options 2 (8) (2)

User Options 2 can be enabled or disabled for a selected user so that the level of access to the system may be altered. The following options are available:

- (1) Enable One Time Use Access Code**
On: The Access code can only be used once to arm and disarm the system. After the Access code has been used to arm the system it is automatically deleted.
Off: The Access code behaves normally.
- (2) Time Lock Code with Control Timer 1**
On: When Control Timer 1 is on, the Access code will not be accepted by the system. When Control Timer 1 is off, the Access code will be accepted by the system. For information on programming Control Timers, see page 36.
Off: The Access code will be accepted at all times.
- (3) Enable Open Reporting**
On: The system will report an 'Open' condition to the alarm receiving centre when the Access code is used to disarm one or more partitions.
Off: The system will not report an 'Open' status.



NOTE The panel will always send an open signal after an alarm even if this option is disabled.

- (4) Enable Close Reporting**
On: The system will report a 'Close' condition to the monitoring station when the Access code is used to arm one or more partitions.
Off: The system will not report a 'Close' condition.
- (5) Enable User as Duress Code**
On: The Access code will report a 'Duress' condition to the monitoring station when the Access code is used.
Off: The Access code behaves normally.
- (6) Activate Door Strike Output**
On: When a user Access code is entered, the output type "Door Strike" (see page 49) is activated for 2 seconds.
Off: The user Access code will not activate the "Door Strike" output.
- (7) Allow Global Bell/Sounder Silence**
On: This option allows users to silence the bell and internal sounder for any partition, even if the user is not assigned to

the partition that is in alarm. The user cannot disarm or reset the partition if they are not assigned to it.

Off: The user can only silence alarms for partitions that are assigned to their code.

⑧ Disable Remote Access

On: The touch-tone remote control feature is disabled for the selected user.

Off: The touch-tone remote control feature is enabled for the selected user.

User Options 3

⑧ ③

User Options 3 can be enabled or disabled for a selected user so that the level of access to the system may be altered. The following options are available:

① Allow Engineer Code Programming

On: The Access code can access User 00 (Engineer) in the Program New Users menu (menu 80).

Off: The Access code cannot access user 00 in the Program New Users menu.

② Allow NVM Locking/Communicator Programming

On: The Access code is allowed to lock/unlock the NVM (providing "Allow Engineer Programming" is enabled). Once the NVM is locked the "Load Defaults" jumper pins on the main control panel are disabled, thus preventing the panel from being defaulted. The Access code is also allowed to access the communicator programming menus 70 - 79.

Off: The Access code cannot lock/unlock the NVM or access communicator programming menus 70 - 79.

③ Allow Engineer Programming

On: The Access code can access the Engineer programming menus.

Off: The Access code cannot access the Engineer programming menus.

④ Allow Test Call Transmission

On: The Access code can perform a test transmission to the monitoring station (menu 92, see page 69).

Off: The Access code cannot perform a test transmission.

⑤ Allow Alarm/Fault Acknowledgement

On: The Access code can be used to acknowledge and reset alarms and service faults. A user with this option can disarm the system after an alarm, even if the user does not have the "Allow Disarming" option.

Off: The Access code cannot be used to acknowledge and reset alarms and service faults.

⑥ Allow User Programming

On: The Access code can access the user program menus (menu 90 - 98).

Off: The Access code cannot access the user program menus.

⑦ Allow User Code Programming

On: The Access code can access users 01 to 31 in the User programming menus (menus 80 - 85).

Off: The Access code cannot access user 01 to 31 in the User programming menus.


⑧ Local Partition Access Only

On: The Access code can only be used to arm and disarm the partitions that are assigned to the remote keypad. For example, if the user is assigned to all four partitions and they use a remote keypad that is only assigned to partition 1, they will only be permitted to arm and disarm partition 1 at that particular remote keypad.

Off: The Access code can be used at any remote keypad (Global access).

User Text (LCD Only)

⑧ ④

If the system is fitted with a LCD remote keypad you can assign up to 8 characters of text to each user. This text is used when viewing the system Event Log, see page 77. User text is programmed in a similar way to mobile phones. Characters are selected by pressing the corresponding key the appropriate number of times (to select a character on the same key, press  to move the cursor along). For details on entering text, see page 22.

Program Standard Users

⑧ ⑤

This menu option allows you to add "Standard" users to the system. The user will automatically be assigned the following options:

User Options 1: Partition 1 Access

Allow Arming

Allow Bypassing

Allow Disarming

Allow User Functions

User Options 2: Enable Open Reporting

Enable Close Reporting

Allow Global Bell/Sounder Silence


User Options 3: Allow Alarm/Fault Acknowledgement


Default ALL Users

⑧ ⑥

This menu option allows you to default all Users to their factory default settings. Before selecting this menu option you **MUST** link out the "Load Defaults" pins (JP6) on the control panel PCB, see page 8. After selecting this option, User 01(Master) is reverted to 5678 and Users 02 onwards are deleted.

System Tests & Utilities





Walk Test

⑨ ⑩

The Walk Test feature can only be performed when the partition is disarmed. 24 hour zones (except Fire, Tamper and Trouble) are disabled during Zone Test allowing Audible PA buttons, Silent PA buttons, etc. to be tested.



NOTE Pressing Reset clears all previously tested zones.

Test Speakers & Outputs

⑨ ①

This menu options allows you to perform the following tests:

- ① Test Speakers
- ② Test Bells
- ③ Test Strobes
- ④ Test System Outputs
- ⑤ Test LCD Display



NOTE Only outputs with the 'Enable User Test' option selected (see page 49), will be included in test 4.

Send Test Call

⑨ ②

This menu options allows you to send a test call transmission to your Alarm Receiving Centre. If the engineer code is used to select this option the keypad will display the progress status of the call.



NOTE If the panel is fitted with a *Speech Module*, keys ① - ④ can be used to switch between speech message 1 - 4 during the test.

Enable Remote/Engineer Access

⑨ ③

This option will enable both Remote Access to the control panel via downloading and Engineer Access (if EN 50131-1 requirements is enabled, see page 37). Once enabled, the control panel will allow access until 12.00am, after which, both Remote and Engineer Access will be disabled.



NOTE If the "Load Defaults" jumper pins (JP6) are shorted whilst this menu option is selected, the Engineer Access code is restored to its factory default setting of 1234 (providing the NVM is not locked).

Start Call Back

⑨ ④

This option will cause the control panel to initiate a call back sequence. This will allow the remote downloading computer to remotely access the control panel.



NOTE If the Call Back is unsuccessful the keypad will sound the Error Tone.

Program Time

⑨ ⑤

The control panel has a real time clock that is used to date and time stamp events that are recorded within the system log. The option allows you to set the control panel time.

Program Date

⑨ ⑥

The control panel has a real time clock that is used to date and time stamp events that are recorded within the system log. The option allows you to set the date on the control panel.

Program Banner Text (LCD only)

⑨ ⑦

If the system is fitted with a LCD remote keypad you can assign up to 16 characters of text to the Banner Message. The Banner Message is displayed on the top line of the LCD display during the normal disarmed state. Text is programmed in a similar way to mobile phones. Characters are selected by pressing the corresponding key the appropriate number of times (to select a character on the same key, press ↔ to move the cursor along). For details on entering text, see page 22.

Print 100 Events

⑨ ⑧

This menu option allows the last 100 events in the system Event Log to be sent to the printer port (Com1).

Log Off Engineer

⑨ ⑨

Selecting this menu option will log you out of engineer's programming mode and return the system to its normal state.

5. Operating the Alarm System

Introduction

Before attempting to operate the alarm system ensure you have familiarised yourself with all the arming and disarming methods covered in this section.

Access Codes

- If you make a mistake whilst entering your Access code, simply enter the correct Access code.

Arming & Disarming the Alarm System

Checking if the System is Ready to Arm

To help prevent faults during arming, a **Ready** light has been provided on each keypad. The **Ready** light works as follows:

- If the **Ready** light is on steady then the alarm system is ready to be armed.
- If the **Ready** light is flashing then the alarm system has bypassed zones and/or Force Armable zones that are violated, check these zones before proceeding.
- If the **Ready** light is off then one or more zones are violated, either secure or bypass these zones before proceeding. The keypads will display the zones that are violated:



Active zones are indicated by the relevant zone lights on LED Keypads

Zone 01 Active
Front Door

Zone 04 Active
Patio Doors

Active zones are scrolled in sequence on LCD keypads



NOTE

If any unbypassed zones that are not enabled for "Force Arming" are violated at the end of the exit delay this is termed an exit error and the alarm system will go into fail set state (internal alarm). If programmed by the installer the external bell will also sound. Enter a valid user Access code to silence this alarm.







A zone will only be armed when ALL associated partitions are armed but will be disarmed when ANY associated partition is disarmed.

Away Arming

The Away arming mode is normally used when leaving the premises. When the system is armed in this mode all detection zones assigned to your partition(s) will be armed.

The **Ready** light must be on steady before the alarm system can be Away armed.

► To Away arm the alarm system proceed as follows:

- Enter Access code (? ? ? ?)


- Press  Press 



The **Armed** light will flash and the exit tone will sound.
- Leave the premises, when the system has armed the exit tone will stop. The system is now Away armed.



NOTE







If the Quick Arm feature is enabled (see page 42) you can omit step 1 from the above procedure.

Stay Arming

The Stay arming mode is normally used when the premises will be occupied. When the system is armed in this mode all Interior detection zones assigned to your partition(s) will be bypassed. Before Stay arming check the following:

- Secure or bypass any perimeter zones that are violated.
- Ensure no perimeter zones are bypassed unintentionally.
- Ensure no perimeter Force Armable zones are violated unintentionally.

► To Stay arm the alarm system proceed as follows:

- Enter Access code (? ? ? ?)


- Press  Press 



The alarm system will arm immediately and the **Armed** light will flash.
- The system is now Stay armed.







NOTE

If the Quick Arm feature is enabled (see page 42) you can omit step 1 from the above procedure.

If the system is fitted with a *Premier RKP16 Plus* then the **Stay** light will also illuminate when the system is Stay armed.

Cancelling the Arming Process

- To cancel the arming process during the exit delay:





- 1 Enter Access code (?) (?) (?) (?)


- 2 Press (H) Press (X)


- 3 Arming has been cancelled and the alarm system is now disarmed.



NOTE If the system only has one partition you will not have to perform step 2.

Disarming During Entry

- To disarm the alarm system during entry, proceed as follows:





- 1 Enter the premises via the designated entry point, the entry tone will sound. Proceed directly to the remote keypad.


- 2 Enter Access code (?) (?) (?) (?)


- 3 The entry tone will stop and the **Armed** light will turn off. The alarm system is now disarmed.



NOTE If a valid Access code is not entered before the end of the entry delay, an alarm will occur.

Disarming when not in Entry

- To disarm the alarm system when not in entry, proceed as follows:

- 1 Enter Access code (?) (?) (?) (?)


- 2 Press (H) Press (X)


- 3 The **Armed** light will turn off. The alarm system is now disarmed.






NOTE If the system only has one partition you will not have to perform step 2.

If the Quick Disarm feature is enabled (see page 42) and the system is Stay armed you can omit step 1 from the above procedure.

Disarming after an Alarm

- To disarm the alarm system after an alarm, proceed as follows:





- 1 Enter Access code (?) (?) (?) (?)



- 2 The system is disarmed and the keypads display the source of the alarm.

The system must now be reset before you can arm again, see page 75 for details on resetting alarms.

Auto Stay Arming

If your installer has enabled the Auto Stay feature the system will automatically Stay arm if the entry/exit zone (front door) is not activated whilst attempting to Away arm the system.

- To auto Stay arm your alarm system proceed as follows:



- 1 Enter Access code (?) (?) (?) (?)


 - 2 Press (H) Press (✓)


- The **Armed** light will flash and the exit tone will sound.

- 3 Do NOT leave the premises during the exit delay. At the end of the exit delay the alarm system will Stay arm.

Changing between Delayed and Instant Stay

When Stay arming the system the delayed zones (front door etc) are normally delayed, i.e., when a delayed zone is violated it will start the entry delay timer. However, it is possible to change the delayed zones to instant when the system is in a Stay armed mode. If a delayed zone is violated when the system is in the "Instant Stay" mode the system will generate an alarm immediately.

- To change from Delayed Stay to Instant Stay, proceed as follows:

- 1 Ensure that the system is **Stay** armed.
- 2 Press and hold the (H) key until you hear the confirmation tone.


- 3 The **Armed** light will flash quickly. The system is **Instant Stay** armed.



NOTE If the system is fitted with a *Premier RKP16 Plus* the **Instant** light will also illuminate.

► To change from **Instant Stay** to **Delayed Stay**, proceed as follows:

1 Ensure that the system is **Instant Stay** armed.

2 Press and hold the key until you hear the confirmation tone.



3 The **Armed** light will flash slowly.
The system is **Delayed Stay** armed.



NOTE If your system is fitted with a *Premier RKP16 Plus* the **Instant** light will go off.

Arming and Disarming Partitions

This section covers arming and disarming partitions. In order to use these procedures the following requirements must be configured:

- The alarm system must be split into one or more partitions.
- Your Access code must be assigned to more than one partition.
- The keypad that you use to operate the alarm system must be assigned to multiple partitions OR your Access code is enabled for Global Access.

Away Arming Partitions

This option allows you to Away arm one or more partitions.

► To Away arm selected partitions, proceed as follows:

1 Enter Access code



2 Press



3 The **Ready** light will flash quickly.
Press - to select/deselect partitions,
e.g. Press to select Partition 2.



Partition 2 is now selected.

4 Press



The **Armed** light will flash and the exit tone will sound.

5 Leave the area being armed, when the partition has armed the exit tone will stop. The selected partition(s) is now Away armed.



NOTE If the Quick Arm feature is enabled (see page 42) you can omit step 1 from the above procedure.

Stay Arming Partitions

This option allows you to Stay arm one or more partitions.

► To Stay Arm selected partitions, proceed as follows:

1 Enter Access code



2 Press



3 The **Ready** light will flash quickly.
Press - to select/deselect partitions,
e.g. Press to select Partition 1.



Partition 1 is now selected.

4 Press



The selected partition(s) will arm immediately and the **Armed** light will flash.

5 The selected partition(s) is now **Stay** armed.

Disarming Partitions

This option allows you to disarm one or more partitions.

► To disarm selected partitions, proceed as follows:

1 Enter Access code



2 Press



3 The **Ready** light will flash quickly.
Press - to select/deselect partitions,
e.g. Press to select Partition 2.



Partition 2 is now selected for disarm.

4 Press



5 The selected partitions are disarmed.






Changing to another Partition

Normally the remote keypad that you use will be assigned to a particular partition and therefore the zone and status lights will indicate information relevant to the assigned partition. However, you can temporarily switch the remote keypad to a different partition so that the zone and status lights indicate the information relevant to the partition that you have selected. Whilst in this mode you can also use your Access code to arm/disarm the partition you have selected (providing you have access to the selected partition).

In order to use the cross partitioning feature, it is recommended that the system is configured as follows:

- Cross partitioning must be enabled (see page 37).
- The user must be assigned to multiple partitions.
- The user should be set for "Local Partition Access Only", see page 67.
- The remote keypads should only be assigned to a single partition.

➤ To change to another partition, proceed as follows:

- 1 Press 
 
- 2 Enter partition ① - ④,
e.g. Press ② to select Partition 2.
  

The remote keypad will now indicate information relevant to the selected partition.



NOTE

After changing to the selected partition, the remote keypad will only remain in the selected partition for 10 seconds after the last key press. However if an Access code is entered whilst the remote is in this mode, the remote keypad will remain in the selected partition for 1 minute after the last key press.

Bypassing Zones

Manually Bypassing Zones

Bypassing a zone prevents it from causing an alarm.













NOTE

After manually bypassing a zone, the bypass will remain in place until the zone is manually unbypassed.

The bypass mode will time-out if no key is pressed for 60 seconds.

24 hour zones cannot be unbypassed if they are violated.

➤ To manually bypass zones, proceed as follows:

- 1 Enter Access code ② ② ② ②
  
- 2 Press 
 
- 3 The **Ready** light will flash quickly.
Enter the zone number ② ②,
e.g. Enter ① ② to select Zone 2.
  
- 4 The selected zone is now bypassed. Repeat step 3 to bypass additional zones.
- 5 Once the selected zones have been bypassed press:
 -  to Away arm
 -  to Stay arm
 -  to return to the normal disarmed state



NOTE

If the Quick Bypass feature is enabled (see page 42) you can omit step 1 from the above procedure.

When one or more zones are bypassed the **Ready** light will flash and if the system is fitted with a *Premier RKP8/16 Plus* or LCD remote keypad then the **Bypass** light will also illuminate.

Unbypassing Zones












To manually unbypass zones, perform the manual bypass procedure on a zone that is already bypassed.

- 24 hour zones cannot be unbypassed if they are still violated.
- If the "Reinstate Bypassed Zones on Disarm" option is enabled (see page 37) all zones will automatically be unbypassed each time the system is disarmed.

Group Bypass

The Group Bypass feature allows you to bypass a predefined group of zones. The alarm system has up to four groups, see page 29 on programming bypass groups.

➤ To Bypass a group of zones, proceed as follows:

- 1 Enter Access code (?) (?) (?) (?)

- 2 Enter bypass group (1) - (4) followed by ()


- 3 The keypad will display the bypassed zones.
 If required, zones can be added or removed from the group by entering the required zone number (?) (?) , e.g. Enter (0) (5) to add Zone 5.



- 4 The selected zone is now bypassed. Repeat step 3 to bypass additional zones.
- 5 Once the selected zones have been bypassed press:
 /  to Away arm
 to Stay arm
 to return to the normal disarmed state






If the Quick Bypass feature is enabled (see page 42) you can omit step 1 from the above procedure.

When one or more zones are bypassed the **Ready** light will flash and if the system is fitted with a *Premier RKP8/16 Plus* or LCD remote keypad then the **Bypass** light will also illuminate.




Quick Bypass and Arm

The Quick Bypass and Arm feature allows you to Bypass a predefined group of zones and Away or Stay arm the system. The alarm system has up to four groups, see page 29 on programming bypass groups.

➤ To Quick Bypass a group of zones and Away arm, proceed as follows:

- 1 Enter bypass group (1) - (4)

- 2 Press ()

 The **Armed** and **Ready** lights will flash and the exit tone will sound.
- 3 When the exit tone stops, the system is Away armed with the selected group of zones bypassed.

➤ To Quick Bypass a group of zones and Stay arm, proceed as follows:

- 1 Enter bypass group (1) - (4)

- 2 Press ()

 The alarm system will arm immediately and the **Armed** and **Ready** lights will flash.
- 3 The system is Stay armed with the selected group of zones bypassed.







The Quick Arm feature must be enabled to use this feature (see page 42).

Reset Alarms

This function is used to reset any standing alarms and service faults. It is also used to reset detectors with a latched alarm indication, e.g., Smoke Detectors.




► To Reset Alarms, proceed as follows:

- 1 Enter Access code (?) (?) (?) (?)

- 2 Press () (0) Press ()

- 3 The keypad will beep and the alarm system will reset all latching detectors and attempt to clear any standing **Alarms or Service Faults**.


Last Alarm Log

The control panel has a memory that stores the zones that caused an alarm when the system was last armed.

► To view the alarm memory, proceed as follows:

- 1 Enter Access code (?) (?) (?) (?)

- 2 Press () (1)


The keypad will display the zones that caused an alarm when the system was last armed.

- 3 Press () to return to the normal disarmed state.

Service Faults

The response to a Service Fault condition is programmed by the installer but is normally limited to the keypad buzzer. To silence the Service Fault alarm, enter your Access code.

A flashing **Service** light indicates a new fault condition. The alarm system cannot be armed whilst a new fault exists. The **Service** light will remain flashing until the new fault is acknowledged, after which it will revert to a steady yellow and the alarm system can be armed. The **Service** light will remain steady until **all** faults have been cleared.

After a new Service Fault has been acknowledged the **Service** light will revert to steady yellow and the alarm system can be armed. The **Service** light will remain steady yellow until **all** faults have been cleared.




AC Fail and Telephone Line Fault can each have a delay programmed. The **Service** light will turn steady yellow immediately

on either of these faults but no Service Fault Alarm (transmission or audible alarm) will occur unless the delay expires.



If your installer has disabled AC fail acknowledgement the **Service** light will flash "rapidly" during an AC fail condition. The system can be armed without requiring acknowledgement of this fault.

Acknowledging a New Service Fault

► New service faults can be acknowledged as follows:

- 1 Enter Access code (?) (?) (?) (?)

- 2 Press () (2)


The keypad will display all Service Faults.

- 3 Press () or () to acknowledge the fault and return to the normal disarmed state.





View Service Faults

► Standing faults can be viewed as follows:

1. Press the  key followed by the  key.

The keypad will display any Service Faults (see tables).

On completion press the  key.

| Service Faults Displayed on LED Keypads | |
|---|---|
| Light | Fault Condition |
| 1 | General Warnings Press (Key 1) to view the warning, lights 1-5 will indicate the following:- 1 = AC Fail 2 = Arming Fob has Low Battery 3 = Soak Test Active |
| 2 | Telephone Line Fault |
| 3 | 2-Wire Smoke Alarm |
| 4 | Box Tamper & Auxiliary Input: Press  to view type, lights 1 - 8 indicate: 1 = Box Tamper 4 = Auxiliary Tamper * 2 = Auxiliary Tamper 5 = Bell Tamper * 3 = Auxiliary PA 6 = Radio Plus Tamper 7 = Low Fob Battery 8 = User Code Tamper * = UK Bell Module |
| 5 | Date or Time Lost |
| 6 | Zone Tamper/Trouble Press  to view zone number |
| 7 | Keypad Tamper/Removed Press  to view keypad number |
| 8 | Equipment Faults Press  to view fault type, lights 1 - 8 indicate: 1 = Output 1 Fault 2 = Output 2 Fault 3 = Siren/Bell Fault 4 = 2-Wire Smoke Sensor Fault 5 = Auxiliary Fuse Failed 6 = Battery Fault 7 = Service Timer/Zone Soak Test Failed 8 = Com1 Fault or Fail To Communicate |

| Service Faults Displayed on LCD Keypads | |
|---|---|
| LCD | Fault Condition |
| AC Fail | AC Fail |
| Soak Test Active | One or more zones on soak test |
| 1:Proceed 0:Exit | 1 to continue arming 0 to exit arming |
| Arm Low Fob Bat? | Key fob has a low battery (Message above shown) |
| User Code Tamper | Shown after invalid user code attempts |
| Line Fault | Telephone Line Fault |
| Smoke Alarm (2W) | 2-Wire Smoke Alarm |
| Box/Aux Tamper | Box Tamper |
| Aux Tamper | Auxiliary Tamper (Aux Input) |
| Auxiliary Tamper | Auxiliary Tamper (UK Bell Module) |
| Bell Tamper | Bell Tamper (UK Bell Module) |
| Aux PA Alarm | Auxiliary PA (Aux Input) |
| Date/Time Loss | Date or Time Lost |
| Tamper Zone > 01 | Zone Tamper/Trouble |
| Tamper Keypad > 1 | Keypad Tamper/Removed |
| Output 1 Fault | Output 1 Fault |
| Output 2 Fault | Output 2 Fault |
| Siren Fault | Siren/Bell Fault |
| Smoke Sen. Fault | 2-Wire Smoke Sensor Fault |
| Aux. Fuse Fault | Auxiliary Fuse Failed |
| Battery Fault | Battery Fault |
| Service Required | Service Timer/Zone Soak Test Failed |
| Coms Fault | Com1 Fault or Fail To Communicate |

Anti-code Reset

This feature is normally used in the UK where users are not permitted to reset the panel following a communicated alarm. However, the user can reset the panel after entering a unique remote reset number, which is supplied by their installer or ARC.

► To perform an Anti-code Reset, proceed as follows:

- 1 Enter Access code (? ? ? ?)
- 2 Press (3)

The keypad will display a randomly generated 4-digit Code.
- 3 Contact the ARC to obtain a Anti-code Reset number.
- 4 Enter the Anti-code Reset number given to you by the ARC (? ? ? ?).

If the code is accepted, the keypad will sound an acceptance tone and the system will reset and return to the normal disarmed state.

Toggle Chime On and Off

When a zone is enabled for Chime the keypad will generate a Chime tone every time the zone is violated. This function allows you to turn the Chime feature on and off.

► To toggle Chime on and off, proceed as follows:

- 1 Enter Access code (? ? ? ?)
- 2 Enter (4) Press (P)
- 3 If Chime was off, it will turn on and the keypad will sound the Chime tone. If Chime was on, it will turn off and the keypad will sound the acceptance tone.

Change User Code

All users of the alarm system can change their own Access code number.

► To change your Access code, proceed as follows:

- 1 Enter Access code (? ? ? ?)
- 2 Enter (5)
- 3 Enter new code (? ? ? ?)

If the code is 4 or 5 digits press the () key to accept.
- 4 Re-enter new code (? ? ? ?)
- 5 The keypad will sound an acceptance tone if the new Access code was accepted. If you hear an error tone (low), please repeat from step 1.

View Log (LCD Only)

The control panel has an Event Log, which stores all system activity i.e., users entering their codes to arm and disarm the system, alarm events, faults etc. Each event is time and date stamped.

► To view the Event Log, proceed as follows:

- 1 Enter Access code (? ? ? ?)
- 2 Enter (6)
- 3
Partitions Time Day Time Day/Month
- 4 Press () to toggle information displayed
Press () to scroll up and down through the log. Press () to when finished.

Abort Communications

This option aborts any communications to the Alarm Receiving Centre.

► To Abort Communications, proceed as follows:

- 1 Enter Access code (? ? ? ?)
- 2 Enter (7)
- 3 The keypad will bleep and the alarm system will abort all communications to the Alarm Receiving Centre.

6. Specifications

Control Panel

All Models Large & Small Polymer

Current

| | |
|---------------------------|------|
| Current Consumption | 50mA |
| Maximum Current Available | |
| 0.3A charge | 1.1A |

Rated Output

| Battery Arrangement | Battery Charge | Rated Output (Amps) |
|---------------------|----------------|---------------------|
| 1 x 7Ah | 0.3A | 12h 0.533A |

Standby and Recharge Times

| EN50131-1 | Grade 1 | Grade 2 |
|------------------------|---------|---------|
| Minimum Standby Period | 12h | 12h |
| Maximum Recharge Time | 72 Hrs | 72 Hrs |

Control Panel

| | |
|---|----------------------------------|
| Power Supply | Type A |
| Rated Input: | 100V - 240V @ 50/60Hz; 1A |
| Rated Output Current @ 55°C:: | 1.5A MAX |
| Rated Output Voltage: | 13.7Vdc +/- 2% |
| Mains Terminal Block Fuse: | 250Vac; 3-3.15A Slow/Medium Blow |
| Maximum rating of each power output (note that these are not considered to be "independent power outputs" according to EN50131-6) | |

| | |
|---------|------|
| Aux 12V | 1.0A |
| Siren | 1.0A |
| Network | 1.0A |
| Battery | 2.5A |

| | |
|-----------------------------|---|
| Standby Current | 50mA |
| Output Voltage Range: | 13.0V to 13.9V |
| Maximum Ripple Voltage: | 0.5V pk-pk |
| Battery type: | sealed lead acid, up to 7Ah, Maximum recharge time 72h |
| Battery Low Voltage Signal: | 10.5V |
| Deep Discharge protection: | 8.0V |
| Fuses (Electronic PTC) | F1 (2.5A) Battery Fuse F2 (900mA) Auxiliary 12V power fuse F3 (900mA) Siren/Bell output fuse F4 (900mA) Network fuse |

| | |
|--------------------------------|-----------------------|
| Housing (Polymer) | 3mm Polycarbonate |
| Dimensions (Small) (W x H x D) | 282mm x 225mm x 80mm |
| Dimensions (Large) (W x H x D) | 305mm x 263mm x 98mm |
| Battery Compartment | One 12V 7.0Ah battery |
| Packed Weight | 1.2 - 1.5 Kg (Approx) |

All Models Metal

Current

| | |
|---------------------------|------|
| Current Consumption | 50mA |
| Maximum Current Available | |
| 0.3A charge | 1.0A |
| 0.75A charge | 1.9A |

Rated Output

| Battery Arrangement | Battery Charge | Rated Output (Amps) |
|---------------------|----------------|---------------------|
| 1 x 7Ah | 0.3A | 12h 0.533A |
| 1 x 17Ah | 0.3A | 24h 0.241A |
| | 0.75A | 30h 0.183A |
| | | 60h X |
| | | 0.233A |
| | | 0.233A |

Standby and Recharge Times

| EN50131-1 | Grade 1 | Grade 2 |
|------------------------|---------|---------|
| Minimum Standby Period | 12h | 12h |
| Maximum Recharge Time | 72 Hrs | 72 Hrs |

Jumper Settings

| Battery Arrangement | Recharge Time | Charge Selection |
|---------------------|---------------|------------------|
| 1 x 7Ah | < 24Hrs | 0.3A |
| 1 x 17Ah | < 24Hrs | 0.75AA |
| | < 72Hrs | 0.3A |

Control Panel

| | |
|---|----------------------------------|
| Rated Input: | 220V - 240V @50/60Hz; 1A |
| Rated Output Current@40°C: | 2.5A MAX |
| Rated Input: | 100VV - 120V @50/60Hz; 1A |
| Rated Output Current@40°C: | 2.3A MAX |
| Rated Output Voltage: | 13.7Vdc +/- 2% |
| Mains Terminal Block Fuse: | 250Vac; 3-3.15A Slow/Medium Blow |
| Rated Input: | 220V - 240V @50/60Hz; 1A |
| Rated Output Current@40°C: | 2.5A MAX |
| Maximum rating of each power output (note that these are not considered to be "independent power outputs" according to EN50131-6) | |

| | |
|---------|------|
| Aux 12V | 1.0A |
| Siren | 1.0A |
| Network | 1.0A |
| Battery | 2.5A |

Standby Current

| | |
|-------------------------|--|
| Output Voltage Range: | 13.0V to 13.9V |
| Maximum Ripple Voltage: | 0.5V pk-pk |
| Battery type: | sealed lead acid, up to 7Ah, Maximum recharge time 72h |

| | |
|-----------------------------|---|
| Battery Low Voltage Signal: | 10.5V |
| Deep Discharge protection: | 8.0V |
| Fuses (Electronic PTC) | F1 (2.5A) Battery Fuse F2 (900mA) Auxiliary 12V power fuse F3 (900mA) Siren/Bell output fuse F4 (900mA) Network fuse |

| | |
|------------------------|----------------------------|
| Housing (Metal) | 1mm Steel |
| Dimensions (W x H x D) | 315mm x 415mm x 100mm |
| Battery Compartment | Up to One 12V 18Ah battery |
| Packed Weight | 4.0Kg (Approx) |

All Models

| Electrical | |
|----------------------------------|----------------------|
| Current Consumption | |
| Quiescent Current: | <50mA |
| Alarm: | <150mA |
| Zones | |
| Number: | 8 |
| EOL Resistor Value: | 3K3 |
| Panel Outputs | |
| O/P 1 - Supervised: | 1A switched to 0V |
| O/P 2 - Supervised: | 1A switched to 0V |
| O/P 3 - 8: | 100mA switched to 0V |
| Siren Output (Supervised) | |
| Speaker Mode: | Minimum load 4Ω |
| Bell Mode: | 1A switched to 0V |
| 2-Wire Smoke Detectors: | |
| | ESL429CT |
| | System Sensor 2100TS |

| | |
|-----------------------------|--|
| Onboard Communicator | |
| Protocols: | Pulse Format, Express Format, Fast Format, Contact ID, SIA Level 2/3, Pager and Mobile Phone |
| Dialling Formats: | Pulse or DTMF |
| REN: | 1 |
| Approval: | CTR21, DPT-TE-001 |

Non Volatile Memory Component

| | |
|-------------------------------|---------|
| 412, 412 Plus, 816, 816 Plus: | 24LC128 |
| 832 | 24LC256 |

EN50136-1-1 & EN50136-2-3

The inbuilt communicator complies with the requirements of EN50136-2-3, EN50136-1-1 and are suitable for use in systems designed for use with ATS levels 1 or 2 and environmental class 1 or 2 – i.e. systems using notification options up to and including 2B. With the PSTN functioning normally, the ATS will comply with the required performance levels subject to the ARC being suitably equipped.



These units may be used for Downloading, Remote Servicing or SMS text messaging purposes in systems at ALL security grades.

Environmental

| | |
|------------------------|---|
| Operating Temperature: | -10°C to +55°C +14°F to +131°F |
| Maximum Humidity: | 95% non-condensing |
| EMC Environment: | Residential/Commercial/Light Industrial or Industrial |

Remote Keypads

ACE Type B

Electrical

Operating Voltage: 9 - 13.7VDC

Current Consumption

Nominal (model dependant): 10mA
When fully back lit: 200mA

Zone Indicators

Premier RKP4/8/16: LED (4/8/16)
Premier RKP8/16 Plus: LED (8/16)
Premier LCD/LCDL/FMK/SMK: 32 Character (Standard/Large)

Environmental

Operating Temperature: -10°C to +55°C
+14°F to +131°F

Maximum Humidity: 95% non-condensing

EMC Environment: Residential/Commercial/Light Industrial or Industrial

Physical

Dimensions:

Premier RKP4/8/16 140mm x 105mm x 35mm
Premier RKP8/16 Plus/LCD/-L/P 145mm x 115mm x 30mm

Packed Weight: 380g

Remote Zone Expander

ACE Type B

Electrical

Operating Voltage: 9 - 13.7VDC

Current Consumption

Nominal: 35mA
In Alarm with Speaker: 180mA

Zones

Number: 8
EOL Resistor Value: 3K3

Speaker Output:

Minimum load 4Ω

Outputs

O/P 1 & OP 2: 100mA switched to 0V

Environmental

Operating Temperature: -10°C to +55°C
+14°F to +131°F

Maximum Humidity: 95% non-condensing

EMC Environment: Residential/Commercial/Light Industrial or Industrial

Physical

Dimensions: 145mm x 115mm x 30mm
Packed Weight: 260g approx.

Local Zone Expander

Electrical

Operating Voltage: 9 - 13.7VDC

Current Consumption: 35mA

Connection: Plugs onto control panel

Zones

Number: 8
EOL Resistor Value: 3K3

Environmental

Operating Temperature: -10°C to +55°C
+14°F to +131°F

Maximum Humidity: 95% non-condensing

EMC Environment: Residential/Commercial/Light Industrial or Industrial

Physical

Dimensions: 83mm x 50mm x 12mm
Packed Weight: 50g

Safety Notes

1. Only use batteries of the specified type.
2. Dispose of used batteries safely according to the manufacturer's instructions.
3. Locate the battery inside the panel space provided.
4. This equipment is designed for dry indoor use only.

5. When replacing a fuse always observe the specified rating and type - failure to do so is dangerous and will invalidate the warranty. Fuses should comply with IEC 127.
6. The press-seal bag must not be stored inside the panel.

Standards



Texcom declares that this product complies with the requirements of the following directives:

- 2004/108/EC EMC Directive
- 2006/95/EC LVD Directive
- 2011/65/EU RoHS Directive

The product therefore meets all the requirements to enable it to be CE marked.



Weee Directive: 2012/19/EU (WEEE directive): Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or dispose of it at designated collection points. For more information see: www.recyclethis.info.


This product is suitable for use in systems designed to comply with EN 50131-1 at grade 2 and environmental class II.

EN 50131-1/3/6 Compliance

In order to comply with the requirements of EN 50131-1, EN 50131-3 and EN 50131-6 the following programming and system configuration must be implemented:

- Menu Options 39 1-8 must all be turned ON, see page 40.
- EN 50131-1 Requirements must be programmed as "Enabled", see page 37.
- The "Permanent Keypad Status Display" option must be programmed to "Disabled" for all remote keypads, see page 42. In addition the "Courtesy Delay" timer must not be set above 180 seconds, see page 36.
- The "Partition Entry Delay" timers must not be programmed above 45 seconds, see page 31.
- The "Partition Bell Delay" timers must not be programmed above 10 minutes, see page 31.
- The "Partition Bell Duration" timers must be programmed between 2 and 15 minutes, see page 31.
- "Quick Arm", "Quick Disarm" and "Quick Bypass" option must be programmed to "Disabled" for all remote keypads, see page 42.
- The "Tamper Alarms Cause a Trouble While Disarmed" option must be "Enabled", see page 37.
- Do not fit more than 10 unpowered detectors per zone.
- Do not fit more than one non-latching powered detector per zone.
- Do not mix unpowered detectors and non-latching detectors on a zone.
- A Type W must not be used.

Prioritisation of signal and message processing indications.

First alarm indications followed by any other events during that set period, will be reported on the keypad and will scroll, viewing of these events can be controlled by the up and down key  on the keypad.

Compliance Label

If the system is programmed to NOT comply with the requirements of EN50131-1 or EN50131-3, or the system is installed at Grade 1 then the compliance label must be removed.

Inhibit functions

For Alarms and Tamper the inhibit function is controlled by the Swinger shutdown counter which is programmable and is defaulted to 3.



NOTE See page 27 & 34 for details.

Minimum Logical Keys

10,000 for 4 digit code
100,000 for 5 digit code
1,000,000 for 6 digit code



NOTE User codes must be programmed to be a 6 digit code to comply with INCERT

The number of disallowed codes

Premier 412 = 0
Premier 816 = 0
Premier 832 = 0



NOTE Dependant on the use of the Black Listed codes function available via Wintex, a maximum of 16 codes may be Black Listed

Warranty

All Texecom products are designed for reliable, trouble free operation. Quality is carefully monitored by extensive computerised testing. As a result the control panel is covered by a two-year warranty against defects in materials or workmanship.

As the control panel is not a complete alarm system but only a part thereof, Texecom cannot accept responsibility or liability for any damages whatsoever based on a claim that the control panel failed to function correctly.

Due to our policy of continuous improvements Texecom reserve the right to change specification without prior notice.

7. Quick Reference Guide

| Menu | Function | Page |
|--|-------------------------------------|------|
| Programming Zones | | |
| ① ① ① | All Zone Options | 26 |
| ① ① ① | Zone Type | 26 |
| ① ① ① Null | ① ① ① 24-Hour Tamper | |
| ① ① ① Delay 1 | ① ① ① Trouble | |
| ① ① ① Delay 2 | ① ① ① 24-Hour - Gas | |
| ① ① ① Interior Follower | ① ① ① 24-Hour - Water | |
| ① ① ① Interior Instant | ① ① ① 24-Hour - High Temp | |
| ① ① ① Perimeter Instant | ① ① ① 24-Hour - Low Temp | |
| ① ① ① Fire | ① ① ① Momentary Key Switch | |
| ① ① ① PA Silent | ① ① ① Maintained Key Switch | |
| ① ① ① PA Audible | ① ① ① Push To Set | |
| ① ① ① Medical | | |
| ① ① ② | Zone Wiring | 27 |
| ① ① ② Normally Closed | ⑤ ① ② Single EOL - O/C Tamper | |
| ① ① ② Normally Open | ⑥ ① ② Single EOL - S/C Tamper | |
| ② ① ② Single EOL - N/C & N/O | ⑦ ① ② Double EOL | |
| ③ ① ② Single EOL - N/O (Fire) | ⑧ ① ② Zone Doubled | |
| ④ ① ② Single EOL - N/C | ⑨ ① ② Triple EOL | |
| ① ① ③ | Zone Attributes 1 | 27 |
| ① ① ③ Enable Instant Internals | ⑤ ① ③ Enable Instant Strobe | |
| ② ① ③ Enable Bell | ⑥ ① ③ Enable User Chime | |
| ③ ① ③ Delayed Bell | ⑦ ① ③ Enable Transmission Delay | |
| ④ ① ③ Pulsed Bell | ⑧ ① ③ Enable Transmission | |
| ① ① ④ | Zone Attributes 2 | 28 |
| ① ① ④ Enable Manual Bypass | ⑤ ① ④ Enable Cross Zoning | |
| ② ① ④ Enable Stay Bypass | ⑥ ① ④ Enable Soak Test | |
| ③ ① ④ Enable Force Arming | ⑦ ① ④ Enable Swinger Shutdown | |
| ④ ① ④ Quick Response Time | ⑧ ① ④ Enable Double Knock | |
| ① ① ⑤ | Zone Attributes 3 | 28 |
| ① ① ⑤ Change to Delay 1 on Stay Arm | | |
| ② ① ⑤ Change to Follower on Stay Arm | | |
| ③ ① ⑤ Zone Warning (* Keyswitch is Instant Arming) | | |
| ④ ① ⑤ Auto Reinstate if Force Armed (* Keyswitch will Stay Arm/Disarm) | | |
| ⑤ ① ⑤ Disable Keyswitch if Away Armed | | |
| ⑥ ① ⑤ Disable Exit Faults (* Disabled Auto Arm) | | |
| ⑦ ① ⑤ Truncate Exit Delay (* Monitor Only) | | |
| ⑧ ① ⑤ Forced Walk Test | | |
| * Attributes for Key Switch zone types | | |
| ① ① ⑥ | Zone Partitions & Groups | 28 |
| ① ① ⑥ Enabled for Partition 1 | ⑤ ① ⑥ Enable for Bypass Group 1 | |
| ② ① ⑥ Enabled for Partition 2 | ⑥ ① ⑥ Enable for Bypass Group 2 | |
| ③ ① ⑥ Enabled for Partition 3 | ⑦ ① ⑥ Enable for Bypass Group 3 | |
| ④ ① ⑥ Enabled for Partition 4 | ⑧ ① ⑥ Enable for Bypass Group 4 | |
| ① ① ⑦ | Zone Text | 29 |
| ① ① ⑦ . , ? ! 1 @ " - & | ⑦ ① ⑦ p q r s 7 P Q R S | |
| ② ① ⑦ a b c 2 A B C | ⑧ ① ⑦ t u v 8 T U V | |
| ③ ① ⑦ d e f 3 D E F | ⑨ ① ⑦ w x y z 9 W X Y Z | |
| ④ ① ⑦ g h i 4 G H I | ⑩ ① ⑦ Space 0 , # * | |
| ⑤ ① ⑦ j k l 5 J K L | ⑪ ① ⑦ Move Left/Right | |
| ⑥ ① ⑦ m n o 7 M N O | ⑫ ① ⑦ Backspace (delete) | |
| ① ① ⑧ | Assign Radio Device | 29 |

| Menu | Function | Page |
|---|-------------------------------------|------|
| Programming Partitions | | |
| ② ① ① | Partition Exit Time | 31 |
| ② ① ① | Partition Entry Delay 1 Time | 31 |
| ② ① ② | Partition Entry Delay 2 Time | 31 |
| ② ① ③ | Partition Communicator Delay | 31 |
| ② ① ④ | Partition Bell Delay | 31 |
| ② ① ⑤ | Part Bell Duration | 31 |
| ② ① ⑥ | Partition Options | 31 |
| ① ② ① Enable Auto Bypass Mode | | |
| ② ② ① Stay Armed Exit is Silent | | |
| ③ ② ① Enable Remote Arming | | |
| ④ ② ① Enable Remote Disarming | | |
| ⑤ ② ① Enable Local Exit Tones | | |
| ⑥ ② ① Stay Armed Entry is Instant | | |
| ⑦ ② ① Stay Armed Exit is Delayed | | |
| ⑧ ② ① Only Start Exit when Partition is Ready | | |
| ② ① ⑦ | Partition Auto Arm/Disarm | 32 |
| ① ② ⑦ Arm with Control Timer 1 | ⑤ ② ⑦ Disarm with Control Timer 1 | |
| ② ② ⑦ Arm with Control Timer 2 | ⑥ ② ⑦ Disarm with Control Timer 2 | |
| ③ ② ⑦ Arm with Control Timer 3 | ⑦ ② ⑦ Disarm with Control Timer 3 | |
| ④ ② ⑦ Arm with Control Timer 4 | ⑧ ② ⑦ Disarm with Control Timer 4 | |
| ② ① ⑧ | Equipment Areas | 32 |
| ① ② ⑧ Auxiliary Input Areas | ② ② ⑧ Bell Squawk Areas | |
| ③ ② ⑧ Panel Bell Areas | ③ ② ⑧ Masked when Armed | |
| Programming Global Options | | |
| ③ ① ① | System Timers | 35 |
| ① ③ ① AC Fail Delay | ① ③ ① Test Transmission Time | |
| ② ③ ① Line Fault Delay | ② ③ ① Courtesy Delay | |
| ③ ③ ① Cross Zone Time | ③ ③ ① Service Timer | |
| ④ ③ ① Zone Soak Test Time | ④ ③ ① 2-Wire Verified Delay | |
| ⑤ ③ ① Restore Reporting Delay | ⑤ ③ ① Alarm Confirmation Delay | |
| ⑥ ③ ① Output Short Pulse Time | ⑥ ③ ① Activity Time Window | |
| ⑦ ③ ① Zone Response Time | ⑦ ③ ① Poll IP Every | |
| ⑧ ③ ① Transmission Abort | | |
| ③ ① ② | System Counters/Levels | 36 |
| ① ③ ② Swinger Shutdown Count | ③ ③ ② Clock Adjustment | |
| ② ③ ② Panel Speaker Volume | ④ ③ ② Language Selection | |
| ③ ③ ② Chime Volume | ⑤ ③ ② Country Operation Code | |
| ③ ① ③ | System Control Timers | 36 |
| ③ ① ③ | System Options 1 | 36 |
| ① ③ ③ Clock = Crystal | | |
| ② ③ ③ Battery Connection Supervision | | |
| ③ ③ ③ Battery Dynamically Load Tested | | |
| ④ ③ ③ Panel NVM is Locked | | |
| ⑤ ③ ③ Power Savings During AC Mains Failure | | |
| ⑥ ③ ③ Line Fault Overrides Bell Delay | | |
| ⑦ ③ ③ Two-Wire Smoke Detection on O/P 1 | | |
| ⑧ ③ ③ Convert Siren Output from Voltage to Speaker Driver | | |
| ③ ① ④ | System Options 2 | 37 |
| ① ③ ④ Tamper Alarms Cause a Trouble While Disarmed | | |
| ② ③ ④ Tamper Alarms Cause a Trouble While Stay Armed | | |
| ③ ③ ④ Defer Reporting of Non-Zone Restorals | | |

| Menu | Function | Page |
|----------------|---|-----------|
| ④ | Use Delay Timer to Defer Non-Zone Restorals | |
| ⑤ | Inhibit Keyswitch Operation Upon EOL Tamper | |
| ⑥ | Away Arm Overrides Alarm Transmission Delay | |
| ⑦ | Defer Reporting of Zone Restorals | |
| ⑧ | Use Delay Timer to Defer Zone Restorals | |
| ③ ⑤ | System Options 3 | 37 |
| ① | Away Arm Exit Error Doesn't Sound Bell | |
| ② | Zone Test - Silence on No Violation | |
| ③ | Alarm Status Light Indicates Fire | |
| ④ | Enable Entry/Exit Tones for Panel Speaker | |
| ⑤ | Enable Cross Partitioning | |
| ⑥ | Enable EN 50131-1 Requirements | |
| ⑦ | Reinstate Bypassed Zones on Disarm | |
| ⑧ | Invert Panel Bell/Siren Output | |
| ③ ⑥ | Hardware Options | 38 |
| ① | Panel Output 1 Supervised for Faults | |
| ② | Panel Output 2 Supervised for Faults | |
| ③ | Siren/Bell Output Supervised for Faults | |
| ④ | Panel Box Tamper Switch Monitored | |
| ⑤ | Auxiliary Fuse Supervised for Faults | |
| ⑥ | Battery Supervised for Faults | |
| ⑦ | AC Mains Supply is Monitored | |
| ⑧ | Telephone Line Is Monitored | |
| ③ ⑦ | Auxiliary Input Options | 38 |
| ① | Not Used | |
| ① | Auxiliary Tamper | |
| ② | Remote Reset | |
| ③ | Telephone Line Monitor | |
| ④ | Panic Alarm | |
| ⑤ | Silent PA | |
| ⑥ | Latched Key switch | |
| ⑦ | Momentary Key switch | |
| ③ ⑧ - ① | Miscellaneous Options 1 | 38 |
| ① | Enable Bell Squawk on AWAY Arm/Disarm | |
| ② | Enable Bell Squawk on STAY Arm/Disarm | |
| ③ | Disable AC Fail Acknowledgement | |
| ④ | Disable Open/Close Reporting on STAY Arm | |
| ⑤ | Cross/Double Knock Timer is in Minutes | |
| ⑥ | Disable Zone Bypass when Armed | |
| ⑦ | Activated Zones Cause Alarm during Exit | |
| ⑧ | Control Timer 4 Performs Battery Test | |
| ③ ⑧ - ② | Miscellaneous Options 2 | 39 |
| ① | Disable Service Fault Acknowledgement | |
| ② | Enable User Reset for Alarms | |
| ③ | Disable Online Printing | |
| ④ | Enable Bell Module and UK Options | |
| ⑤ | Enable DD 243:2002 Options | |
| ⑥ | Enable Confirmation after Entry Time-Out | |
| ⑦ | Invert Auxiliary Input Operation | |
| ⑧ | Auto BST/GMT Time Change | |
| ③ ⑧ - ③ | Miscellaneous Options 3 | 39 |
| ① | Enable User Tamper Reset | |
| ② | Allow Engineer Access when Armed | |
| ③ ⑨ | EN50131 | 40 |
| ① | Fob Low Battery Arming | |
| ② | Indicate Zone Soak Test | |
| ③ | Soak Test Acknowledgement | |
| ④ | Entry Stray Notification | |
| ⑤ | Entry Timeout Notification | |

| Menu | Function | Page |
|-------------------------------------|--|-----------|
| ⑥ | Expander Lost | |
| ⑦ | User Code Entry | |
| ⑧ | AC & Battery Fail Latch | |
| Programming Remote Keypads | | |
| ④ ① | Keypad Options 1 | 42 |
| ① | Partition 1 Operation | |
| ② | Partition 2 Operation | |
| ③ | Partition 3 Operation | |
| ④ | Partition 4 Operation | |
| ⑤ | Permanent Keypad Status Display | |
| ⑥ | Press Any Key for Display | |
| ⑦ | Display Zones vs. Partitions | |
| ⑧ | Wrong Code Attempts = Code Tamper | |
| ④ ① | Keypad Options 2 | 42 |
| ① | Code Tamper Causes a Tamper Alarm | |
| ② | Keypad Activation of Fire Alarm | |
| ③ | Keypad Activation of Medical Alarm | |
| ④ | Keypad Activation of PA Alarm | |
| ⑤ | Keypad PA Alarm is Silent | |
| ⑥ | Quick Arm with Keypad ARM Key | |
| ⑦ | Quick Disarm with Keypad DISARM Key | |
| ⑧ | Quick Bypass with Keypad BYPASS Key | |
| ④ ② | Keypad Options 3 | 42 |
| ① | Fire Alarm Tones from Keypad | |
| ② | Burglary Alarm Tones from Keypad | |
| ③ | Trouble Tones from Keypad | |
| ④ | Acceptance Tones from Keypad | |
| ⑤ | Error Tones from Keypad | |
| ⑥ | Chime Tones from Keypad | |
| ⑦ | Entry Tones from Keypad | |
| ⑧ | Exit Tones from Keypad | |
| ④ ③ | Keypad Options 4 | 43 |
| ① | Enable Keypad Zones (RKP8/16 Plus & Premier LCD/LCD-P/LCDDL/LCDDL-P) | |
| ② | Disable Keypad Lid Tamper | |
| ③ | Zone Shift by 4 | |
| ④ | Zone Shift by 8 | |
| ⑤ | Zone Shift by 16 | |
| Programming Remote Expanders | | |
| ⑤ ① | Expander Partitions | 44 |
| ① | Partition 1 Operation | |
| ② | Partition 2 Operation | |
| ③ | Partition 3 Operation | |
| ④ | Partition 4 Operation | |
| ⑤ ① | Expander Tones | 44 |
| ① | Fire Alarm Tones from Expander | |
| ② | Burglary Alarm Tones from Expander | |
| ③ | Trouble Tones from Expander | |
| ④ | Acceptance Tones from Expander | |
| ⑤ | Error Tones from Expander | |
| ⑥ | Chime Tones from Expander | |
| ⑦ | Entry Tones from Expander | |
| ⑧ | Exit Tones from Expander | |
| ⑤ ② | Expander Volume Level | 44 |

| Menu | Function | Page |
|--|----------------------|------|
| Programming System Outputs | | |
| ⑥ ① | Panel Outputs | 47 |
| ⑥ ① | Fast Format Channels | 47 |
| ⑥ ② | Expander 1 Outputs | 47 |
| ⑥ ③ | Expander 2 Outputs | 47 |
| ⑥ ④ | Expander 3 Outputs | 47 |
| ⑥ ⑤ | Keypad Outputs | 47 |
| ① System Output Types 00 Courtesy 18 Siren/Bell Fault 01 Successful Transmission 19 Smoke Sensor Fault 02 Log 80% Full 20 Auxiliary Fuse Fault 03 Program Mode Selected 21 Latched Battery Fault 04 Download In Progress 22 Service Required/Test Fail 05 Timed Arming Countdown 23 Fail To Communicate 06 Zone Soak Test Active 24 Control Timer 1 Active 07 Zone Soak Test Failed 25 Control Timer 2 Active 08 Latched AC Fail 26 Control Timer 3 Active 09 Telephone Line Fault 27 Control Timer 4 Active 10 Smoke Alarm 28 PC Output 1 11 Box/Auxiliary Tamper 29 PC Output 2 12 Date Time Loss 30 Walk Test 13 Zone Trouble/Tamper 31 Confirmed Alarm 14 Keypad Tamper/Removed 32 ARC 2 Active 15 Service Fault 33 Zones Locked Out 16 Output 1 Fault 34 AC Fail 17 Output 2 Fault 35 Battery Fault 36 Poll Timer ② Partition Output Types 00 PA Alarm 19 Bypass 01 Duress Alarm 20 Sensor Reset on Exit 02 Burglar Alarm 21 Sensor Reset on Reset 03 Medical Alarm 22 Single Pulse on Arming 04 24Hr - Water Alarm 23 Double Pulse on Arming 05 24Hr - Gas Alarm 24 Chime 06 24Hr - Low Temp Alarm 25 Door Strike 07 24Hr - High Temp Alarm 26 Cross Zone Time Active 08 Tamper 27 Single Pulse on Disarming 09 Trouble 28 Reset Required 10 Fire 29 Acknowledgement Required 11 Fire Fault 30 Confirmed Alarm 12 Bell 31 Alarm Abort 13 Strobe 32 Away Armed 14 Entry 33 Away Armed/Exit 15 Exit 34 Detector Latch 16 Armed 35 Armed/Alarm 17 Stay Armed 36 Arm Failed 18 Ready 37 All Armed ③ Zone Output Types 01 - 32 Zone Mimic 01 - 32 33 - 64 Zone Alarm 01 - 32 Output Attributes 1 Partition 1 5 User Test 2 Partition 2 6 Inverted 3 Partition 3 7 Latching 4 Partition 4 8 Pulsed | | |

| Menu | Function | Page |
|---|-------------------------|------|
| Programming The Communicator | | |
| ⑦ ① | Communicator Options | 52 |
| ① Enable On-Board Communicator ② Enable DTMF Dialling ③ Switch to Pulse Dialling after 3 rd Attempt ④ Enable European Pulse Dialling ⑤ Enable Auto Test Transmission ⑥ Enable Cancel Call Waiting ⑦ Enable Backup to Alarm Receiving Centre ⑧ Enable Blind Dialling | | |
| ⑦ ① | ARC 1 Communicator Menu | 52 |
| ① Primary and secondary telephone numbers ① Account Numbers (partitions 1-4) ② Protocol Type: ① Disabled ① Pulse Format ② Express Format ③ Fast Format/Speech Module ④ Contact ID ⑤ SIA Level 2/3 ⑥ Pager ⑦ Mobile Phone ③ Dial Attempts ④ Partition Options: ① Report for Partition 1 ② Report for Partition 2 ③ Report for Partition 3 ④ Report for Partition 4 ⑤ Reporting Options: ① Priority Alarm and Cancel Events ② Alarm and Cancel Events ③ Open and Close Events ④ Bypass and Unbypass Events ⑤ Maintenance Alarm Events ⑥ Tamper Alarm Events ⑦ Test Transmission Events ⑧ Restore Events ⑥ Pulse Format Options: ① Use 1900Hz Carrier ② Use 40 PPS Baud Rate ③ Enable Parity ④ Use 2 Digit Events ⑤ Use 2300Hz Handshake ⑥ Use 2300Hz Kiss-Off ⑦ Use Fast/Slow Format ⑦ Fast Format/Speech Reporting Channels ① Report Channel 1 ② Report Channel 2 ③ Report Channel 3 ④ Report Channel 4 ⑤ Report Channel 5 ⑥ Report Channel 6 ⑦ Report Channel 7 ⑧ Report Channel 8 ⑧ Protocol Options: ① Disable SIA Modifier Blocks/Enable Speech Module ② Disable Events for Each Partition ③ Pager Terminator = * (Star) ④ Send Pager Terminator Twice/Send SIA Text ⑤ Pager DTMF Tones = 500mS ⑥ Disable Zone Restorals ⑦ Communication Acknowledgement Tone ⑧ Connect via IP | | |

| Menu | Function | Page |
|-------------------------------------|--|------|
| ⑦ ② | ARC 2 Communicator Menu | 55 |
| ⑦ ③ | Fast Format/Speech Restore Channels | 55 |
| ① | Report Restore on Channel 1 | |
| ② | Report Restore on Channel 2 | |
| ③ | Report Restore on Channel 3 | |
| ④ | Report Restore on Channel 4 | |
| ⑤ | Report Restore on Channel 5 | |
| ⑥ | Report Restore on Channel 6 | |
| ⑦ | Report Restore on Channel 7 | |
| ⑧ | Report Restore on Channel 8 | |
| ⑦ ④ | Fast Format Open/Close Channels | 56 |
| ① | Report Open/Close on Channel 1 | |
| ② | Report Open/Close on Channel 2 | |
| ③ | Report Open/Close on Channel 3 | |
| ④ | Report Open/Close on Channel 4 | |
| ⑤ | Report Open/Close on Channel 5 | |
| ⑥ | Report Open/Close on Channel 6 | |
| ⑦ | Report Open/Close on Channel 7 | |
| ⑧ | Report Open/Close on Channel 8 | |
| ⑦ ⑤ | Cancel Call Waiting | 56 |
| Programming Download Options | | |
| ⑦ ⑥ | Download Menu | 57 |
| ⑩ | Download Options: | |
| ① | Enable Attended Download | |
| ② | Enable Unattended Call Back | |
| ③ | Enable 2-Call Answer Phone Defeat | |
| ④ | Restrict Download when Armed | |
| ⑤ | Download when Part Armed | |
| ⑥ | Disconnect Telephone Line | |
| ① | Download Telephone No | |
| ② | UDL Password | |
| ③ | Call Back Attempts | |
| ④ | Ring Count | |
| ⑤ | Com1 Device Type | |
| ⑥ | ComIP/SMG Address and Port | |
| ⑦ | ComIP Gateway | |
| ⑧ | ComIP Subnet Mask | |
| ⑨ | Com2 Device Type | |
| ● | Chiron Iris Data Setup | |
| ① | Access Point Name | |
| ② | User Name | |
| ③ | Password | |
| Programming Reporting Codes | | |
| ⑦ ⑦ | Zone Alarm/Restore Codes | 63 |
| ⑦ ⑧ | Zone Bypass/Unbypass Codes | 63 |
| ⑦ ⑨ | Non Zone Alarm/Restore Codes | 63 |
| Programming Users | | |
| ⑧ ⑩ | Program User | 66 |
| ⑧ ① | User Options 1 | 66 |
| ① | Enable for Partition 1 | |
| ② | Enable for Partition 2 | |
| ③ | Enable for Partition 3 | |
| ④ | Enable for Partition 4 | |
| ⑤ | Allow Arming | |
| ⑥ | Allow Bypassing | |
| ⑦ | Allow Disarming | |
| ⑧ | Allow User Functions | |
| ⑧ ② | User Options 2 | 66 |
| ① | Enable One Time Use Access Code | |

| Menu | Function | Page |
|-----------------------------------|--------------------------------------|----------------------|
| ② | Time Lock Code with Control Timer 1 | |
| ③ | Enable Open Reporting | |
| ④ | Enable Close Reporting | |
| ⑤ | Enable User as Duress Code | |
| ⑥ | Activate Door Strike Output | |
| ⑦ | Allow Global Bell/Sounder Silence | |
| ⑧ | Disable Remote Access | |
| ⑧ ③ | User Options 3 | 67 |
| ① | Allow Engineer Code Programming | |
| ② | Allow NVM Locking | |
| ③ | Allow Engineer Programming | |
| ④ | Allow Test Call Transmission | |
| ⑤ | Allow Alarm/Fault Acknowledgement | |
| ⑥ | Allow User Programming | |
| ⑦ | Allow User Code Programming | |
| ⑧ | Local Partition Access Only | |
| ⑧ ④ | User Text | 67 |
| ① | .,?!1@ "- & | ⑦ p q r s 7 P Q R S |
| ② | a b c 2 A B C | ⑧ t u v 8 T U V |
| ③ | d e f 3 D E F | ⑨ w x y z 9 W X Y Z |
| ④ | g h I 4 G H I | ⑩ Space 0 , # * |
| ⑤ | j k I 5 J K L | ↔ Move Left/Right |
| ⑥ | m n o 7 M N O | ⌫ Backspace (delete) |
| ⑧ ⑤ | Program Standard Users | 67 |
| ⑧ ⑥ | Default ALL Users | 67 |
| System Tests and Utilities | | |
| ⑨ ⑩ | Walk Test | 69 |
| ⌫ | Clears previously tested zones | |
| ⑨ ① | Test Speakers and Outputs | 69 |
| ① | Test Speakers | ④ Test Outputs |
| ② | Test Bells | ⑤ Test LCD Display |
| ③ | Test Strobes | |
| ⑨ ② | Send Test Call | 69 |
| ⑨ ③ | Enable Remote/Engineer Access | 69 |
| ⑨ ④ | Start Call Back | 69 |
| ⑨ ⑤ | Program Time | 69 |
| ⑨ ⑥ | Program Date | 69 |
| ⑨ ⑦ | Program Banner Text | 69 |
| ① | .,?!1@ "- & | ⑦ p q r s 7 P Q R S |
| ② | a b c 2 A B C | ⑧ t u v 8 T U V |
| ③ | d e f 3 D E F | ⑨ w x y z 9 W X Y Z |
| ④ | g h I 4 G H I | ⑩ Space 0 , # * |
| ⑤ | j k I 5 J K L | ↔ Move Left/Right |
| ⑥ | m n o 7 M N O | ⌫ Backspace (delete) |
| ⑨ ⑧ | Print 100 Events | 69 |
| ⑨ ⑨ | Log Off Engineer | 69 |

| Service Faults Displayed on LED Keypads | |
|---|--|
| Light | Fault Condition |
| 1 | General Warnings Press ① to view type, lights 1 - 5 indicate: 1 = AC Fail 2 = Arming Fob has Low Battery 3 = Soak Test Active |
| | |
| | |
| 2 | Telephone Line Fault |
| 3 | 2-Wire Smoke Alarm |
| 4 | Box Tamper & Auxiliary Input: Press ④ to view type, lights 1 - 5 indicate: 1 = Box Tamper 4 = Auxiliary Tamper 2 = Auxiliary Tamper 5 = Bell Tamper 3 = Auxiliary PA 6 = RadioPlus Tamper 7 = Low Fob Battery detected |
| | |
| | |
| 5 | Date or Time Lost |
| 6 | Zone Tamper/Trouble Press ⑥ to view zone number |
| 7 | Keypad Tamper/Removed Press ⑦ to view keypad number |
| 8 | Equipment Faults Press ⑧ to view fault type, lights 1 - 8 indicate: 1 = Output 1 Fault 2 = Output 2 Fault 3 = Siren/Bell Fault 4 = 2-Wire Smoke Sensor Fault 5 = Auxiliary Fuse Failed 6 = Battery Fault 7 = Service Timer/Zone Soak Test Failed 8 = Com1 Fault or Fail To Communicate |
| | |
| | |

| Service Faults Displayed on LCD Keypads | |
|---|-------------------------------------|
| LCD | Fault Condition |
| AC Fail | AC Fail |
| Line Fault | Telephone Line Fault |
| Smoke Alarm (2W) | 2-Wire Smoke Alarm |
| Box/Aux Tamper | Box Tamper |
| Aux Tamper | Auxiliary Tamper (Aux Input) |
| Auxiliary Tamper | Auxiliary Tamper (UK Bell Module) |
| Bell Tamper | Bell Tamper (UK Bell Module) |
| Aux PA Alarm | Auxiliary PA (Aux Input) |
| Date/Time Loss | Date or Time Lost |
| Tamper Zone > 01 | Zone Tamper/Trouble |
| Tamper Keypad > 1 | Keypad Tamper/Removed |
| Output 1 Fault | Output 1 Fault |
| Output 2 Fault | Output 2 Fault |
| Siren Fault | Siren/Bell Fault |
| Smoke Sen. Fault | 2-Wire Smoke Sensor Fault |
| Aux. Fuse Fault | Auxiliary Fuse Failed |
| Battery Fault | Battery Fault |
| Service Required | Service Timer/Zone Soak Test Failed |
| Coms Fault | Com1 Fault or Fail To Communicate |

| User Functions | |
|----------------------------------|---------------------------------|
| Enter User Code ①②③④ followed by | |
| ①②③④ 0 | Reset Alarm/Troubles |
| ①②③④ 1 | View Last Alarm |
| ①②③④ 2 | View/Acknowledge Service Faults |
| ①②③④ 3 | Anti-code Remote Reset |
| ①②③④ 4 | Toggle Chime On and Off |
| ①②③④ 5 | Change Own Passcode |
| ①②③④ 6 | View Event Log (LCD Only) |
| ①②③④ 7 | Abort Communications |
| ①②③④ 9 | Select User Programming Mode |

8. Standard Defaults & Programming Records

Installation Details

Customer: _____

Address: _____

Telephone: _____ Fax: _____

Email: _____

Alarm Receiving Centre 1:

Alarm Receiving Centre 2:

Installation Date:

Zone Details

| Zone | Location | Zone | Location |
|------|----------|------|----------|
| 01 | | 17 | |
| 02 | | 18 | |
| 03 | | 19 | |
| 04 | | 20 | |
| 05 | | 21 | |
| 06 | | 22 | |
| 07 | | 23 | |
| 08 | | 24 | |
| 09 | | 25 | |
| 10 | | 26 | |
| 11 | | 27 | |
| 12 | | 28 | |
| 13 | | 29 | |
| 14 | | 30 | |
| 15 | | 31 | |
| 16 | | 32 | |

Programming Worksheets & Defaults

These worksheets and defaults apply to the following control panels where standard factory defaults are loaded, if you load country defaults as per page 36 the defaults shown may differ.

- Premier 412/816 - Software Version 12.x >
- Premier 832 - Software Version 12.x >

| Zone Programming | | | | | | |
|------------------|---------|------------------------|------------|---------|-----------|--------------------------|
| Menu: ① ① | | | Zone Types | | | Page 25 |
| Zone | Type | Default | Zone | Type | Default | Zone Types |
| 01 | [] [] | 01 (Delay 1) | 17 | [] [] | 00 (Null) | 00: Null |
| 02 | [] [] | 03 (Interior Follower) | 18 | [] [] | 00 (Null) | 01: Delay 1 |
| 03 | [] [] | 05 (Perimeter Instant) | 19 | [] [] | 00 (Null) | 02: Delay 2 |
| 04 | [] [] | 05 (Perimeter Instant) | 20 | [] [] | 00 (Null) | 03: Interior Follower |
| 05 | [] [] | 05 (Perimeter Instant) | 21 | [] [] | 00 (Null) | 04: Interior Instant |
| 06 | [] [] | 05 (Perimeter Instant) | 22 | [] [] | 00 (Null) | 05: Perimeter Instant |
| 07 | [] [] | 05 (Perimeter Instant) | 23 | [] [] | 00 (Null) | 06: Fire |
| 08 | [] [] | 05 (Perimeter Instant) | 24 | [] [] | 00 (Null) | 07: PA Silent |
| 09 | [] [] | 00 (Null) | 25 | [] [] | 00 (Null) | 08: PA Audible |
| 10 | [] [] | 00 (Null) | 26 | [] [] | 00 (Null) | 09: Medical |
| 11 | [] [] | 00 (Null) | 27 | [] [] | 00 (Null) | 10: 24-Hour Tamper |
| 12 | [] [] | 00 (Null) | 28 | [] [] | 00 (Null) | 11: Trouble |
| 13 | [] [] | 00 (Null) | 29 | [] [] | 00 (Null) | 12: 24-Hour - Gas |
| 14 | [] [] | 00 (Null) | 30 | [] [] | 00 (Null) | 13: 24-Hour - Water |
| 15 | [] [] | 00 (Null) | 31 | [] [] | 00 (Null) | 14: 24-Hour - High Temp |
| 16 | [] [] | 00 (Null) | 32 | [] [] | 00 (Null) | 15: 24-Hour - Low Temp |
| | | | | | | 16: Momentary Keyswitch |
| | | | | | | 17: Maintained Keyswitch |
| | | | | | | 18: Push To Set |

| Zone Wiring | | | | | | |
|-------------|------|---------------------|------|------|---------------------|--------------------------------------|
| Menu: ① ② | | | | | | Page 27 |
| Zone | Type | Default | Zone | Type | Default | Wiring Types |
| 01 | [] | 0 (Normally Closed) | 17 | [] | 0 (Normally Closed) | 0: Normally Closed |
| 02 | [] | 0 (Normally Closed) | 18 | [] | 0 (Normally Closed) | 1: Normally Open |
| 03 | [] | 0 (Normally Closed) | 19 | [] | 0 (Normally Closed) | 2: Single EOL - N/C & N/O (Burglary) |
| 04 | [] | 0 (Normally Closed) | 20 | [] | 0 (Normally Closed) | 3: Single EOL - N/O (Fire) |
| 05 | [] | 0 (Normally Closed) | 21 | [] | 0 (Normally Closed) | 4: Single EOL - N/C |
| 06 | [] | 0 (Normally Closed) | 22 | [] | 0 (Normally Closed) | 5: Single EOL - O/C Tamper |
| 07 | [] | 0 (Normally Closed) | 23 | [] | 0 (Normally Closed) | 6: Single EOL - S/C Tamper |
| 08 | [] | 0 (Normally Closed) | 24 | [] | 0 (Normally Closed) | 7: Double EOL |
| 09 | [] | 0 (Normally Closed) | 25 | [] | 0 (Normally Closed) | 8: Zone Doubled |
| 10 | [] | 0 (Normally Closed) | 26 | [] | 0 (Normally Closed) | |
| 11 | [] | 0 (Normally Closed) | 27 | [] | 0 (Normally Closed) | |
| 12 | [] | 0 (Normally Closed) | 28 | [] | 0 (Normally Closed) | |
| 13 | [] | 0 (Normally Closed) | 29 | [] | 0 (Normally Closed) | |
| 14 | [] | 0 (Normally Closed) | 30 | [] | 0 (Normally Closed) | |
| 15 | [] | 0 (Normally Closed) | 31 | [] | 0 (Normally Closed) | |
| 16 | [] | 0 (Normally Closed) | 32 | [] | 0 (Normally Closed) | |

| Zone Attributes 1 | | | | | | | | | |
|-------------------|-------------------------------|------------------|-------------------|------------------|----------------------------|------------------------|--------------------------------|--------------------------|---------|
| Menu: ① ③ | | | | | | | | | Page 27 |
| Zone | Enable Instant Internals 1 | Enable Bell 2 | Delayed Bell 3 | Pulsed Bell 4 | Enable Instant Strobe 5 | Enable User Chime 6 | Enable Transmission Delay 7 | Enable Transmission 8 | |
| 01 | [] XX | [] ✓✓ | [] ✓✓ | [] XX | [] XX | [] ✓✓ | [] ✓✓ | [] ✓✓ | |
| 02 | [] XX | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 03 | [] XX | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 04 | [] XX | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 05 | [] XX | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 06 | [] XX | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 07 | [] XX | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 08 | [] XX | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 09 | [] XX | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 10 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 11 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 12 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 13 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |

| Menu: ① ③ | | Zone Attributes 1 | | | | | | | | Page 27 |
|---|--------|-------------------|--------|--------|--------|--------|--------|--------|--------|---------|
| 14 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 15 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 16 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 17 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 18 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 19 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 20 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 21 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 22 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 23 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 24 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 25 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 26 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 27 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 28 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 29 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 30 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 31 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 32 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| ✓✓ = Default setting is ON XX = Default setting is OFF | | | | | | | | | | |

| Menu: ① ④ | | Zone Attributes 2 | | | | | | | | Page 26 |
|---|---------------------------|-------------------------|--------------------------|--------------------------|--------------------------|-----------------------|------------------------------|--------------------------|--|---------|
| Zone | Enable Manual Bypass 1 | Enable Stay Bypass 2 | Enable Force Arming 3 | Quick Response Time 4 | Enable Cross Zoning 5 | Enable Soak Test 6 | Enable Swinger Shutdown 7 | Enable Double Knock 8 | | |
| 01 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] ✓✓ | [] XX | | |
| 02 | [] ✓✓ | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] ✓✓ | [] XX | | |
| 03 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] ✓✓ | [] XX | | |
| 04 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] ✓✓ | [] XX | | |
| 05 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] ✓✓ | [] XX | | |
| 06 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] ✓✓ | [] XX | | |
| 07 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] ✓✓ | [] XX | | |
| 08 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] ✓✓ | [] XX | | |
| 09 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | | |
| 10 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | | |
| 11 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | | |
| 12 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | | |
| 13 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | | |
| 14 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | | |
| 15 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | | |
| 16 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | | |
| 17 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | | |
| 18 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | | |
| 19 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | | |
| 20 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | | |
| 21 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | | |
| 22 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | | |
| 23 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | | |
| 24 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | | |
| 25 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | | |
| 26 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | | |
| 27 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | | |
| 28 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | | |
| 29 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | | |
| 30 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | | |
| 31 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | | |
| 32 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | | |
| ✓✓ = Default setting is ON XX = Default setting is OFF | | | | | | | | | | |

| Menu: ① ⑤ | | Zone Attributes 3 | | | | | | Page 28 | |
|-----------|------------------------------------|-------------------------------------|---------------------|--------------------------------------|--------------------------------------|----------------------------|--------------------------|-----------------------|--|
| Zone | Change to Delay 1 on Stay Arm 1 | Change to Follower on Stay Arm 2 | * Zone Warning 3 | * Auto Reinstate if Force Armed 4 | Disable Keyswitch if Away Armed 5 | * Disable Exit Faults 6 | Truncate Exit Delay 7 | Forced Walk Test 8 | |
| 01 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 02 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 03 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 04 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 05 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 06 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 07 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 08 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 09 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 10 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 11 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 12 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 13 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 14 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 15 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 16 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 17 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 18 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 19 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 20 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 21 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 22 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 23 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 24 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 25 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 26 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 27 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 28 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 29 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 30 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 31 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 32 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |

✓✓ = Default setting is ON
 XX = Default setting is OFF
 * = Attributes 3, 4, 6 & 7 change when zone is programmed as a key switch type:
 3 = Key Switch is Instant Arming
 4 = Key Switch will Stay Arm/Disarm
 6 = Disable Auto Arm
 7 = Monitor Only

| Menu: ① ⑥ | | Zone Partitions & Bypass Groups | | | | | | Page 29 | |
|-----------|------------------------------|---------------------------------|------------------------------|------------------------------|---------------------------------|---------------------------------|---------------------------------|---------------------------------|--|
| Zone | Enabled for Partition 1 1 | Enabled for Partition 2 2 | Enabled for Partition 3 3 | Enabled for Partition 4 4 | Enabled for Bypass Group 1 5 | Enabled for Bypass Group 2 6 | Enabled for Bypass Group 3 7 | Enabled for Bypass Group 4 8 | |
| 01 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 02 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 03 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 04 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 05 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 06 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 07 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 08 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 09 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 10 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 11 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 12 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 13 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 14 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 15 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 16 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 17 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |

| Menu: ① ⑥ | | Zone Partitions & Bypass Groups | | | | | | | | Page 29 |
|-----------|--------|---------------------------------|--------|--------|--------|--------|--------|--------|--------|---------|
| 18 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 19 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 20 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 21 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 22 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 23 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 24 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 25 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 26 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 27 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 28 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 29 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 30 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 31 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |
| 32 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | |

✓✓ = Default setting is ON
XX = Default setting is OFF

| Menu: ① ⑦ | | Zone Text (LCD Only) | | Page 27 |
|-----------|------|----------------------|------|---|
| Zone | Text | Zone | Text | Editing Keys |
| 01 | | 17 | | ① .,?!1@ "- & ② abc2ABC ③ def3DEF ④ ghi4GHI ⑤ jkl5JKL ⑥ mno7MNO ⑦ pqr7PQRS ⑧ tuv8TUV ⑨ wxyz9WXYZ ⑩ Space 0, # * ⬅ Move Left/Right ⌫ Backspace (delete) |
| 02 | | 18 | | |
| 03 | | 19 | | |
| 04 | | 20 | | |
| 05 | | 21 | | |
| 06 | | 22 | | |
| 07 | | 23 | | |
| 08 | | 24 | | |
| 09 | | 25 | | |
| 10 | | 26 | | |
| 11 | | 27 | | |
| 12 | | 28 | | |
| 13 | | 29 | | |
| 14 | | 30 | | |
| 15 | | 31 | | |
| 16 | | 32 | | |

| Partition Programming | | | | | | | | | | | | |
|-----------------------|-------------------------------|-------------------------------|-------------------------------|-------------------------------|----------------------------------|----------------------------------|----------------------------------|---|---|---------|---|-------------|
| Menus: ②① - ②⑤ | | Partition Timers | | | | | | Page 29 | | | | |
| Partition Timer | | 1 | | 2 | | 3 | | 4 | | Default | | |
| ②① | Exit Time | [|] | [|] | [|] | [|] | [|] | 020 Seconds |
| ②① | Entry Delay 1 | [|] | [|] | [|] | [|] | [|] | 015 Seconds |
| ②② | Entry Delay 2 | [|] | [|] | [|] | [|] | [|] | 030 Seconds |
| ②③ | Comms Delay | [|] | [|] | [|] | [|] | [|] | 000 Minutes |
| ②④ | Bell Delay | [|] | [|] | [|] | [|] | [|] | 000 Minutes |
| ②⑤ | Bell Duration | [|] | [|] | [|] | [|] | [|] | 015 Minutes |
| Menu: ②⑥ | | Partition Options | | | | | | Page 31 | | | | |
| Partition | Enable Auto Bypass Mode | Stay Armed Exit is Silent | Enable Remote Arming | Enable Remote Disarming | Enable Local Exit Tones | Stay Armed Entry is Instant | Stay Armed Exit is Delayed | Only Start Exit when Partition is Ready | | | | |
| | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | | | | |
| 1 | []X | []X | []X | []X | []X | []X | []X | []X | | | | |
| 2 | []X | []X | []X | []X | []X | []X | []X | []X | | | | |
| 3 | []X | []X | []X | []X | []X | []X | []X | []X | | | | |
| 4 | []X | []X | []X | []X | []X | []X | []X | []X | | | | |
| Menu: ②⑦ | | Partition Auto Arm/Disarm | | | | | | Page 30 | | | | |
| Partition | Auto Arm with Control Timer 1 | Auto Arm with Control Timer 2 | Auto Arm with Control Timer 3 | Auto Arm with Control Timer 4 | Auto Disarm with Control Timer 1 | Auto Disarm with Control Timer 2 | Auto Disarm with Control Timer 3 | Auto Disarm with Control Timer 4 | | | | |
| | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | | | | |
| 1 | []X | []X | []X | []X | []X | []X | []X | []X | | | | |
| 2 | []X | []X | []X | []X | []X | []X | []X | []X | | | | |
| 3 | []X | []X | []X | []X | []X | []X | []X | []X | | | | |

| Partition Programming | | | | | | | | | |
|--------------------------|------------|-----------------|-------|-------|-------|-------|-------|---------|-------|
| 4 | [] X | [] X | [] X | [] X | [] X | [] X | [] X | [] X | [] X |
| Menu: ② ⑧ | | Equipment Areas | | | | | | Page 30 | |
| Options | Partitions | | | | | | | | |
| | 1 | | 2 | | 3 | | 4 | | |
| 0: Auxiliary Input Areas | [] | ✓✓ | [] | X | [] | X | [] | X | [] |
| 1: Panel Bell Areas | [] | ✓✓ | [] | X | [] | X | [] | X | [] |
| 2: Bell Squawk Areas | [] | ✓✓ | [] | X | [] | X | [] | X | [] |

| Global Programming | | | | | | | | | |
|--|--|---------------------------------------|---|---|-----------------------------------|------------------------------------|---|---------|-------------|
| Menu: ③ ① | | Global System Timers | | | | | | Page 33 | |
| Timer | Value | | Default | | Timer | Value | | Default | |
| 00: AC Fail Delay | [] | [] | [] | 001 Minutes | 08: Test Transmission Time | [] | [] | [] | 024 Hours |
| 01: Line Fault Delay | [] | [] | [] | 001 Seconds | 09: Courtesy Delay | [] | [] | [] | 060 Seconds |
| 02: Cross Zone Time | [] | [] | [] | 030 Seconds | 10: Service Timer | [] | [] | [] | 000 Weeks |
| 03: Zone Soak Test Time | [] | [] | [] | 014 Days | 11: 2-Wire Verified Delay | [] | [] | [] | 000 Seconds |
| 04: Restore Reporting Delay | [] | [] | [] | 030 Minutes | 12: Alarm Confirmation Delay | [] | [] | [] | 045 Minutes |
| 05: Output Short Pulse Time | [] | [] | [] | 050 x 100mS | 13: Activity Time Window | [] | [] | [] | 048 Hours |
| 06: Zone Response Time | [] | [] | [] | 010 x 80mS | 14: Poll IP Every | [] | [] | [] | 000 Minutes |
| 07: Transmission Abort | [] | [] | [] | 180 Seconds | | | | | |
| Menu: ③ ① | | Global Counter/Levels | | | | | | Page 36 | |
| Counter/Level | Value | | Default | | Counter/Level | Value | | Default | |
| 0: Swinger Shutdown Count | [] | [] | [] | 003 | 2: Chime Volume | [] | | | 7 |
| 1: Panel Speaker Volume | [] | | | 4 | 3: Clock Adjustment | [] | [] | | 50 |
| Menu: ③ ② | | Control Timers | | | | | | Page 34 | |
| Timer | ON/OFF Time | | | | Days of Operation | | | | |
| 1 | ON: | [] | [] | [] | [] | [] | [] | [] | [] |
| | OFF: | [] | [] | [] | [] | [] | [] | [] | [] |
| 2 | ON: | [] | [] | [] | [] | [] | [] | [] | [] |
| | OFF: | [] | [] | [] | [] | [] | [] | [] | [] |
| 3 | ON: | [] | [] | [] | [] | [] | [] | [] | [] |
| | OFF: | [] | [] | [] | [] | [] | [] | [] | [] |
| 4 | ON: | [] | [] | [] | [] | [] | [] | [] | [] |
| | OFF: | [] | [] | [] | [] | [] | [] | [] | [] |
| Menu: ③ ③ | | System Options 1 | | | | | | Page 36 | |
| Clock = Crystal | Battery Connection Supervision | Battery Dynamically Load Tested | Panel NVM is Locked | Power Savings During AC Mains Failure | Line Fault Overrides Bell Delay | 2-Wire Smoke Detection on O/P 1 | Convert Siren Output from Voltage to Speaker Driver | | |
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | | |
| [] XX | [] ✓✓ | [] XX | [] XX | [] ✓✓ | [] ✓✓ | [] XX | [] ✓✓ | | |
| Menu: ③ ④ | | System Options 2 | | | | | | Page 37 | |
| Tamper Alarms Cause a Trouble While Disarmed | Tamper Alarms Cause a Trouble While Stay Armed | Defer Reporting of Non-Zone Restorals | Use Delay Timer to Defer Non-Zone Restorals | Inhibit Keyswitch Operation on EOL Tamper | Away Arm Overrides Alarm Tx Delay | Defer Reporting of Zone Restorals | Use Delay Timer to Defer Zone Restorals | | |
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | | |
| [] ✓✓ | [] ✓✓ | [] ✓✓ | [] XX | [] XX | [] ✓✓ | [] XX | [] XX | | |
| Menu: ③ ⑤ | | System Options 3 | | | | | | Page 37 | |
| Away Arm Exit Error Doesn't Sound Bell | Zone Test - Silence on No Violation | Alarm Status Light Indicates Fire | Enable Entry/Exit Tones for Panel Speaker | Enable Cross Partitioning | Enable EN 50131-1 Requirements | Reinstate Bypassed Zones on Disarm | Invert Panel Siren Output | | |
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | | |
| [] XX | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] ✓✓ | [] XX | | |
| Menu: ③ ⑥ | | Hardware Options | | | | | | Page 38 | |
| Panel Output 1 Supervised for Faults | Panel Output 2 Supervised for Faults | Siren/Bell O/P Supervised for Faults | Panel Box Tamper Switch Monitored | Auxiliary Fuse Supervised for Faults | Battery Supervised for Faults | AC Mains Supply is Monitored | Telephone Line Is Monitored | | |
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | | |
| [] XX | [] XX | [] XX | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | | |
| Menu: ③ ⑦ | | Auxiliary Input | | | | | | Page 38 | |
| Value | Default | | Types | | | | | | |

Global Programming

| | | | | | | | |
|--|--|--|---|---|---|--|--|
| [] | 0 | 0: Not Used; 1: Auxiliary Tamper; 2: Remote Reset; 3: Line Fault; 4: Panic Alarm; 5: Silent PA; 6: Latched Key Switch; 7: Momentary Key Switch | | | | | |
| Menu: ③ ⑧ ① Miscellaneous Options 1 Page 38 | | | | | | | |
| Enable Bell Squawk on AWAY Arm/Disarm 1 | Enable Bell Squawk on STAY Arm/Disarm 2 | Disable AC Fail Ack. 3 | Disable Open/Close Reporting on STAY Arm 4 | Cross/Double Knock Timer is in Minutes 5 | Disable Zone Bypass when Armed 6 | Activated Zones Cause Alarm during Exit 7 | Control Timer 4 Performs Battery Test 8 |
| [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| Menu: ③ ⑧ ② Miscellaneous Options 2 Page 39 | | | | | | | |
| Disable Service Fault Ack. 1 | Enable User Reset for Alarms 2 | Disable On-line Printing 3 | Enable UK Bell Module 4 | Enable DD243: 2002 Options 5 | Enable Confirmation after Entry Time-Out 6 | Invert Auxiliary Input Operation 7 | Auto BST/GMT Time Change 8 |
| [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| Menu: ③ ⑧ ③ Miscellaneous Options 3 Page 39 | | | | | | | |
| Allow User Tamper Reset 1 | Allow Engineer Access when Armed 2 | | | | | | |
| [] XX | [] XX | | | | | | |
| Menu: ③ ⑨ EN50131 Page 39 | | | | | | | |
| Confirm Low fob Battery on Arm 1 | Soak Test Active Indication 2 | Soak Test Acknowledge Required 3 | Entry Stray Notification Delay 4 | Entry Timeout Notify Delay 5 | Cable Cut Expander Tamper 6 | User Code Entry Timed 7 | Power Failure Latch 8 |
| [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |

Remote Keypad Programming

| Menu: ④ ① Remote Keypad Options 1 Page 42 | | | | | | | | |
|--|--|---------------------------------------|---|------------------------------------|--------------------------------------|------------------------------------|--|--|
| Keypad | Partition 1 Operation 1 | Partition 2 Operation 2 | Partition 3 Operation 3 | Partition 4 Operation 4 | Permanent Keypad Status Display 5 | Press any Key for Display 6 | Display Zones vs. Partitions 7 | Wrong Code Attempts = Code Tamper 8 |
| 1 | [] ✓✓ | [] XX | [] XX | [] XX | [] ✓✓ | [] XX | [] ✓✓ | [] XX |
| 2 | [] ✓✓ | [] XX | [] XX | [] XX | [] ✓✓ | [] XX | [] ✓✓ | [] XX |
| 3 | [] ✓✓ | [] XX | [] XX | [] XX | [] ✓✓ | [] XX | [] ✓✓ | [] XX |
| 4 | [] ✓✓ | [] XX | [] XX | [] XX | [] ✓✓ | [] XX | [] ✓✓ | [] XX |
| 5 | [] ✓✓ | [] XX | [] XX | [] XX | [] ✓✓ | [] XX | [] ✓✓ | [] XX |
| 6 | [] ✓✓ | [] XX | [] XX | [] XX | [] ✓✓ | [] XX | [] ✓✓ | [] XX |
| Menu: ④ ① Remote Keypad Options 2 Page 39 | | | | | | | | |
| Keypad | Code Tamper Causes a Tamper Alarm 1 | Keypad Activation of Fire Alarm 2 | Keypad Activation of Medical Alarm 3 | Keypad Activation of PA Alarm 4 | Keypad PA Alarm is Silent 5 | Quick Arm with Keypad ARM Key 6 | Quick Disarm with Keypad DISARM Key 7 | Quick Bypass with Keypad BYPASS Key 8 |
| 1 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 2 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 3 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 4 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 5 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 6 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| Menu: ④ ② Remote Keypad Options 3 Page 42 | | | | | | | | |
| Keypad | Fire Alarm Tones from Keypad 1 | Burglary Alarm Tones from Keypad 2 | Trouble Tones from Keypad 3 | Acceptance Tones from Keypad 4 | Error Tones from Keypad 5 | Chime Tones from Keypad 6 | Entry Tones from Keypad 7 | Exit Tones from Keypad 8 |
| 1 | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ |
| 2 | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ |
| 3 | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ |
| 4 | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ |
| 5 | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ |
| 6 | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ |

Remote Keypad Programming

Menu: ④③

Remote Keypad Options 4

Page 43

| Keypad | Enable Keypad Zones 1 | Disable Keypad Lid Tamper 2 | Zone Shift by 4 3 | Zone Shift by 8 4 | Zone Shift by 16 5 | Reserved 6 | Reserved 7 | Reserved 8 |
|--------|--------------------------|--------------------------------|-------------------------|-------------------------|--------------------------|---------------|---------------|---------------|
| 1 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 2 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 3 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 4 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 5 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 6 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |

Expander Programming

Menu: ⑤①

Expander Partitions

Page 44

| Exp. | Partition 1 1 | Partition 2 2 | Partition 3 3 | Partition 4 4 | Reserved 5 | Reserved 6 | Reserved 7 | Reserved 8 |
|------|------------------|------------------|------------------|------------------|---------------|---------------|---------------|---------------|
| 1 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 2 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 3 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |

Menu: ⑤①

Expander Tones

Page 44

| Exp. | Fire Alarm Tones from Expander 1 | Burglary Alarm Tones from Expander 2 | Trouble Tones from Expander 3 | Acceptance Tones from Expander 4 | Error Tones from Expander 5 | Chime Tones from Expander 6 | Entry Tones from Expander 7 | Exit Tones from Expander 8 |
|------|-------------------------------------|---|----------------------------------|-------------------------------------|--------------------------------|--------------------------------|--------------------------------|-------------------------------|
| 1 | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ |
| 2 | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ |
| 3 | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ |

Menu: ⑤②

Expander Volume

Page 44

| Exp. 1 | [] | Default 4 | Exp. 2 | [] | Default 4 | Exp. 3 | [] | Default 4 |
|--------|-----|-----------|--------|-----|-----------|--------|-----|-----------|
|--------|-----|-----------|--------|-----|-----------|--------|-----|-----------|

Output Programming

Menu: ⑥①

Panel Outputs

Page 47

| Output | Group & Type | Default | Part. 1 1 | Part. 2 2 | Part. 3 3 | Part. 4 4 | Test 5 | Invert 6 | Latch 7 | Pulsed 8 |
|--------|--------------|---------|--------------|--------------|--------------|--------------|-----------|-------------|------------|-------------|
| 1 | []: [] [] | 2:12 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 2 | []: [] [] | 2:13 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 3 | []: [] [] | 2:10 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 4 | []: [] [] | 2:01 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 5 | []: [] [] | 2:02 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 6 | []: [] [] | 2:16 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 7 | []: [] [] | 2:31 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 8 | []: [] [] | 2:30 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |

Menu: ⑥①

Fast Format/Speech Channels

Page 47

| Output | Group & Type | Default | Part. 1 1 | Part. 2 2 | Part. 3 3 | Part. 4 4 | Test 5 | Invert 6 | Latch 7 | Pulsed 8 |
|--------|--------------|---------|--------------|--------------|--------------|--------------|-----------|-------------|------------|-------------|
| 1 | []: [] [] | 2:10 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 2 | []: [] [] | 2:00 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 3 | []: [] [] | 2:02 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 4 | []: [] [] | 2:16 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 5 | []: [] [] | 2:31 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 6 | []: [] [] | 2:17 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 7 | []: [] [] | 2:01 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 8 | []: [] [] | 2:30 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |

| Menu: ⑥ ② | | Expander Outputs | | | | | | | | Page 47 |
|-----------|---------------|------------------|--------------|--------------|--------------|--------------|-----------|-------------|------------|-------------|
| Output | Group & Type | Default | Part. 1 1 | Part. 2 2 | Part. 3 3 | Part. 4 4 | Test 5 | Invert 6 | Latch 7 | Pulsed 8 |
| 1.1 | [] : [] [] | 0:00 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 2.2 | [] : [] [] | 0:00 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 2.1 | [] : [] [] | 0:00 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 2.2 | [] : [] [] | 0:00 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 3.1 | [] : [] [] | 0:00 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 3.2 | [] : [] [] | 0:00 | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |

| Menu: ⑥ ⑤ | | Keypad Outputs | | | | | | | | Page 47 |
|-----------|---------------|----------------|--------------|--------------|--------------|--------------|-----------|-------------|------------|-------------|
| Output | Group & Type | Default | Part. 1 1 | Part. 2 2 | Part. 3 3 | Part. 4 4 | Test 5 | Invert 6 | Latch 7 | Pulsed 8 |
| 1 | [] : [] [] | 0:00 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 2 | [] : [] [] | 0:00 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 3 | [] : [] [] | 0:00 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 4 | [] : [] [] | 0:00 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 5 | [] : [] [] | 0:00 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| 6 | [] : [] [] | 0:00 | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |

| Output Types | | | |
|--------------|-----------------------------|--------------------------------|----------------------------|
| Output Group | System Output Types | | Partition Output Types |
| 0: Not Used | 00: Courtesy | 19: Smoke Sensor Fault | 00: PA Alarm |
| 1: System | 01: Successful Transmission | 20: Auxiliary Fuse Fault | 01: Duress Alarm |
| 2: Partition | 02: Log 80% Full | 21: Latched Battery Fault | 02: Burglar Alarm |
| 3: Zone | 03: Program Mode Selected | 22: Service Required/Test Fail | 03: Medical Alarm |
| | 04: Download In Progress | 23: Fail To Communicate | 04: 24Hr - Water Alarm |
| | 05: Timed Arming Countdown | 24: Control Timer 1 Active | 05: 24Hr - Gas Alarm |
| | 06: Zone Soak Test Active | 25: Control Timer 2 Active | 06: 24Hr - Low Temp Alarm |
| | 07: Zone Soak Test Failed | 26: Control Timer 3 Active | 07: 24Hr - High Temp Alarm |
| | 08: Latched AC Fail | 27: Control Timer 4 Active | 08: Tamper |
| | 09: Telephone Line Fault | 28: PC Output 1 | 09: Trouble |
| | 10: Smoke Alarm | 29: PC Output 2 | 10: Fire |
| | 11: Box/Auxiliary Tamper | 30: Walk Test | 11: Fire Fault |
| | 12: Date Time Loss | 31: Confirmed Alarm | 12: Bell |
| | 13: Zone Trouble/Tamper | 32: ARC 2 Active | 13: Strobe |
| | 14: Keypad Tamper/Removed | 33: Zones Locked Out | 14: Entry |
| | 15: Service Fault | 34: AC Fail | 15: Exit |
| | 16: Output 1 Fault | 35: Battery Fault | 16: Armed |
| | 17: Output 2 Fault | 36: Poll Timer | 17: Stay Armed |
| | 18: Siren/Bell Fault | | 18: Ready |
| | Zone Output Types (Mimic) | | Zone Output Types (Alarm) |
| | 01: Zone 01 Mimic | 17: Zone 17 Mimic | 33: Zone 01 Alarm |
| | 02: Zone 02 Mimic | 18: Zone 18 Mimic | 34: Zone 02 Alarm |
| | 03: Zone 03 Mimic | 19: Zone 19 Mimic | 35: Zone 03 Alarm |
| | 04: Zone 04 Mimic | 20: Zone 20 Mimic | 36: Zone 04 Alarm |
| | 05: Zone 05 Mimic | 21: Zone 21 Mimic | 37: Zone 05 Alarm |
| | 06: Zone 06 Mimic | 22: Zone 22 Mimic | 38: Zone 06 Alarm |
| | 07: Zone 07 Mimic | 23: Zone 23 Mimic | 39: Zone 07 Alarm |
| | 08: Zone 08 Mimic | 24: Zone 24 Mimic | 40: Zone 08 Alarm |
| | 09: Zone 09 Mimic | 25: Zone 25 Mimic | 41: Zone 09 Alarm |
| | 10: Zone 10 Mimic | 26: Zone 26 Mimic | 42: Zone 10 Alarm |
| | 11: Zone 11 Mimic | 27: Zone 27 Mimic | 43: Zone 11 Alarm |
| | 12: Zone 12 Mimic | 28: Zone 28 Mimic | 44: Zone 12 Alarm |
| | 13: Zone 13 Mimic | 29: Zone 29 Mimic | 45: Zone 13 Alarm |
| | 14: Zone 14 Mimic | 30: Zone 30 Mimic | 46: Zone 14 Alarm |
| | 15: Zone 15 Mimic | 31: Zone 31 Mimic | 47: Zone 15 Alarm |
| | 16: Zone 16 Mimic | 32: Zone 32 Mimic | 48: Zone 16 Alarm |
| | | | 49: Zone 17 Alarm |
| | | | 50: Zone 18 Alarm |
| | | | 51: Zone 19 Alarm |
| | | | 52: Zone 20 Alarm |
| | | | 53: Zone 21 Alarm |
| | | | 54: Zone 22 Alarm |
| | | | 55: Zone 23 Alarm |
| | | | 56: Zone 24 Alarm |
| | | | 57: Zone 25 Alarm |
| | | | 58: Zone 26 Alarm |
| | | | 59: Zone 27 Alarm |
| | | | 60: Zone 28 Alarm |
| | | | 61: Zone 29 Alarm |
| | | | 62: Zone 30 Alarm |
| | | | 63: Zone 31 Alarm |
| | | | 64: Zone 32 Alarm |

| Communicator Programming | | | | | | | |
|-----------------------------------|---------------------------|---|-------------------------------------|------------------------------------|---------------------------------|--|----------------------------|
| Menu: ⑦ ① | | Communicator Options | | | | | Page 50 |
| Enable On-Board Communicator 1 | Enable DTMF Dialling 2 | Switch to Pulse Dialling after 3 rd Attempt 3 | Enable European Pulse Dialling 4 | Enable Auto Test Transmission 5 | Enable Cancel Call Waiting 6 | Enable Backup to Receiving Centre 7 | Enable Blind Dialling 8 |
| [] XX | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] ✓✓ |

[illegible]

| | | | | | | | | | |
|--|--|--------|--------|--------|--------|--------|--------|--------|--------|
| | | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
| | | [] XX | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |

| | | | | | | | | |
|-------------------------------|-----------|--|-----------|-----------|-----------|-----------|-----------|----------------|
| Menu: ⑦③ | | Fast Format/Speech Restore Channels | | | | | | Page 55 |
| Channel 1 | Channel 2 | Channel 3 | Channel 4 | Channel 5 | Channel 6 | Channel 7 | Channel 8 | |
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | |
| [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | [] ✓✓ | |
| Menu: ⑦④ | | Fast Format Open/Close Channels | | | | | | Page 56 |
| Channel 1 | Channel 2 | Channel 3 | Channel 4 | Channel 5 | Channel 6 | Channel 7 | Channel 8 | |
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | |
| [] XX | [] XX | [] XX | [] ✓✓ | [] XX | [] XX | [] XX | [] XX | |
| Menu: ⑦⑤ | | Cancel Call Waiting Sequence | | | | | | Page 54 |
| Cancel Call Waiting Sequence: | | [] None | | | | | | |

| Download Programming | | | | | | | |
|-----------------------------|---------------------------|---|-----------------------------|-----------------------------------|------------------------------|--------------------------|---------------------------|
| Menu: ⑦⑥ | | Download Menu Options | | | | | Page 60 |
| ① | Download Options | Enable Attended Download | Enable Unattended Call Back | Enable 2-Call Answer Phone Defeat | Restrict Download when Armed | Download when Part Armed | Disconnect Telephone Line |
| | | 1 | 2 | 3 | 4 | 5 | 6 |
| | | [] XX | [] XX | [] XX | [] XX | [] XX | [] XX |
| ① | Download Tel No | [] None | | | | | |
| ② | Download Password | [] [] [] [] [] [] [] [] [] None | | | | | |
| ③ | Dial Attempts | [] 1 | | | | | |
| ④ | Ring Count | [] 2 | | | | | |
| ⑤ | Com1 Device Type | [] 0 Types: 0 = PC-Com; 1 = RadioPlus; 2 = Inovonics Radio; 3 = ComIP; 4 = WebWayOne/Emizon Module; 5 = Chiron Module | | | | | |
| ⑥ | ComIP Address/Port | Address: [] . [] . [] . [] Port: [] [] [] [] [] [] None | | | | | |
| ⑦ | ComIP Gateway | [] . [] . [] . [] None | | | | | |
| ⑧ | ComIP Subnet Mask | [] 8 | | | | | |
| ⑨ | Com 2 Device Type | [] 0 Types: 0 = PC-Com; 1 = RadioPlus; 2 = Inovonics Radio; 3 = ComIP; 4 = WebWayOne/Emizon Module; 5 = Chiron Module | | | | | |
| 🏠 | Chiron Iris Setup | [] 0 Options: 1 = Access Point Name; 2 = User Name; 3 = Password; | | | | | |

| Reporting Codes Programming | | | | | | | | |
|--|----------|------------|----------|--------------|--|-------------|----------|---------------|
| Menu: ⑦⑦ Zone Alarm/Restore Codes | | | | | Menu: ⑦⑧ Zone Bypass/Unbypass Codes | | | |
| Page 63 | | | | | Page 63 | | | |
| Zone | Event No | Alarm Code | Event No | Restore Code | Event No | Bypass Code | Event No | Unbypass Code |
| 01 | 00 | [] [] 31 | 01 | [] [] 00 | 00 | [] [] 61 | 01 | [] [] 00 |
| 02 | 02 | [] [] 32 | 03 | [] [] 00 | 02 | [] [] 62 | 03 | [] [] 00 |
| 03 | 04 | [] [] 33 | 05 | [] [] 00 | 04 | [] [] 63 | 05 | [] [] 00 |
| 04 | 06 | [] [] 34 | 07 | [] [] 00 | 06 | [] [] 64 | 07 | [] [] 00 |
| 05 | 08 | [] [] 35 | 09 | [] [] 00 | 08 | [] [] 65 | 09 | [] [] 00 |
| 06 | 10 | [] [] 36 | 11 | [] [] 00 | 10 | [] [] 66 | 11 | [] [] 00 |
| 07 | 12 | [] [] 37 | 13 | [] [] 00 | 12 | [] [] 67 | 13 | [] [] 00 |
| 08 | 14 | [] [] 38 | 15 | [] [] 00 | 14 | [] [] 68 | 15 | [] [] 00 |
| 09 | 16 | [] [] 39 | 17 | [] [] 00 | 16 | [] [] 69 | 17 | [] [] 00 |
| 10 | 18 | [] [] 3A | 19 | [] [] 00 | 18 | [] [] 6A | 19 | [] [] 00 |
| 11 | 20 | [] [] 3B | 21 | [] [] 00 | 20 | [] [] 6B | 21 | [] [] 00 |
| 12 | 22 | [] [] 3C | 23 | [] [] 00 | 22 | [] [] 6C | 23 | [] [] 00 |
| 13 | 24 | [] [] 3D | 25 | [] [] 00 | 24 | [] [] 6D | 25 | [] [] 00 |
| 14 | 26 | [] [] 3E | 27 | [] [] 00 | 26 | [] [] 6E | 27 | [] [] 00 |
| 15 | 28 | [] [] 3F | 29 | [] [] 00 | 28 | [] [] 6F | 29 | [] [] 00 |
| 16 | 30 | [] [] 30 | 31 | [] [] 00 | 30 | [] [] 60 | 31 | [] [] 00 |
| 17 | 32 | [] [] 00 | 33 | [] [] 00 | 32 | [] [] 00 | 33 | [] [] 00 |
| 18 | 34 | [] [] 00 | 35 | [] [] 00 | 34 | [] [] 00 | 35 | [] [] 00 |
| 19 | 36 | [] [] 00 | 37 | [] [] 00 | 36 | [] [] 00 | 37 | [] [] 00 |
| 20 | 38 | [] [] 00 | 39 | [] [] 00 | 38 | [] [] 00 | 39 | [] [] 00 |
| 21 | 40 | [] [] 00 | 41 | [] [] 00 | 40 | [] [] 00 | 41 | [] [] 00 |
| 22 | 42 | [] [] 00 | 43 | [] [] 00 | 42 | [] [] 00 | 43 | [] [] 00 |
| 23 | 44 | [] [] 00 | 45 | [] [] 00 | 44 | [] [] 00 | 45 | [] [] 00 |
| 24 | 46 | [] [] 00 | 47 | [] [] 00 | 46 | [] [] 00 | 47 | [] [] 00 |

Reporting Codes Programming

| | | | | | | | | |
|----|----|------------|----|------------|----|------------|----|------------|
| 25 | 48 | [] [] 00 | 49 | [] [] 00 | 48 | [] [] 00 | 49 | [] [] 00 |
| 26 | 50 | [] [] 00 | 51 | [] [] 00 | 50 | [] [] 00 | 51 | [] [] 00 |
| 27 | 52 | [] [] 00 | 53 | [] [] 00 | 52 | [] [] 00 | 53 | [] [] 00 |
| 28 | 54 | [] [] 00 | 55 | [] [] 00 | 54 | [] [] 00 | 55 | [] [] 00 |
| 29 | 56 | [] [] 00 | 57 | [] [] 00 | 56 | [] [] 00 | 57 | [] [] 00 |
| 30 | 58 | [] [] 00 | 59 | [] [] 00 | 58 | [] [] 00 | 59 | [] [] 00 |
| 31 | 60 | [] [] 00 | 61 | [] [] 00 | 60 | [] [] 00 | 61 | [] [] 00 |
| 32 | 62 | [] [] 00 | 63 | [] [] 00 | 62 | [] [] 00 | 63 | [] [] 00 |

| Menu: ⑦ ⑨ | | Non Zone Alarm/Restore Codes | | | | Page 63 |
|-----------|-------------------------------|------------------------------|-----------------|---------------|------------|---------|
| Event No | Event Type | Event | Reporting Group | Pulse/Express | Contact ID | SIA |
| 00 | AC Fail | Alarm | Maintenance | [] [] FF | 301 | AT |
| 01 | | Restore | Restore | [] [] AF | 301 | AR |
| 02 | Low Battery | Alarm | Maintenance | [] [] FE | 302 | YT |
| 03 | | Restore | Restore | [] [] AE | 302 | YR |
| 04 | Telephone Line Fault | Alarm | Maintenance | [] [] FD | 351 | LT |
| 05 | | Restore | Restore | [] [] AD | 351 | LR |
| 06 | Fail to Communicate | Alarm | Maintenance | [] [] 00 | 354 | YC |
| 07 | | Restore | - | - | - | - |
| 08 | Open/Close | Alarm | Open | [] [] B* | 401 | OP |
| 09 | | Restore | Close | [] [] C* | 401 | CL |
| 10 | Recent Closing | Alarm | Close | [] [] DA | 459 | CR |
| 11 | | Restore | - | - | - | - |
| 12 | Auto Open/Close | Alarm | Open | [] [] CC | 403 | OA |
| 13 | | Restore | Close | [] [] CC | 403 | CA |
| 14 | Auto Arm Deferred | Alarm | Close | [] [] D* | 405 | CE |
| 15 | | Restore | - | - | - | - |
| 16 | Remote Open/Close | Alarm | Open | [] [] B9 | 407 | OP |
| 17 | | Restore | Close | [] [] C9 | 407 | CL |
| 18 | Quick Arm | Alarm | - | - | - | - |
| 19 | | Restore | Close | [] [] C | 408 | CL |
| 20 | Open After Alarm (Cancel) | Alarm | Open | [] [] D* | 406 | OR |
| 21 | | Restore | - | - | - | - |
| 22 | Download Start | Alarm | Maintenance | [] [] 00 | | |
| 23 | | Restore | - | - | - | - |
| 24 | Download End | Alarm | Maintenance | [] [] 00 | | |
| 25 | | Restore | - | - | - | - |
| 26 | Group Bypass/Unbypass | Alarm | Bypass | [] [] 00 | 574 | |
| 27 | | Restore | Unbypass | [] [] 00 | 574 | |
| 28 | Log Capacity Alert (80%) | Alarm | Maintenance | [] [] 00 | 623 | JL |
| 29 | | Restore | - | - | - | - |
| 30 | Keypad Lockout (Device No) | Alarm | Tamper | [] [] EA | 421 | JA |
| 31 | | Restore | - | - | - | - |
| 32 | Code Tamper Alarm (Device No) | Alarm | Tamper | [] [] EA | 421 | JA |
| 33 | | Restore | - | - | - | - |
| 34 | Manual Test Transmission | Alarm | Test | [] [] 9A | 601 | RX |
| 35 | | Restore | - | - | - | - |
| 36 | Automatic Test Transmission | Alarm | Test | [] [] 9C | 602 | RP |
| 37 | | Restore | - | - | - | - |
| 38 | User Zone Test Start/End | Alarm | Test | [] [] 00 | | |
| 39 | | Restore | Restore | [] [] 00 | | |
| 40 | Auxiliary Power Fail/Restore | Alarm | Maintenance | [] [] FB | 300 | YP |
| 41 | | Restore | Restore | [] [] AB | 300 | YQ |
| 42 | Bell Output Fault/Restore | Alarm | Maintenance | [] [] 00 | 321 | YA |
| 43 | | Restore | Restore | [] [] 00 | 321 | YH |
| 44 | Installer Programming Start | Alarm | Maintenance | [] [] 00 | | |
| 45 | | Restore | - | - | - | - |
| 46 | Installer Programming End | Alarm | Maintenance | [] [] 00 | | |
| 47 | | Restore | - | - | - | - |
| 48 | Exit Error | Alarm | Close | [] [] 00 | | |
| 49 | | Restore | - | - | - | - |
| 50 | Verified Cross Zone Alarm | Alarm | Alarm | [] [] 00 | 140 | BV |
| 51 | | Restore | - | - | - | - |

| Menu: ⑦ ⑨ | | Non Zone Alarm/Restore Codes | | | | Page 63 |
|-----------|--------------------------------|------------------------------|-----------------|---------------|------------|---------|
| Event No | Event Type | Event | Reporting Group | Pulse/Express | Contact ID | SIA |
| 52 | Soak Test | Alarm | Test | [] [] 00 | | |
| 53 | | Restore | - | - | - | - |
| 54 | Fire Zone Trouble | Alarm | Tamper | [] [] 00 | 373 | FT |
| 55 | | Restore | Restore | [] [] 00 | 373 | FJ |
| 56 | System Power Up | Alarm | Maintenance | [] [] 00 | | |
| 57 | | Restore | - | - | - | - |
| 58 | Swinger Shutdown (Zone No) | Alarm | Alarm | [] [] 00 | | |
| 59 | | Restore | - | - | - | - |
| 60 | User Code Entered | Alarm | - | - | - | - |
| 61 | | Restore | - | - | - | - |
| 62 | Exit Started | Alarm | - | - | - | - |
| 63 | | Restore | - | - | - | - |
| 64 | Entry Started | Alarm | - | - | - | - |
| 65 | | Restore | - | - | - | - |
| 66 | Bell Active | Alarm | - | - | - | - |
| 67 | | Restore | - | - | - | - |
| 68 | Alarm Active | Alarm | - | - | - | - |
| 69 | | Restore | - | - | - | - |
| 70 | Keypad Tamper | Alarm | Tamper | [] [] 3* | 137 | TA |
| 71 | | Restore | - | - | - | - |
| 72 | Keypad Medical | Alarm | Priority Alarm | [] [] 00 | 100 | MA |
| 73 | | Restore | - | - | - | - |
| 74 | Keypad Fire/2-Wire Smoke | Alarm | Priority Alarm | [] [] 00 | 115 | FA |
| 75 | | Restore | Restore | [] [] 00 | 115 | FH |
| 76 | Duress Code Alarm | Alarm | Priority Alarm | [] [] 00 | 121 | HA |
| 77 | | Restore | - | - | - | - |
| 78 | Keypad Silent PA | Alarm | Priority Alarm | [] [] 2* | 122 | PA |
| 79 | | Restore | - | - | - | - |
| 80 | Keypad Audible PA/Auxiliary PA | Alarm | Priority Alarm | [] [] 2* | 120 | PA |
| 81 | | Restore | Restore | [] [] 00 | 120 | PH |
| 82 | Box Tamper | Alarm | Tamper | [] [] 30 | 137 | TA |
| 83 | | Restore | Restore | [] [] 00 | 137 | TR |
| 84 | Zone Tamper | Alarm | Tamper | [] [] 3* | 144 | TA |
| 85 | | Restore | Restore | [] [] 00 | 144 | TR |
| 86 | Zone Trouble | Alarm | Tamper | [] [] 00 | 380 | UT |
| 87 | | Restore | Restore | [] [] 00 | 380 | UJ |
| 88 | Expander/Remote Trouble | Alarm | Tamper | [] [] 00 | 333 | ET |
| 89 | | Restore | - | - | - | - |
| 90 | Auxiliary Tamper Input | Alarm | Tamper | [] [] 30 | 137 | TA |
| 91 | | Restore | Restore | [] [] 00 | 137 | TR |
| 92 | Date Changed | Alarm | Maintenance | [] [] 00 | 625 | JD |
| 93 | | Restore | - | - | - | - |
| 94 | Time Changed | Alarm | Maintenance | [] [] 00 | 625 | JT |
| 95 | | Restore | - | - | - | - |
| 96 | System Reset | Alarm | Maintenance | [] [] 00 | | |
| 97 | | Restore | - | - | - | - |
| 98 | Remote Control | Alarm | Test | [] [] 00 | - | - |
| 99 | | Restore | Restore | [] [] 00 | - | - |
| 100 | Confirmed Alarm | Alarm | Alarm | [] [] 00 | 139 | BV |
| 101 | | Restore | - | - | - | - |
| 102 | Monitored Alarm | Alarm | Alarm | [] [] 00 | 220 | BA |
| 103 | | Restore | Restore | [] [] 00 | 220 | BH |
| 104 | FOB Low Battery | Alarm | Maintenance | [] [] 00 | 384 | XT |
| 105 | | Restore | - | [] [] 00 | - | - |
| 106 | Radio Supervision | Alarm | Maintenance | [] [] 00 | 355 | YS |
| 107 | Radio Supervision | Restore | Maintenance | [] [] 00 | - | YT |
| 108 | Communication Port | Alarm | Maintenance | [] [] 00 | 356 | ET |
| 109 | | Restore | - | [] [] 00 | - | - |

* If the second digit for Pulse/Express is programmed as "0", the panel will replace this digit with the Zone/User/Keypad number.

A dash (-) indicates an event that is not generated by the control panel and therefore cannot be reported.

Notes

System Overview

Installation

Control Panel PCB Layout

Installing Remote Keypads & Expanders

Zone Connections

Siren/Bell, Telephone and Panel Outputs

Commissioning & Troubleshooting

Programming Menus

Programming Zones

Programming Partitions

Programming Global Options

Programming Remote Keypads

Programming Remote Expanders

Programming System Outputs

Programming the Communicator

Programming Download Options

Programming Reporting Codes

Programming Users

System Tests, Utilities and Using *RadioPlus*

Operating the Alarm System

Specifications

Quick Reference Guide & Defaults

Texecom

Texecom Limited, Bradwood Court, St. Crispin Way, Haslingden,
Lancashire BB4 4PW, England.

Technical Support:

UK Customers Tel: 08456 300 600

(Calls charged at 3.36 pence per minute from a BT landline. Calls from other networks may vary.)

International Customers Tel: +44 1706 233875

Email: techsupport@texe.com

© Texecom Limited 2016

INS159-13

